

WSGIFT

HH23770 Turtle
Decorative String
Lights



WSgift HH23770 Turtle Decorative String Lights User Manual

[Home](#) » [Support](#) » WSGift HH23770 Turtle Decorative String Lights User Manual 

Contents

- [1 WSGift HH23770 Turtle Decorative String Lights](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 FREQUENTLY ASKED QUESTIONS](#)
- [11 References](#)

WSGIFT

WSgift HH23770 Turtle Decorative String Lights



INTRODUCTION

Give your room a creative, ocean-themed light with the WSGift HH23770 Turtle Decorative String Lights. These 13-foot string lights are ideal for both indoor and outdoor decorations since they have 40 adorable green turtle-shaped LEDs that generate a warm white glow. They are totally cordless, weatherproof, and run on three AA batteries (not included), which makes them a flexible lighting option for weddings, parties, bedrooms, gardens, and holiday displays. You can set a timer, choose from eight various illumination settings, or just turn them on and off whenever it's convenient for you with an easy-to-use remote control. Easily wrapped around plants, fences, furniture, and other objects, the flexible silver wire adds a whimsical and enchanted accent to any environment. These long-lasting and fashionable turtle lights from WSGift, which retail for **\$13.99**, are an economical and environmentally responsible way to add a nautical feel to your room.

SPECIFICATIONS

Brand	WSgift
Product Name	Turtle Decorative String Lights
Model Number	HH23770
Price	\$13.99
Color	Green
Light Color	Warm White
Indoor/Outdoor Usage	Indoor & Outdoor
Style	Turtle Decorative String Lights
Theme	Holiday, Weddings, Party Decor
Product Length	13 ft
LED Quantity	40 LEDs (Turtle-Shaped)
Material	Silver Copper Wire
Power Source	Battery Powered (3xAA, not included)
Special Features	Timer Function, Remote Control, Weatherproof
Lighting Modes	8 Modes (Combination, In Wave, Sequential, Slo Glo, Chasing/Flash, Slow Fade, Twinkle /Flash, Steady On)
Water Resistance Level	Weatherproof
Easy Installation	Battery-operated, flexible wire for shaping

WHAT'S IN THE BOX

- Decorative String Lights
- User Manual

FEATURES

- **40 Turtle-Shaped LEDs:** This set of 40 tiny LED lights has a distinctive decorative appearance.
- **13 Ft Total Length:** With a total length of 13 feet, the string is long enough for a variety of decorating applications.
- **Battery Operated:** For convenient and portable use, three AA batteries (not included) are needed.
- **Weatherproof Battery Box:** Made to withstand weather and moisture, this battery box can be used both indoors and outdoors.
- Included is a remote control, which makes operating from a distance simple.

Smart Remote Control



Notice: Remote distance 26Ft, point direct to the USB interface

- **Timer Function:** To save energy, set the lights to switch off automatically after a predetermined amount of time.
- **Eight Lighting Modes:** Combination, Wave, Sequential, Slo Glo, Chasing, Slow Fade, Twinkle, and Steady On are among the various lighting effects available.
- **Warm White LED Light:** This light creates a nice atmosphere by emitting a gentle, warm white glow.
- Silver wire can be readily bent and curved to fit around fences, furniture, and plants.
- **Turtle-Themed Design:** This is Perfect for beach homes, sea life enthusiasts, or décor with an ocean theme.
- Both indoors and outside, it's ideal for adorning gardens, patios, balconies, and bedrooms.
- LEDs that use little electricity and produce strong illumination are known as energy-efficient LEDs.
- **Safe to Touch:** LEDs are safe for extended usage since they don't overheat.
- **Lightweight and portable:** You don't have to worry about power sources when moving or installing it anywhere.
- **Ideal for a Variety of Events:** Excellent for holiday decorations, festivals, weddings, and parties.



SETUP GUIDE

- **Unpack the Lights:** To prevent tangling, carefully take the string lights out of the package.
- **Check for Damage:** Before using, look for any indications of damage to the battery box and wiring.
- Batteries should be inserted by opening the battery box and placing three AA batteries in the proper polarity.
- **Secure the Battery Box:** To guarantee a correct connection, firmly close the battery box.
- **Turn On the Lights:** To turn on the lights, press the battery box's power button or use the remote control.
- **Choose a Lighting Mode:** Using the remote control or the button on the battery box, choose one of the eight lighting styles.
- **Use the Timer Feature:** If you'd like, you may program the lights to go out automatically after a predetermined amount of time.
- **Shape the Wire:** The flexible silver wire may be bent and shaped to fit around furniture, trees, and railings.
- **Secure in Place:** To hold the string lights in place, use sticky tape, hooks, or clips.
- **Test Various locations:** To determine the ideal lighting effect, try a variety of locations and angles.
- **Use Indoors or Outdoors:** If using the battery box outdoors, make sure it is in a dry area.
- **Avoid Water:** Although the lights are waterproof, do not immerse the battery box in water.
- **Modify as Needed:** Depending on the situation, alter the lighting's position or mode.
- **Pair with Other Decorations:** For a breathtaking visual effect, pair with other fairy lights or decorations.
- **Turn Off When Not in Use:** Turn off lights when not in use to extend battery life.

CARE & MAINTENANCE

- **Store Correctly:** Carefully coil the lights and keep them in a dry location when not in use.
- **Avoid Bending Too Much:** Bending the silver wire too often can cause the connections to become weaker.

- **Clean Gently:** To get rid of dust, use a dry or slightly moist towel to wipe the turtle LEDs and wiring.
- **Verify Battery Levels:** To keep lights bright, change out old batteries as they begin to fade.
- **Remove Batteries When Not in Use:** If the lights won't be utilized for an extended amount of time, remove the batteries to prevent corrosion.
- **Protect the Battery Box:** To avoid electrical problems, keep the battery compartment dry.
- **Avoid Extreme weather:** Keep the lights out of frigid weather and extreme heat.
- **Test Before Events:** Make sure the lights are functioning correctly by testing them before a particular occasion.
- **Handle Carefully:** To prevent breaking, shape the wire gently.
- **Do Not Pull on the Wire:** To avoid damaging the LEDs, do not pull on the string.
- **Use in Secure Places:** Keep the battery box away from anything that could catch fire.
- **Look for Loose Connections:** If the lights go out, look for loose connections in the wires and battery.
- Keep out of little children's reach to prevent inadvertent wire damage or choking dangers.
- **Check for Wear and Tear:** If you see frayed cables or broken LEDs, replace the lights.
- **Reposition for Best Effect:** Gradually reposition for best visual appeal and lighting impact.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Lights not turning on	Batteries inserted incorrectly	Check and reposition the batteries
Dim or flickering lights	Low battery power	Replace with new AA batteries
Remote not working	Dead remote battery	Replace the CR2 battery in the remote
Lights turning off randomly	Timer function activated	Check and reset the timer settings
Some LEDs not lighting up	Loose wiring	Gently adjust wire positioning
Modes not changing	Remote signal interference	Ensure remote is pointed directly at the battery box
Wire tangling easily	Flexible silver wire	Untangle carefully before setting up
Lights overheating	Overuse or faulty battery	Replace batteries and avoid prolonged continuous use
Not waterproof in heavy rain	Battery box exposed	Place battery box in a covered area
Short battery lifespan	High brightness or continuous use	Reduce brightness or use timer function

PROS & CONS

Pros:

- Unique and adorable turtle-shaped LEDs for themed décor
- Battery-operated, allowing portable and flexible placement
- Weatherproof design, suitable for both indoor and outdoor use

- Remote control for easy operation, including timer and modes
- 8 lighting modes for a customizable ambiance

Cons:

- Batteries not included, requiring separate purchase
- Battery-operated, may require frequent battery changes for prolonged use
- Limited to 13 ft, may not cover large areas without multiple sets
- Not USB-powered, limiting eco-friendly options
- Silver wire may be fragile, requiring careful handling

FREQUENTLY ASKED QUESTIONS

What are the main features of the WSgift HH23770 Turtle Decorative String Lights?

The WSgift HH23770 is a 13 ft battery-powered string light featuring 40 green turtle-shaped warm white LED lights. It has 8 lighting modes, a weatherproof battery box, and a remote control with a timer function, making it ideal for indoor and outdoor decorations.

How long is the WSgift HH23770 Turtle String Light?

The total length is 13 feet, making it suitable for weddings, holidays, parties, bedrooms, and outdoor decorations.

What power source does the WSgift HH23770 Turtle String Lights use?

These lights are battery-powered and require 3 AA batteries (not included in the package).

What lighting modes are available in the WSgift HH23770 Turtle Lights?

The lights have 8 different modes, including: Combination, In wave, Sequential, Slo Glo, Chasing/Flash, Slow fade, Twinkle/Flash, Steady on ,

Why are my WSgift HH23770 Turtle Lights not turning on?

The batteries are inserted correctly and are not depleted. The battery box is properly closed to maintain

contact. You are using the power button or remote correctly.

Why is the remote control not working for my WSgift HH23770 Turtle Lights?

The CR2 battery inside the remote is functional. The battery compartment of the remote is properly closed. You are within range and pointing the remote at the battery box.

How do I turn on/off the WSgift HH23770 Turtle Lights using the remote?

Press the ON/OFF button on the remote. You can also turn them on manually using the power button on the battery box.

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.