Manuals+ — User Manuals Simplified.

X2E ML-N4000 XORAYA External Storage Unit

X2E ML-N4000 XORAYA External Storage Unit Instructions

Contents

X2E
embedded system design

X2E ML-N4000 XORAYA External Storage Unit

Specifications

- Product Name: XORAYA External Storage Unit
- Compatible Devices: ML-N4000, N4000, N4000+, Datacube-C6
- FCC Authorization: Yes

Compatibility

The XORAYA External Storage Unit is designed to work seamlessly with XORAYA devices including ML-N4000, N4000, N4000+, and Datacube-C6. Ensure you have one of these compatible devices before proceeding. The XORAYA External Storage Unit can be used with the following XORAYA devices: ML-N4000, N4000, N4000+ and Datacube-C6.

This equipment has been tested and found to comply with the limits for a Class A digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at one's own expense. Changes or modifications made to this equipment not expressly approved for compliance may void the FCC authorization to operate this equipment.

Setup

1. Connect the External Storage Unit to your XORAYA device using the provided cable.
2. Power on both the storage unit and your XORAYA device.
3. Follow the on-screen prompts on your XORAYA device to initialize the storage unit.

Data Management

To store or retrieve data from the External Storage Unit, access the file management system on your XORAYA device. You can transfer files, backup data, or expand storage capacity using the External Storage Unit.

Maintenance

Keep the External Storage Unit in a cool, dry place away from direct sunlight. Clean the unit with a soft, dry cloth if needed. Avoid dropping or exposing the unit to extreme temperatures.

Documents / Resources

	X2E ML-N4000 XORAYA External Storage Unit [pdf] Instructions ML-N4000 XORAYA External Storage Unit, ML-N4000, XORAYA External Storage Unit, External Storage Unit, Storage Unit, Unit

References

- **User Manual**