



## Xfinity xFi Wireless Gateway TG1682G User Guide

[Home](#) » [Support](#) » Xfinity xFi Wireless Gateway TG1682G User Guide 

### Contents

- [1 Xfinity xFi Wireless Gateway TG1682G User Guide](#)
- [2 Inside the Kit.](#)
- [3 1. SET UP & CONNECT](#)
- [4 2. POWER UP & ACTIVATE](#)
- [5 DOWNLOAD](#)
- [6 References](#)
- [7 Related Posts](#)

**Xfinity xFi Wireless Gateway TG1682G User Guide**




## **Self-Installation Instructions**

### **XFINITY INTERNET AND VOICE**

For DIY Videos, Activation and FAQs:  
Go to [www.comcast.com/selfinstall](http://www.comcast.com/selfinstall)

**Inside the Kit.**




The Comcast Wireless Gateway 2 is a dual-band device and offers both 2.4 GHz and 5 GHz WiFi networks. While 5 GHz offers higher speeds than 2.4 GHz, not all WiFi devices will support the newer 5 GHz technology.

To learn more about your Wireless Gateway, refer to your User Guide in the XFINITY folder.

## 1. SET UP & CONNECT

XFINITY Wireless Gateway (Back) Actual device may vary.



**Connect the Ethernet cable from the Ethernet connection on your computer to the Ethernet connection on your Wireless Gateway.**

In order to successfully activate your service via a computer, your computer must be powered on and connected to the Wireless Gateway via the Ethernet cable.

For wireless activation, refer to the Wireless Gateway Activation and Connection Guide in your XFINITY folder.

**Connect a telephone cord (not included) from your telephone into the Tel 1 connection on your Wireless Gateway.**

Connect a coax cable from your cable wall outlet to the Cable/RF In connection on your Wireless Gateway. Make sure this connection is finger tight.

You may only need one coax cable for your Wireless Gateway connection, so select the length that suits your needs.

**Plug the power cord into your Wireless Gateway, then into an electrical outlet. If your Wireless Gateway has a Power button, turn it on.**

**After activation, use the Network Name (SSID) and Password on the bottom or side panel of the device to connect your wireless network.**

Refer to your XFINITY folder for alternate connection information.

## **2. POWER UP & ACTIVATE**


**Activate.**

[www.comcast.com/activate](http://www.comcast.com/activate)



Wait for the US/DS and Online LEDs to stop blinking and remain completely lit for 1 minute. This may take up to 20 minutes.

Once the light is solid, open up your Web browser.



To activate your service, you will need the Account Number given to you by the Comcast Service Center agent.



Your XFINITY Wireless Gateway is WiFi capable. To walk you through the setup of your home network, refer to the Wireless Gateway Activation and Connection Guide found in your XFINITY folder.



**To Activate:**

[www.comcast.com/activate](http://www.comcast.com/activate)

—or—

1-855-OK-BEGIN (1-855-652-3446)



Information on how to set up XFINITY® Internet and Voice features, such as online security and XFINITY voicemail, is available in your XFINITY folder.

1-800-XFINITY

© 2015 Comcast. All rights reserved.

---

## DOWNLOAD

Xfinity xFi Wireless Gateway TG1682G User Guide – [[Download PDF](#)]

---

---

## References

- [User Manual](#)