

Xianluo
SCB-01 Automatic
Cat Litter Box



Xianluo SCB-01 Automatic Cat Litter Box User Manual

[Home](#) » [Xianluo](#) » Xianluo SCB-01 Automatic Cat Litter Box User Manual 

Contents

- 1 Xianluo SCB-01 Automatic Cat Litter Box
- 2 FOR THE FIRST USE
- 3 INSTRUCTIONS FOR THE FIRST USE
- 4 APP
- 5 Overseas users
- 6 OPERATING INSTRUCTIONS
- 7 FAULT SELF-CHECK METHOD
- 8 PRODUCT LIST
- 9 INTRODUCTION OF CONTROL PANEL
- 10 CIRCUIT DIAGRAM
- 11 Filter and Bottom tray Disassembly & Assembly
- 12 PARAMETERS AND SPECIFICATIONS
- 13 FCC Warning
- 14 Product Specifications
- 15 Frequently Asked Questions
- 16 Documents / Resources
 - 16.1 References
- 17 Related Posts

Xianluo

Xianluo SCB-01 Automatic Cat Litter Box



Important reminder: In case of electronic failure please click “Reset” on the app settings page to restore operation after the machine is connected to the network!

MORE COMFORTABLE AND CLEAN LIFE WITH PETS



Please scan the code to watch the guide video.

FOR THE FIRST USE

1. Please place the machine on firm and flat ground.
2. Please add litter no higher than the MAX line after placing the machine well.
3. Please power on the machine and wait for it to finish self-check. Then it is ready for the cat to use.

Cautions

1. Please install and use this device strictly according to the instructions.
2. Please use it in an indoor environment, do not place it in direct sunlight, and keep it away from fire sources.
3. Please place the device on a flat and hard ground, and do not place articles on the top of the device.
4. Do not drag or place vigorously during placement to avoid device damage.
5. Kittens weighing less than 1kg and lactating cats should not use the auto-cleaning mode of the device.

6. It is strictly forbidden to soak or immerse the host part of this device.
7. Please unplug the power cord when moving, cleaning the device or not using it for a long time.
8. Please use the original power adapter to avoid damage to the device or potential safety hazards.
9. If children use this device, please make sure to use it under the guidance of an adult.
10. Please perform maintenance under the guidance of professionals to avoid all kinds of damage.
11. If you encounter product use problems, please contact customer service.
12. Please read this manual carefully before. Once installed and used, it means that you have carefully read and accepted the following safety instructions.
13. If the product does not work properly due to other unknown conditions, and you do not have time to refer to the instructions, please restart the power.


INSTRUCTIONS FOR THE FIRST USE

Unpacking

Turn over the carton to cut the tape from the bottom, then turn over back the carton to pull up the carton vertically.

Placement

Place the machine on the flat ground and make sure all four feet of the product are in contact with the ground. Items with a height of more than 30CM shall not be placed within 30CM in front of the product, so as not to affect the cat identification sensor outside the product.




Notice

- The four feet of the product must be in contact with firm flat ground!
- Place the machine on the soft carpet.
- Place the two front feet of the machine on the cat litter mat or carpet.

Accessories(in the litter storage box)


- Adapter*!
- Manual*!
- Garbage bag(45*50mm)*l(roll)




Notice: Please observe the installation method of garbage bags, or scan the code below to watch the video.

Add litter sand

Make sure the leveled litter height is between the MAX line and the MIN line. (The amount of sand can be adjusted according to the actual situation.)



1. Power on with an adapter and wait for the machine to self-check for about 3-8 minutes. It will automatically enter the state of sensing after self-check, no need to change its program.
2. After the cat leaves, the product will automatically clean up the clumped cat excrement in about 3 minutes, and last for 4 minutes.
3. After cleaning, the product will automatically start the smell cleaning function, and last for 30 minutes.



Notice

- Pickup or drag the product after powering up. (This will interfere with weight calibration in the reset program.)
- If you place the product in a narrow space or there is an infrared interference source in front of the product, the product self-check may take about 8 minutes. Please wait patiently.
- If the product detects that the space is not suitable for its infrared sensor to work, the infrared detection function will be automatically disabled after the self-check is completed. However, the weight detection system inside the product will assume the judgment work of whether the cat enters.
- During the clearing process, all keys are suspended. If you need to perform other functions, please wait until the clearing process is complete.

APP


Overseas users




- **Method 1:** You can scan the above icon with your mobile phone
- **Method 2** You can download the “Tuya” App and install it by searching it in the App Store.


Networking:

1. Confirm that the phone is connected to 2.4G WiFi, then turn on Bluetooth and Location.




2. Please press 'Auto' for 2 seconds. When you hear a beep sound, the machine starts to enter the distribution network mode. Open the mobile app for pairing, and the WIFI indicator light will turn on when the reception is successful. If the connection is not successful, it will remain turned off.
3. Open your phone App to add equipment or scan automatically.









4. After scanning to the machine, click the icon



5. Continue "Next" after inputting WiFi code and wait to connect.



6. Enter APP after connecting.



Notice

1. If the network configuration fails or a timeout message is displayed, check the following possibilities:
2. Whether Wi-Fi, Bluetooth, and Location switch are enabled at the same time.
3. Whether the WiFi is in the 2.4G band and whether the phone is connected to the 2.4G band WiFi network. (The product cannot recognize the 5G band network.)

- Whether the WiFi indicator on the panel is flashing during network configuration.
- Whether the WiFi network in your home is faulty or down, please check whether other devices can use the network normally.
- Whether the WiFi password is correct.
- Whether the WiFi signal is too bad, please move the machine to a nearby router and reconnect.
- The router connects to many wireless devices, causing IP address conflicts.
- For dual-frequency routers, the network cannot be configured directly. Users need to separate 2.4G and SG into independent channels in router Settings, and then select 2.4G channel for network configuration.

OPERATING INSTRUCTIONS

Auto

Click "Auto" on the panel or on the App to start auto-sensing for cats in and out. (It will open automatically after the product is powered on and self-checked.)




Notice

- Please click "Auto" on the panel or on the App to close auto-sensing, if you have kittens less than 1kg or the cat is pregnant. Then click "Clean" by your hand according to the actual use of the machine.
- If you are using litter that clumps quickly, you can adjust the "cleaning wait time" in the App, such as 1 minute, to clean the litter as quickly as possible and reduce the smell. If you are a multi-cat family, you can adjust the "cleaning interval" in the App, for example, 30 minutes, so as to avoid repeated ineffective cleaning of the product.
- If the cat enters the bin for more than 10 seconds, the cat is judged to have potty behavior. After the cat leaves for 3 minutes, the automatic cleaning procedure will be performed. (The default interval between cleanups is 15 minutes to prevent the product from being started too frequently during multiple cat use. If the machine doesn't work after your second cat pees, it may be because the interval between these two pees is less than 15 minutes.)
- The button on the App cannot be closed/opened or synchronized with the panel temporarily, please check the network status or re-configure the network or click the corresponding button on the App and repeat once or twice.

Clean:

Click "Clean" on the panel or on the App to start clearing immediately.



1. During the clearing process, all keys are suspended. If you need to perform other functions, please wait until the clearing process is complete.
2. Prolong the waiting time for cleaning in the phone App when the cat has diarrhea, so as to allow the cat litter to take enough time to clump and reduce the pollution of soft feces in the ball bin.
3. If you have restarted the machine, the waiting time of the "Clean" procedure will be restored to the default value of 3 minutes, which can be reset in the APP if necessary. (setting range: to 60 minutes)
4. Prolong the interval time between two clearings when you have multiple cats, so as to prevent repeated cleaning of products.
5. If you have restarted the machine, the interval time between two clearings will be restored to the default value of 15 minutes, which can be reset in the APP if necessary. (setting range: 0 to 120 minutes)

Add cat litter**Method 1**

In "Auto" mode, when the adding cat litter is more than 1kg, the "Auto" will flash. After 30 minutes, the cat litter will be automatically smoothed and the weight will be automatically calibrated. If you think 30 minutes is too long to wait, please long press the "Remove odor" button for 2 or more seconds. The sand will be smoothed immediately and the weight will be calibrated immediately. Or click "weight clearing" on the app to use it.

Method 2:

Power off the machine, then power it on again after adding sand.

Recommended suitable cat litter:

Mineral litter, Bentonite litter

Compatibility Cat litter



1. Tofu litter (diameter not more than 2.5mm, length not more than 15mm)
2. Mixed litter of Tofu litter and Bentonite litter (diameter not more than 2.5mm, length not more than 15mm).

Cat litter that is not recommended

1. Crystal litter, Crystal litter can not clump well, which will bring a serious cleaning burden to the inner wall of the cat litter basin.
2. Tofu litter with a length of more than 15mm, poor fluidity and filtration, there will be some stuck inside the filter. This phenomenon can also be alleviated by adjusting the parameter to 6 by “litter surface calibration” on the App.
3. Low-density cat litter, such as pine wood cat litter and activated carbon cat litter, it is difficult to rely on its own weight to pass through the filter. Some of them will be stuck inside the filter. This phenomenon can also be alleviated by adjusting the parameter to 6 by “sand surface calibration” on the App.

Notice

1. The machine won't stop when it is smoothing sand even a cat enters it at this moment. But don't worry. The machine only swings at some angles, this swing won't hurt the cat. (Besides this situation, the machine has a protection function. It will stop immediately once cat walks close to the entrance during clearing.)
2. Please make sure the height of the sand is between the MIN line and the MAX line after adding. If not, please adjust it with method 2.
3. You can find the sand surface correction option on the App to adjust the position of the sand. (In grade 0, the sand surface is tilted to the right, and in grade 6, the sand surface is tilted to the left.)




Replace litter

1. Replace the garbage bag with an empty one (ID avoid that the original one is already full of litter.);
2. Make sure the rest sand Is dose to the MIN line (to avoid overflow when the bin rotates);
3. Press"Replace Litter" for seconds, then wait for the machine to clear the rest;(about minutes)
4. Replace the garbage bag with an empty one again after clearing the sand;

Notice

1. click"Replace Litter" again to cancel If you click It by mistake or you find you have forgotten to replace the garbage bag first.
2. For fine mineral sand, when to replace the bag (step 1), to avoid the overflow of mineral sand from the mouth of the bag, you can first press "Clean for 2 seconds; then the litter bin will rotate 90- counterclockwise to ensure that the mouth of the bag Is upward when replacing. After bag replacement, repeat 3 and 4.
3. Or click on the app "Replace Utter bag" After changing, click back.



Remove Odor:

Method 1:

Click "Remove Odor" on the panel or click "Odorless" on your phone App.

Method 2

Set regular work on your phone App.

Notice


1. The machine will remove odor automatically for 30 minutes after every clearing.
2. It will stop automatically once the cat enters in, continues to work after the cat leaves.




Replace garbage bag:

When the indicator "Full" lights up, you need to replace the garbage bag.


1. Press "Clean" for 2 seconds, adjust the waste bin to the bag changing angle, open the waste bin, and take out the used garbage bag.
2. The bag change Angle lasts for 60 seconds, and the device automatically returns after 60 seconds. If the new garbage bag is not installed within 60 seconds, it can continue after the device is returned.



3. The drawstring of the new garbage bag is aligned with the tie-up pile, and the lower edge of the bag opening is clamped under the locating clip.
4. Wrap the garbage bag around the outer frame of the waste bin gate, and pull out the drawstring.




5. Press the drawstring into the tie-up pile, tighten it, and wind it.
6. After the installation, confirm that the automatic flip door of the waste bin is not blocked and can open and close normally. Arrange the back of the garbage bag to prevent being caught by the waste bin cover.




Notice

1. The "Full" prompt is only a reference value. When using different types of cat litter, its volume, density, and fluidity will affect the judgment of the "Full" prompt. In the APP, you can adjust the delay of the "Full" prompt according to your own use. The default value is (there is still a little space in the bag for garbage), and the maximum value can be adjusted to 15.
2. If you have restarted the machine, the delay of the "Full" prompt will be restored to the default value of 0, which can be reset in the APP if necessary.
3. Normally, the storage capacity of one cat can reach 15 days, and three cats can reach 5 days. Users can replace the garbage bag every 5 days depending on the number of cats or temperature conditions.




Unable to shovel sand:

1. Open the app client and click Settings in the lower right corner
2. Find the "clean Angle calibration" option, there are 0-5 gears to choose from, users can choose the gear according to usage habits.
3. The cleaning angle is normal at 0 and larger at 5.




Notice:

If you cannot take out the trash, please adjust appropriately



Solution for product failure


1. CDOpen the app client and click Settings in the lower right corner
2. Find "Reset" and click it to restore the factory settings with one click.



Notice: Do not use this function unless it is necessary, and do not use it repeatedly. If you encounter a problem that cannot be solved, please contact customer service.

Wash bin:


1. Please power off the machine first!
2. Open the buckle of the barrel compartment, and lift the bin. ⓂDry the bin before loading it back to the base!



Notice: If the indicator of bin sign lights up, please restart the machine or click "Clean" to make it clear once.

Lock the keyboard


Hold down "Auto" + "Remove Odor" for more than 2 seconds, or click the "Child Lock" on the app to enable or disable the child lock function.



"auto" + "Remove odor" 2 seconds

Turn off or turn on the infrared sensor:

When the cat litter box is placed in a cage or a narrow space, please hold down "Clean" + "Replace litter" for more than 2 seconds, or click the bucket infrared sensor option in the APP to turn off or on the bucket infrared sensor to prevent the machine from always judging wrongly.




"Clean" "Replace litter" 2 seconds



Timing:

sleep mode

When cat litter box is placed in the bedroom, you can set in the App “timed Do Not Disturb “to prevent the night-time activation from disturbing sleep.




Notice

1. During the DND period, the light on the panel will be off. Touch any button to exit the DND mode immediately.
2. If the product is clearing when setting DND, the machine will enter the DND state after the cleaning is complete.

Timing

Regular clean-up mode

- Set the machine to clean regularly in the App” Regular Cleaning”. 3.10.3 Timing net flavour
- Set the machine to remove odor regularly in the App”Deodo Timing”.



Notice: If the execution time of these scheduled procedures overlaps with the DND time, the product will first perform odor and cleaning, and then return to DND mode.

FAULT SELF-CHECK METHOD


1. Re-power the product, click "Remove Odor" more than 5 times within 2 minutes, and then the product will enter the testing mode.

In testing mode:















1. Click each key to check whether the key works properly. If it works properly, the PCB hardware is good.
2. Press the machine from the top with a force of more than 1kg to see whether the "Full" indicator flashes. If it does, the gravity sensor is good. If the bin mark keeps lighting up, the motor is good.
3. If the WiFi mark keeps lighting up, the WiFi hardware is good.
4. Cover the infrared sensor at the barrel mouth, if the "Auto" mark flashes, the sensor is good.

Repower on the machine after checking.


PRODUCT LIST



INTRODUCTION OF CONTROL PANEL

	Category	Function	Operation	Status	Prompt tone
wifi	Host Key	Clean	Click 	Start cleaning immediately	one ring
		Replace litter	Press  for 2"	Start replacing cat litter	Long ring for 1"
		Auto cleaning	Click 	Start Auto cleaning	one ring
		Remove odor	Click 	Start purifying the air	one ring
		Join network	Press  for 2"	Reset WiFi to start join network	Long ring for 1"
		Leveling	Press  for 2"	Leveling the cat litter	Long ring for 1"
		Change garbage bag	Press  for 2"	Adjust the barrel angle to the bag changing position	Long ring for 1"
		Lock/Unlock	Press  +  for 2"	Locked/Unlock	Long ring for 3"
	Indicator	Ring lamp	Lighting	Power On	
		Fault lamp (left)	Lighting 	Barrel is not installed or it cannot run	
		WiFi lamp (middle)	Lighting 	The device is connected	
			Flash 	The device is trying to connect to the network	
			Unlit 	The device is not connected	
		Waste full lamp (right)	Lighting 	Remind users to replace garbage bag when the waste bin is almost full	


CIRCUIT DIAGRAM



Filter and Bottom tray Disassembly & Assembly

In order to facilitate users' disassembly and assembly, the two accessories as shown in the picture are fixed with buckles. If they fall off during transportation, it is a normal phenomenon. Please refer to this picture, after installation, it can be used normally.

Disassembly & Assembly of ball bin filter




1. Disassembly & Assembly method of filter Hold the left and right sides of the filter and align it with the shaft hole of the filter baffle, Disassembly & assembly can be completed

Disassembly & Assembly of ball bin bottom tray




Scan the QR code to watch the disassembly & assembly video



Disassembly of the bottom tray

1. Remove the filter first
2. After aligning the front and rear anchor points, press the four anchor points into the installation slots in sequence
3. In order to improve the fitting area between the bottom tray and the ball bin, the edge of the bottom tray is relatively sharp Please wear gloves when disassembling

PARAMETERS AND SPECIFICATIONS



- **Product Name** Smart Cat Litter Box
- **Product Model** SCB-01
- **Whole Machine Size** 480(W)X520(D)X505(H)mm
- **Rated Voltage** DC12V
- **Rated Power** ≤18W
- **Suggested pet-type** cat

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Mobile devices:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body.

Product Specifications

- **Compliance:** FCC Part 15

- **Operating Conditions:** Indoor use only
- **Recommended Distance:** Minimum 20cm between device and body

Frequently Asked Questions

Why is the weight data only about half of that of my cats?

Please check whether the cat enters the machine with only two feet inside due to curiosity. Or is the machine placed on a flat ground with four feet connecting to the ground?

Why is the App showing motor failure/why is the fault indicator lighted on the equipment panel/why is the equipment always self-checking?

If the self-check takes more than 15 minutes, the fault indicator is on. It may be that the barrel compartment is not properly installed or there is foreign matter stuck in the rotation. Please open the buckle of the barrel compartment, lift the barrel to check, and then put it back according to the tips(on the base) and close the buckle.

Why is the clearing time so long?

Lower revs make timid cats less scared; It will prolong the whole clearing time if cats enter in or come close frequently due to curiosity.

Why the machine rotates back for a while before finishing the whole rotation?

A: In order to save sand and increase the capacity of the collection bin;

Why the poop can't be cleaned to the garbage box?

A: The door may be blocked by cat litter or garbage bag, or garbage too large to pass through; Please check whether the garbage entrance can be fully opened and closed smoothly(it is recommended to check every time after installing new bag). Large garbage can be handled manually to make it smaller first.

Why the machine didn't stop working while cat enters in?

A:The machine won't stop when performing sand leveling and weight calibrating. However, the safe structure of the product, together with the rotation Angle of the action($\pm 45^\circ$) is no danger for the cat to enter in when working.

Documents / Resources

	Xianluo SCB-01 Automatic Cat Litter Box [pdf] User Manual SCB-01, SCB-01 Automatic Cat Litter Box, Automatic Cat Litter Box, Cat Litter Box, Litter Box, B OX
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.