

Xin Hui A A Electronics Ltd AA-24DC2023-8RF-A Ceiling Fan Remote Controller



Xin Hui A A Electronics Ltd AA-24DC2023-8RF-A Ceiling Fan Remote Controller Instruction Manual


[Home](#) » [Xin Hui A A Electronics Ltd](#) » Xin Hui A A Electronics Ltd AA-24DC2023-8RF-A Ceiling Fan Remote Controller Instruction Manual 

Contents

- [1 Xin Hui A A Electronics Ltd AA-24DC2023-8RF-A Ceiling Fan Remote Controller](#)
- [2 IMPORTANT POINTS](#)
- [3 CONTROL INSTRUCTIONS](#)
- [4 FUNCTIONS OF RECEIVER AND TRANSMITTER](#)
- [5 INSTALLATION INSTRUCTIONS](#)
- [6 FCC](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)



Xin Hui A A Electronics Ltd AA-24DC2023-8RF-A Ceiling Fan Remote Controller



INSTALLATION INSTRUCTION FOR CEILING FAN REMOTE CONTROLLER

MODEL NO. OF RECEIVER: AA-24DC2023-8RF-A(3~5) / AA-24DC2023-8RF-WIFI-A(3~5) **MODEL NO. OF TRANSMITTER:** GG2017-17T4

IMPORTANT POINTS


1. Please read this instruction, and save it for further use.
2. Before installation, TURN OFF THE POWER OF YOUR CEILING FAN.
3. Please note that all wiring appliances should be installed by a qualified electrician.
4. This unit is to be used in a 100-B0V- 50/60Hz supply only. (Rating: RECEIVER: Max 40W for fan motor, Max 20W for LED. TRANSMITTER: transmitting frequency range: 433.92MHz±300kHz, Maximum transmitting power: 8dBm.)
5. Do not install in damp locations or immerse in water. (For indoor use only.)
6. Do not pull on or cut leads shorter.
7. Do not drop or bump the unit.
8. PLEASE NOTE: The battery will weaken with age and should be replaced before leaking takes place as this will damage the transmitter.
9. The batteries must be removed from the transmitter before it is scrapped. And the batteries shall be disposed of safely.
10. The switch shall be mounted at a height greater than 1.7m.
11. The electric shock protection of the RF receiver shall depend on its installation.

12. The RF remote controller shall be used within its rating range, otherwise, overheating and dangerous phenomena may occur.
13. The RF ceiling fan remote controller is made by XIN HUI A.A. ELECTRONICS LTD.
14. **CAUTION:** To reduce the risk of fire or injury, do not use this product in conjunction with any variable (rheostat) wall control.
15. **Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
16. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
17. **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 1. Reorient or relocate the receiving antenna.
 2. Increase the separation between the equipment and the receiver.
 3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 4. Consult the dealer or an experienced radio/TV technician for help.

CONTROL INSTRUCTIONS

1. The receiver is only controlled by the transmitter.
2. If you would like to operate the receiver by a new transmitter, you must use the transmitter to code the remote controller.
3. The way of code is within 10s after the receiver is powered on, you should press and hold on the key of FAN OFF for 3s to code. If code is successful, you will hear a sound "beep" from the buzzer.
4. After the code successfully, the new transmitter can control the receiver and the old transmitter can not control the receiver.

FUNCTIONS OF RECEIVER AND TRANSMITTER




1. CD lamp: The lamp will light up when you press any buttons.
2. FAN OFF: Turn off the ceiling fan.
3. LIGHT ON/OFF: Turn on or Turn off the lamp.
4. YELLOW: Set the LED to warm.
5. WHITE: Set the LED to neutral.
6. BLUE: Set the LED to cool.
7. SPEED 1: Turn on ceiling fan to speed 1.(the slowest speed)
8. SPEED 2: Turn on ceiling fan to speed 2.
9. SPEED 3: Turn on ceiling fan to speed 3.
10. SPEED 4: Turn on ceiling fan to speed 4.
11. SPEED 5: Turn on ceiling fan to speed 5.(the fastest speed)
12. FIR: Switch the Fan direction.
13. LED-: Press and hold to dim LED to the desired level.
14. LED+: Press and hold to brighten LED to the desired level. (Only for the specific LED.)
15. 2H: The LED and ceiling fan will turn off after two hours.
16. NATURAL WIND: Turn on ceiling fan to natural wind mode. Natural Wind mode: The fan circulating switch the

speed in the order of 1-2-3-4-5-6-5-4-3-2-1-.... And the speed switch interval is 19s.


17. 8H: The LED and ceiling fan will turn off after eight hours. Press and hold on 3s to reset the WIFI.

INSTALLATION INSTRUCTIONS

CAUTION: INCORRECT WIRE CONNECTION WOULD DAMAGE THIS RECEIVER.




1. Make the wiring connection must be stuck inside canopy.
2. Once the connection has been made, the receiver inserts into the drop rod hanging bracket. The canopy comes up to cover the receiver and bracket.
3. To change the batteries is to open the battery housing cover by sliding out the cover downward to the arrow shown direction while pressing down the cover with thumb. Holder for transmitter: if desired, install onto the wall with screws.



INPUT

OUTPUT

VIEW AFTER INSTALLATION




FCC

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources

	Xin Hui A A Electronics Ltd AA-24DC2023-8RF-A Ceiling Fan Remote Controller [pdf] Instr uction Manual AA-24DC2023-8RF-A Ceiling Fan Remote Controller, AA-24DC2023-8RF-A, Ceiling Fan Remot e Controller, Fan Remote Controller, Remote Controller, Controller
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.