

Xodux Window Wreath LED Candle Instructions / Battery Replacement

[Home](#) » [Xodux](#) » Xodux Window Wreath LED Candle Instructions / Battery Replacement 

Contents

1 USER MANUAL


1.1 Window Wreath with LED Candle(CW1SOOA)

2 INSTRUCTIONS

3 Questions about your Manual? Post in the comments!

3.1 Related Posts

USER MANUAL



Window Wreath with LED Candle(CW1SOOA)

INSTRUCTIONS

- Remove candle flame by turning counter clockwise.
- Insert 2 “AA” alkaline batteries(-) negative contact first into the candle stick. Be sure that the(+) and(-) terminals on each battery match the(+) and(-) contacts shown in the line drawing. Caution: Do not mix new and old batteries. Do not mix alkaline and standard (carbon-zinc) or rechargeable (nickel cadmium) batteries.
- Screw the candle flame back onto the candle stick by turning clockwise. Note: Candle will now be on. If left on, candle will turn off automatically after six hours and turn back on again the next day at the same time. The timer cycle may be interrupted when batteries need to be replaced.
- Candle can be turned off by un-screwing the flame cap

several turns.

©2020 Xodus Innovations, LLC

2025 Yore Avenue
Benton Harbor, MI 49022
All Rights Reserved.
www.xodusinnovations.com

Made in China

Read More About This User Manuals...

[Xodux-Window-Wreath-LED-Candle-Battery-Replacement-Manual-Optimized.pdf](#)

[Xodux-Window-Wreath-LED-Candle-Battery-Replacement-Manual-Original.pdf](#)

—

Questions about your Manual? Post in the comments!

Manuals+.