



Xppen Technology ACK05 Wireless Shortcut Remote User Guide

[Home](#) » [Xppen Technology](#) » Xppen Technology ACK05 Wireless Shortcut Remote User Guide 


Xppen Technology ACK05 Wireless Shortcut Remote User Guide



Contents

- [1 Overview](#)
- [2 Accessories](#)
- [3 Connection](#)
- [4 FCC WARNING](#)
- [5 CUSTOMER SUPPORT](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Overview



1. Power Slide Switch

2. Indicator light

In blue status:

- **a.** Flashing slowly: No Bluetooth connected
- **b.** Flashing quickly: Waiting for pairing with Bluetooth connection
- **c.** Always On: Successfully paired (Always On for 30 seconds and then off)

In red status:

- **a.** Flashing: Low battery ($\leq 20\%$)
- **b.** Always On: Charging
- **C.** Off: Fully charged

A purple color indicates that the red and the blue indicator are both On simultaneously

3. Roller

4. USB-C Port


5. Shortcut Key Group

4 customizable groups of 10 keys each for a total of 40 shortcut keys. You can disable them if you don't need them. One group is enabled by default, and K1 is the toggle key. Click to switch between key function groups.

* All descriptions and pictures shown are for reference only and may differ from the actual products.

Accessories

Wireless Shortcut Remote, Cable, Bluetooth receiver




All descriptions and pictures shown are for reference only and may differ from the actual products.

Connection

Wired Connection


Connect Wireless Keyboard Shortcuts to Your Computer Using Cable.



Wireless Connection


- A. Connection to the Bluetooth receiver

Plug the Bluetooth receiver into the computer, Slide switch, the indicator light is always on in blue, Always on for 30 seconds then off.



• B. Direct Bluetooth connection

1. Slide switch, the blue indicator light flashes slowly, Then long press the K1 shortcut key for 3 seconds to enter Bluetooth pairing, the blue indicator light flashes quickly.
2. Turn on the Bluetooth on the computer, set up and add Bluetooth device search for device name and complete Bluetooth pairing by clicking the device name, with the blue indicator always on, Always on for 30 seconds then off.
3. Slide switch again to turn off.



IV. Download and Install the Driver

1. Make sure your Wireless Keyboard Shortcuts is connected correctly to the computer.
2. Visit the XPPen website (www.xp-pen.com), click on the Support section and then Download.
Choose a product model and download the latest driver according to your computer system.
3. Follow the prompts to finish the driver installation.

4. temperature -10°-45°

Note:

For the best performance of your device, we highly recommend you check and update the driver regularly from XP Pen website.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

IC Caution:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

CUSTOMER SUPPORT

If you need any further assistance, please contact us at:

service@xp-pen.com

www.xp-pen.com

Documents / Resources

<div>Quick Guide</div> <div>Wireless Shortcut Remote</div>	<div>Xppen Technology ACK05 Wireless Shortcut Remote [pdf] User Guide</div> <div>ACK05, 2AKDT-ACK05, 2AKDTACK05, ACK05 Wireless Shortcut Remote, ACK05, Wireless Sh ortcut Remote, Shortcut Remote, Remote</div>
--	--

References

-  [pen.com](#)
-  [Graphic drawing tablets & Digital Art Pads With Screen | XPPen](#)