



## XPR Group WS4 Controller Instructions

[Home](#) » [XPR Group](#) » XPR Group WS4 Controller Instructions 



### Contents

- 1 WS4 Controller
- 2 Documents / Resources
  - 2.1 References

### WS4 Controller

**IMPORTANT NOTICE:** This WS4 controller is the latest version of CPU EPSILON/6.

No action is needed if the controller is installed on a completely new installation, but if retrofitted or added to an existing site, the complete installation, including the existing working controllers, must be updated to version 3.10 before adding the new version.

To download and update the new firmware 3.10, please visit our firmware update section on our website:

<https://www.xprgroup.com/software-firmware/>

Rev. 1.0





[XPR Group WS4 Controller](#) [pdf] Instructions  
WS4-4D, XPR Group, WS4 Controller, WS4, Controller

References

- [User Manual](#)

**Manuals+, Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.