



XPR-PROX-USB RFID Desktop Reader User Manual

[Home](#) » [xpr](#) » XPR-PROX-USB RFID Desktop Reader User Manual 

XPR-PROX-USB RFID Desktop Reader User Manual



Contents

- [1 Overview](#)
- [2 SPECIFICATIONS](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)

Overview



SPECIFICATIONS

- **Technology:** RFID (125 KHZ, 13.5 MHz)
- **Interface:** USB
- **Supported credentials:** EM4100 or HID PROX Compatible, NTAG, Mifare (Classic, Desfire, Plus, Ultralight)
- **Card encryption:** Mifare Classic, Desfire EV1, EV2, EV3
- **Driver:** Not required
- **Firmware upgrade:** Yes
- **Compatibility:** Windows 7, 8, 10, 11
- **Power supply:** 5 VDC (USB), 150 mA
- **Sound Indicator:** Internal buzzer

- **LED Indicators:** Red, Green
- **Housing:** Black ABS
- **Environmental rating:** Indoor
- **Operating temperature:** +5°C to +40°C
- **Operating humidity:** 5% – 95% relative humidity, non-condensing
- **Dimensions (mm):** 51 x 92 x 27

There is no need to install driver for this reader. Windows will detect it as a HID Compatible Device.

PROX-USB reader is compatible with following software:

- PROS CS
- Bio Manager
- PROA MS
- PROH MS
- XPR Toolbox
- XPR Smart Admin
- Device Manager
- XPR Card encoder
- Key Manage

The latest firmware version can be uploaded to the PROX-USB using XPR Toolbox software from <http://software.xprgroup.com/>

This product herewith complies with requirements of EMC directive 2014/30/EU, Radio Equipment Directive 2014/53/EU. In addition it complies with RoHS2 directive EN50581:2012 and RoHS3 Directive 2015/863/EU.



Documents / Resources

	xpr XPR-PROX-USB RFID Desktop Reader [pdf] User Manual XPR-PROX-USB RFID Desktop Reader, XPR-PROX-USB, RFID Desktop Reader, Desktop Reader, Reader
---	---

References

- [XPR Group. Downloads](#)
- [XPR Group - Safe access systems provider](#)