



XTREME HARMONIX Portable Lightshow Bluetooth Speaker User Manual

[Home](#) » [Xtreme](#) » XTREME HARMONIX Portable Lightshow Bluetooth Speaker User Manual 

Contents

- [1 XTREME HARMONIX Portable Lightshow Bluetooth Speaker](#)
- [2 FEATURES](#)
- [3 OPERATION](#)
- [4 OVERVIEW](#)
- [5 BLUETOOTH CONNECTION](#)
- [6 CHARGING YOUR SPEAKER](#)
- [7 SAFETY AND CARE INSTRUCTIONS](#)
- [8 FCC](#)
- [9 ONE YEAR WARRANTY](#)
- [10 SPECIFICATIONS](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)



XTREME HARMONIX Portable Lightshow Bluetooth Speaker



FEATURES

- Play wireless audio while watching a dazzling multicolor LED light show
- Compatible with 1 Bluetooth® enabled devices with range of up to 33ft
- Built-in phone stand to keep device in view plus audio controls for seamless control over your music
- Lightweight and portable to bring along anywhere!

OPERATION

1. Power Switch Knob: Turn the switch side to side on/off
2. Mode button: Short press the mode button to switch between 3 different modes:
 1. Bluetooth mode
 2. TF card mode
 3. USB drive mode
3. Playing/Pause: Short press to play or pause the song in Bluetooth/TF card/USB/ Aux modes
4. Volume down/previous track: Press and hold the "-" button to reduce volume. Short press to skip to the previous song or skip to the beginning of the current song.
5. Volume Up/Next Track: Press and hold the "+" button to increase the volume. Short press to skip to next song.
6. Micro USB Charging Port
7. USB Drive Port: Insert a USB drive with music to play either WAV or MP3 music in USB mode. When inserted,

the speaker will identify the USB and automatically switch to USB input mode. Note: the max capacity that can be used for the USB Drive is 32GB.

8. TF Card Reader: Insert a TF Card with music to play music in TF Card mode. Note: The max capacity that can be used for TF card mode is 64GB.

OVERVIEW



1. Play/Pause
2. Mode
3. Volume Up/Next Track
4. Volume Down/Previous Track
5. Phone Holder
6. Flashdrive Reader
7. Micro USB Charging Port
8. On/Off Button
9. Micro SD Card Reader

BLUETOOTH CONNECTION

Select Bluetooth mode with the Mode button. Enable Bluetooth on the phone or device that you want to pair. Select " Xtreme XBS9-1069" from the list of available Bluetooth devices to pair and connect. The unit prompt signal tone will confirm that you have paired successfully.

CHARGING YOUR SPEAKER

Connect the charging cable to speaker's Micro USB port. Insert the other end to a 5V USB power source(not included). The red charging light is illuminated when charging and will switch off when the speaker is fully charged.

SAFETY AND CARE INSTRUCTIONS

- This product contains a non-replaceable rechargeable lithium-ion. When discarding, follow your local/state guidelines.
- Do not use abrasive cleaning solvents to clean the unit.
- Disconnect the USB cable once the product is fully charged.
- Do not expose to heat sources or leave in a location that is likely to get excessively hot.
- Do not let the product get wet.
- Do not disassemble.
- Performance can be affected by the environment or when the product becomes discharged.
- Interruption can be caused by obstacles between the product and the
- Bluetooth device, by Wi-Fi or other high frequency signals, or If the product is brought out of range of the Bluetooth device.
- Charge fully before storing for a long period.

Note: Lithium-ion batteries will self-discharge over time. To ensure battery life, do not store the product in an uncharged state for a length of time. If left in a discharged state for too long a lithium-ion battery will no longer have the ability to be recharged.

FCC

Any changes or modifications not expressly approved by the party responsible for compliance could void this user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RADIATION EXPOSURE STATEMENT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ONE YEAR WARRANTY

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase. We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect

covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt. *Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property. For instructions about how to obtain warranty service for your product, please contact Customer Service at customerservice@xtremecables.com

WHAT'S INSIDE:

- Harmonix LED Bluetooth® Speaker
- Micro USB Charging Cable
- User Manual

SPECIFICATIONS

- **Bluetooth:** V5.0
- **Speaker Drivers:** 2 x 3W (mono)
- **Battery Type:** Built-In Lithium Ion Battery
- **Battery Capacity:** 800mAh
- **Input:** 5V/800mA
- **Playing Time:** 2-3 hours
- **Charge Time:** 2 hours

FCCID: 2A3E7-S5

855.999.8041

WWW.XTREMECABLES.COM

Documents / Resources



[XTREME HARMONIX Portable Lightshow Bluetooth Speaker](#) [pdf] User Manual
S5, 2A3E7-S5, 2A3E7S5, HARMONIX Portable Lightshow Bluetooth Speaker, HARMONIX, Po
rtable Lightshow Bluetooth Speaker, Lightshow Bluetooth Speaker, Bluetooth Speaker, Speaker
, Portable Speaker, XBS9-1069-BLK