



XTREME HELIX Light-Up Speaker User Guide

[Home](#) » [Xtreme](#) » XTREME HELIX Light-Up Speaker User Guide 



HELIX
Light-Up Speaker
User Guide



855-999-8041 | www.XtremeCables.com

Contents

- [1 ONE YEAR WARRANTY](#)
- [2 Safety and Care Instructions:](#)
- [3 Charging the Bluetooth Speaker](#)
- [4 Operating the Bluetooth Speaker](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

ONE YEAR WARRANTY

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with the original receipt of retail purchase.

We believe in our products and want to provide you with a replacement if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the product's warranty, the customer must provide proof of the retailer's receipt.

*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at customerservice@xtremecables.com

Package Contents:

Light up speaker

Charging Cable

Safety and Care Instructions:

- Do not attempt to disassemble the unit.
- Repairs to electrical equipment should only be performed by a qualified service person. Improper repairs may place user at risk and void the warranty.
- Do not puncture or harm the exterior surface of the product in any way.
- Do not drop or let the unit fall from high places, as doing so may damage the device.
- Do not use this unit for anything other than its intended user or purpose. Doing so may damage the device and void the warranty.
- This product is not a toy. Keep out of reach of children.
- Do not expose batteries or battery packs to excessive heat or open flame.
- Do not expose the unit to extremely high or low temperatures as this will shorten the life of the device, destroy the battery, and for distort certain parts.
- Do not use abrasive cleaning solvents to clean the unit. In order to prolong battery life, turn off when not in use.


Charging the Bluetooth Speaker

- Please make sure the battery is fully charged before initial use.
- To charge your Xtreme Helix Bluetooth Speaker, connect the supplied Micro USB cable into the Micro-USB charging port and connect the other end to a USB power outlet (5V adaptor not included). The LED indicator will illuminate RED to indicate that the speaker is charging. Allow approximately 3-4 hours of charging time to fully charge the speaker. When the battery is fully charged, the LED will turn off.

Operating the Bluetooth Speaker

1. Turn the Bluetooth Speaker ON by switching the power switch to the ON position. The speaker LED ring accent will flash indicating that the device is in pairing mode.
2. Enable Bluetooth search mode on your smartphone and select the pairing name "HELIX" on your Bluetooth device list. Once the speaker has successfully connected, the LED ring accent will remain solid.
3. To power down the Speaker, switch the power switch to the OFF position. The LED accent ring will turn off.

Documents / Resources

 <p>XTREME HELIX LIGHT-UP SPEAKER</p> <p>ENGLISH</p> <p>© 2018 XTREME. All rights reserved.</p>	<p>XTREME HELIX Light-Up Speaker [pdf] User Guide XTREME, HELIX, Light-Up, Speaker</p>
--	--

