



# XVX L75 Wireless Low Profile Mechanical Keyboard User Manual

[Home](#) » [xvx](#) » XVX L75 Wireless Low Profile Mechanical Keyboard User Manual 

## XVX L75 Wireless Low Profile Mechanical Keyboard User Manual



### Contents

- [1 Welcome](#)
- [2 Package Contents](#)
- [3 Introduction](#)
- [4 Installation, Connection and Use](#)
- [5 RGB Backlit Mode](#)
- [6 Multimedia Function](#)
- [7 Feature](#)
- [8 Troubleshooting Tips](#)
- [9 Pro Software Download Link](#)
- [10 Support](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)


## Welcome

Thank you for choosing Mechanical Rechargeable Keyboard. For the best results, please read the user manual carefully before using the product.

## Package Contents

- Tri-Mode Mechanical keyboard
- 2.4Ghz RF transceiver
- USB Type-C Cable
- User Manual
- 2 in 1 keycap puller/switch puller

## Introduction



### A Type-c Interface

### B Prompt light

Different states of the keyboard display different lights.

**Charging is required:** Flashing red.

**Charging:** Continuous red.

**Charging completed:** Change to other state lights.

**Bluetooth/2.4G connecting:** Flashing light

**Bluetooth/2.4G connected:** Stop flashing

**Switch wireless connection channel:** Blink and stop

### C Wireless mode switch

**OFF:** Wired mode

**ON:** Wireless mode

### D Win/Mac switch

## Installation, Connection and Use

### 1. 'Wired mode

Toggle the switch to "off" for wired mode.

Connect the USB charging cable to your computer

## 2. 2.4G wireless mode

Toggle the switch to “on” for wireless mode.

Press FN+R 3-6 seconds -> Prompt light flashing -> Plug the 2.4Ghz RF transceiver into the USB port of your computer -> The Prompt light stops flashing -> It can be used normally.

## 3. Bluetooth mode

Toggle the switch to “on” for wireless mode.

Press FN+R 3-6 seconds -> Prompt light flashing -> Your computer or mobile phone can find the Bluetooth, click Bluetooth connection -> The Prompt light stops flashing -> It can be used normally.

The name of the Bluetooth device is XVX L75 5.0/XVX L75 3.0.

This product has three Bluetooth channels, FN+Q, FN+W and FN+E, each of which can be connected to a device. The connection method is the same as above. Press FN+Q/FN+W/FN+E once to switch channels.

For example:FN+Q is connected to PC A, FN+W is connected to PC B, FN+E is connected to PC C, and 2.4G is connected to PC D. In wireless mode, press FN+Q to switch to PC A for use, press FN+W to switch to PC B for use, press FN+E to switch to PC C for use, and press FN+R to switch to PC D for use. When switching, the prompt lamp will flash once and then stop, indicating that the switching is succeeded. If the keyboard is not used for a long time, please turn off the wireless mode to save power.

4. It is better to use it after charging for the first time. This will extend battery life. When charging, the indicator light is red, and the red color changes to other colors after full charge. When the battery is low, the indicator will flash red. Please charge it in time.

## 5. Win/Mac/other

This product is applicable to Windows and Mac systems. Please turn the Win/Mac switch to the corresponding position. It can also be used on Android smartphones, iPhone and iPad through Bluetooth.

## RGB Backlit Mode

<b>FN+11:</b> Adjust 20 LED backlight modes
<b>FN+DEL :</b> Adjust lighting color , 8 modes
<b>FN+_&gt;:</b> Increase speed (When the maximum level is reached, thewill flash once.)
<b>FN+&lt;— :</b> Decrease speed (When the minimum level is reached, theme-key will flash once.)
<b>FN+F5:</b> Keyboard backlight – (When the minimum level is reached, thekey will flash once.)
<b>FN+F6:</b> Keyboard backlight + (When the maximum level is reached, theikey will flash once.)
<b>FN+TAB:</b> Constant backlight mode (Click again to exit)

When the keyboard is not in use for 2-3 minutes, the backlight will automatically turn off. Press any key to wake up the backlight again.

## Multimedia Function

MAC	WINDOWS	Function
F1	FN+F1	Screen brightness –
F2	FN+F2	Screen brightness +
F3	FN+F3	Task switching
F4	FN+F4	The computer
F5	FN+F5	Keyboard backlight –
F6	FN+F6	Keyboard backlight +
F7	FN+F7	Previous song
F8	FN+F8	Pause/Play
F9	FN+F9	Next song
F10	FN+F10	Mute
F11	FN+F11	Volume –
F12	FN+F12	Volume +
FN+WIN		Lock/Open WIN
FN+INS		END
FN+ESC 3-5 seconds		Restore factory settings (Except Bluetooth and 2.4G connection)

## Feature

1. Low profile Mechanical keyboard
2. Bluetooth + 2.4G wireless + USB type-c wired Tri-Mode
3. Rechargeable battery :3000mA
4. RGB backlight .20 kinds of lighting modes
5. N-key rollover

## Troubleshooting Tips

If you have problems using the keyboard, here are some ways to help you troubleshoot the problem:

Check whether the battery is powered.

Check whether the wireless mode switch is in the correct position.

Check whether the Win/Mac switch is in the correct position.

Check whether the 2.4Ghz RF transceiver is normally plugged into the USB port. Check whether Bluetooth has been switched to the correct channel.

Try reducing the distance between the keyboard and the computer.

Remove any large metal objects located between the keyboard and the computer that could interrupt the signal.

Cancel the Bluetooth connection, turn off the wireless mode, and disconnect type-c. Then turn on the wireless mode and reconnect the Bluetooth connection. (You can reconnect multiple times).

## Pro Software Download Link

<https://www.xvxchannel.com>

- Please note the macro software is only available for windows pc at this time.
- The software can only be used in wired mode.

## Support



[instagram.com/xvxkeyboard](https://www.instagram.com/xvxkeyboard)



[facebook.com/xvxkeyboard](https://www.facebook.com/xvxkeyboard)



<https://www.xvxchannel.com>



## Documents / Resources



[XVX L75 Wireless Low Profile Mechanical Keyboard](#) [pdf] User Manual  
L75 Wireless Low Profile Mechanical Keyboard, L75, Wireless Low Profile Mechanical Keyboard, Profile Mechanical Keyboard, Mechanical Keyboard, Keyboard

[Manuals+.](#)