




Home » xvx » XVX M67 Jadestone Mechanical Keyboard User Manual 📆



XVX M67 Jadestone Mechanical Keyboard User Manual



Contents [hide]

- 1 Product Basic Wired Version
- 2 Product Basic Wireless Version
- 3 Mode Setting and Repairing -Wireless Version
- 4 Backlight Control & FN Combination Keys
- 5 Q&A
- 6 System Function of Win
- 7 System Function of Mac
- 8 Wired Version & Wireless Version Differentiation
- 9 Documents / Resources
 - 9.1 References

Product Basic – Wired Version

Size:317.5×114.6×33.9mm±2

Layout: 67keys

Backlighting: RGB


Switch: Mechanical Switches

Version: USB Wired

Keycaps Method: IMD

Structure: Gasket Mount

Software: OMK I VIA



Package Contents

- 1 x Manual
- 1 x Brush
- 1 x Keycaps & Switch Puller
- 1 x USB Type-C Cable
- 3 x Switch

Product Basic – Wireless Version

Size:317.5×114.6×33.9mm±2

Layout: 67keys

Backlighting: RGB

Switch: Mechanical Switches

Battery Capacity:4000mAh

Version: 2.4G/USB-C/BT

Keycaps Method: IMD

Structure: Gasket Mount

Software: 0MK / VIA



Package Contents

- 1 x Keyboard
- 1 x Manual
- 1 x Brush
- 1 x Keycaps & Switch Puller
- 1 x USB Type-C Cable
- 3 x Switch
- 1 X Adapter

Mode Setting and Repairing - Wireless Version

2.4G mode: switch to " ? "

Plug the 2.4G adapter into the USB-A port of the device to use it.



2.4G Pairing: Long press FN+R to switch to 2.4G coding mode,
 the R key blinks rapidly, then plug in the 2.4G adapter, and stop blinking after successful coding.

Wired mode: switch to " in "

Connect the keyboard to the computer with the USB-C cable to use it.

Bluetooth mode: switch to " ≥ "

- Long press FN+Q, W, E to switch to BT1,2,3, the corresponding key will flash rapidly, stop fashing after successful code pairing.
- Short press FN+Q, W, E to switch to Bluetooth channel, the corresponding Bluetooth channel will be connected back, the corresponding indicator light will blink slowly, and stop blinking after successful connection back.

Battery Status:

- Lower than 25% of battery, the ESC key will flash red slowly for 30 seconds and then the previous light effect will be restored.
- The ESC key turns on white light to start charging, after 10 seconds and then the previous light effect will be restored.

Backlight Control & FN Combination Keys

FN + 🔼	Backlight Brightness +	FN + Pages	Backlight Saturation +
FN + ▼	Backlight Brightness -	FN + Pager	Backlight Saturation -
FN + 🔼	Backlight Speed +	FN+ Backspace	Switch Backlight Color
FN + 🚺	Backlight Speed -	FN+	Switch Backlight Mode
FN + ESC	Hold for 3 seconds to restore factory settings	FN + Win	Lock/Unlock WIN
FN + Delete		FN + P	Insert
FN + 0	Home	FN + []]	Pause
FN + [[PrtSc	FN + H	Loaded light effect (heart), press FN+H again to return to the original lighting mode
Fn + Space	Press and hold Fn+Space, the number of lights on key 1 to 0 correspond to the percentage of remaining power.		

Q&A

Q. How can I customize key bindings and use macro functions?

A. You can download the latest driver and JSON files from the official website www.xvxchannel.com. You can use VIA to customize key bindings, edit macro functions, and experience the full functionality of the XVx°M67 keyboard.

Note: This OMK/VIA can only be used in wired mode.

System Function of Win


FN + 1!	F1	FN + 78	F7
FN + 2@	F2	FN + 8*	F8
FN + 3#	F3	FN + 9(F9
FN + 45	F4	FN + 0)	F10
FN + 5%	F5	FN + -	F11
FN + 6^	F6	FN + =+	F12

System Function of Mac

FN + 1!	Screen brightness -	FN + 78	Previous song
FN + 2@	Screen brightness +	FN + 8*	Play/Pause
FN + 3#	Task view	FN + 9(Next song
FN + 45	Open the lauchpad	FN + 0)	Mute
FN + -	Volume -	FN + =+	Volume +


Wired Version & Wireless Version Differentiation

Wired Version:



Note: The function of the switch on the lower cover of the wired version is system switching

Wireless Version:



Note: The function of the lower cover switch of the wireless version is mode switching.

FN + A MAC



www.xvxchannel.com





support@xvxchannel.com



instagram.com/xvx_keyboard

Documents / Resources



XVX M67 Jadestone Mechanical Keyboard [pdf] User Manual

M67e, 202411.4, M67 Jadestone Mechanical Keyboard, M67, Jadestone Mechanical Keyboard, Mechanical Keyboard, Keyboard

References

- User Manual
- XVX
- ◆ 202411.4, Jadestone Mechanical Keyboard, Keyboard, M67, M67 Jadestone Mechanical Keyboard, M67e, Mechanical keyboard, xvx

Leave a comment

Your email address will not be published. Required fields are marked*

Comment*

Name

Email

Website

Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.