

**YISHE  
2BLQX-J6 Multi  
Function  
Finger Ring  
Remote Control**



## YISHE 2BLQX-J6 Multi Function Finger Ring Remote Control User Manual

[Home](#) » [YISHE](#) » YISHE 2BLQX-J6 Multi Function Finger Ring Remote Control User Manual 

### Contents

- [1 YISHE 2BLQX-J6 Multi Function Finger Ring Remote Control](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Specifications](#)
- [5 Instructions for use](#)
- [6 Special Note](#)
- [7 FCC Caution](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)

# YISHE

YISHE 2BLQX-J6 Multi Function Finger Ring Remote Control



## Product Information

The Multi-function Finger Ring Remote Control is a versatile device designed to provide convenient control over various electronic devices. Its compact design allows you to wear it as a ring, ensuring easy access whenever you need it. The remote control is compatible with a wide range of devices, making it a versatile tool for your home entertainment setup.

### Specifications:

- Product Name: Multi-function Finger Ring Remote Control
- Compatibility: Universal
- Material: High-quality plastic and metal
- Range: Up to 10 meters
- Battery: CR2032 (included)

## Product Usage Instructions

### Pairing the Remote Control:

To pair the remote control with your device, follow these steps:

1. Turn on the device you want to control.
2. Press and hold the pairing button on the remote control until the LED light flashes.
3. Use the device's own pairing function to connect it with the remote control.

### Basic Functions:

The remote control features standard functions such as power on/off, volume control, and channel selection. Simply press the corresponding buttons on the remote control to operate your device.

### Advanced Functions:

For advanced functions or specific device controls, refer to the user manual of your electronic device. The remote control can usually be programmed to perform custom functions based on your needs.

## FAQs

- **Q: How do I replace the battery?**

A: To replace the battery, locate the battery compartment on the remote control and carefully remove the old battery. Insert a new CR2032 battery into the compartment, ensuring the correct polarity, and close the compartment securely.


- **Q: Can I wear the remote control in water?**

A: It is not recommended to wear the remote control in water or expose it to moisture as it may damage the electronic components.

## Specifications

- **Main functions:** mobile phone/tablet-remote control shooting Photos Video software playback pause, e-book software page turning Applicable
- **System:** 10S/Android/HarmonyOS
- **Bluetooth name:** Yiser-J6
- **Transmission frequency:** 2.4 GHz-2.4834 GHz
- **Communication Distance:** 10 meters (30 feet)
- **Battery capacity:** 40mAh
- **Size:** 29mmx32mmx21 mm
- **Weight:** 5g

## Instructions for use



1. Toggle the remote control side switch (ON/OFF), the remote control indicator light will flash automatically
2. Turn on the phone "settings"-Bluetooth turn on Bluetooth, search for "Yiser-J6" and click the device name pair to display 'connected. After the indicator light stops flashing, the connection is successful (remote control is enabled)
3. Shooting key 1: support various camera software such as mobile phone camera Beauty Camera (ready to use with Bluetooth)
4. Shooting Key 2: supports all software such as TikTok/WeChat to shoot videos (a few models need to be set)
5. Direction keys: Watch the TikTok up and down keys to switch videos.
6. Multi-function key: Watch TikTok (double-click like) or Click pause/resume when other video software is used.

## Special Note

(when Apple IOS system settings and shooting Key 2 are invalid, the setting method is as follows)

1. Apple IOS 13.4 above setting method: # remote control to connect to mobile phone Bluetooth # portrait orientation lock “on” # open settings-accessibility-touch-accessibility touch-open # 105 15 or above system for the first time You can use it by connecting it. If you have adjusted the tracking sensitivity You need to move the dot back to the default position As shown in the figure below:



2. When the shooting Key 2 is invalid, adjust the position of the shutter key method:  
Enter the software shooting interface 1 long Press the shooting Key 2 Don't let go B, and press the direction key to move the “pointer/dot” to the range of the shutter circle of the shooting software.

## FCC Caution


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

## Documents / Resources

	<a href="#">YISHE 2BLQX-J6 Multi Function Finger Ring Remote Control</a> [pdf] User Manual 2BLQX-J6, 2BLQX-J6 Multi Function Finger Ring Remote Control, Multi Function Finger Ring Remote Control, Finger Ring Remote Control, Ring Remote Control, Remote Control, Control
---	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.