

**YISHE
J06 Multi
Functional
Finger Ring
Remote
Control**



YISHE J06 Multi Functional Finger Ring Remote Control Instruction Manual

[Home](#) » [YISHE](#) » YISHE J06 Multi Functional Finger Ring Remote Control Instruction Manual 

Contents

- [1 YISHE J06 Multi-Functional Finger Ring Remote Control](#)
- [2 Product Usage Instructions](#)
- [3 User Manual](#)
- [4 FAQs](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

YISHE

YISHE J06 Multi-Functional Finger Ring Remote Control




Specifications

- **Model:** J06
- **Dimensions:** 396mm
- **FCC Compliance:** FCC1521, FCC15B

Product Usage Instructions

1. **Unboxing:** Carefully unpack the product from its packaging.
2. **Assembly:** Follow the assembly instructions provided in the manual.
3. **Power On:** Connect the product to a power source and switch it on using the designated power button.
4. **Usage:** Use the product according to its intended purpose as described in the manual.
5. **Cleaning:** Regularly clean the product using a soft, dry cloth to maintain its appearance.

User Manual



1. Long press Button I for 3 seconds to turn on. The blue indicator light will automatically flash.
2. Enable Bluetooth in setting on your cell phone and search for “J06” to pair, and the indicator light stops flashing after pair succeed.
3. **Button I:** Supports various camera apps such as phone camera/beauty camera, etc/Double click to return to the previous menu
4. **Button II:** Supports all apps for video shooting such as TikTok/customize button.
5. **Direction Keys:** flip videos on TikTok up and down, left and right. Long press the up and down keys to adjust the volume and long press the left and right keys to switch songs.
6. **Multi-function Button:** click to pause/play when viewing TikTok video (double-click to like) or other video apps, long press to play/pause Music.
7. **Power off:** Long press the power I button for 3 seconds to turn off.

How to Set Up (Note for iPhone and iPad User)

1. Apple iOS 13.4 and above setting method: @Bluetooth connect @Screen auto-rotate lock @Open Settings – Accessibility – Touch – Assistive Touch – turn it on @For iOS 15 and above, simply connect for the first time to use. If the tracking sensitivity has been adjusted, return the dot to the default position.



2. For button II, you need to customize the controlling dot position If shooting pictures and videos function invalid. Please enter the software shooting interface, long press Button II without releasing, and click the direction key to move the “dot” into shutter circle range of the software. You don’t need to reset again unless you ignore the

device.

3. **Note:** If there is a connection issue or abnormal usage after successful connection, first delete (ignore this device), turn off the remote control and then reconnect.”

Tips:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FAQS

Q: How do I reset the product to its factory settings?

A: To reset the product, locate the reset button on the device and hold it down for 10 seconds.


Q: Can I use this product outdoors?

A: This product is designed for indoor use only and should not be exposed to outdoor elements.

Q: What should I do if the product malfunctions?

A: If the product malfunctions, refer to the troubleshooting section of the manual or contact customer support for assistance.

Documents / Resources



[YISHE J06 Multi Functional Finger Ring Remote Control](#) [pdf] Instruction Manual
J06 Multi Functional Finger Ring Remote Control, J06, Multi Functional Finger Ring Remote Co
ntrol, Finger Ring Remote Control, Ring Remote Control, Remote Control, Control

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.