



YOLINK YS1004-UC Hub Instructions

[Home](#) » [YOLINK](#) » YOLINK YS1004-UC Hub Instructions 



YS1004-UC Hub Instructions



YOINK ACADEMY TIPS & TRICKS TOPIC:

Contents

[1 Hub Firmware Update
Procedure](#)

[2 Documents / Resources](#)

[3 Related Posts](#)

Hub Firmware Update Procedure


REMARKS: On occasion, incremental improvements will be made to the Hub's firmware, at which time you must manually approve the update. Updates are not performed automatically. Please periodically check if any updates

are available for your Hub.

1. From the Rooms or Favorites screen, tap on the hub icon
2. Tap on the 3 dots (in the upper-right corner) to view the Settings screen
3. Scroll to the bottom of the page, to Firmware. On the right side will be a number, representing the current firmware version. If there is another number below it, with “ready now” an update is available
4. Tap on the revision number to start the update. The hub will update automatically in the background. You can start the update immediately by pressing the SET button



Documents / Resources

	<p>YOLINK YS1004-UC Hub [pdf] Instructions YS1004-UC, Hub, YS1004-UC Hub</p>
---	--