



YSI TOC 1030 V1.4.2 FW Patch Instructions

[Home](#) » [YSI](#) » YSI TOC 1030 V1.4.2 FW Patch Instructions 

Contents

- 1 [YSI TOC 1030 V1.4.2 FW Patch](#)
- 2 [Reinstall the cover on the 1030 unit](#)
- 3 [Specifications:](#)
- 4 [Product Usage Instructions:](#)
 - 4.1 [Installation:](#)
 - 4.2 [Setup:](#)
 - 4.3 [Operation:](#)
- 5 [FAQ](#)
 - 5.1 [Q: How do I update the firmware on TOC 1030?](#)
 - 5.2 [Q: What should I do if the device does not power on?](#)
- 6 [Documents / Resources](#)
 - 6.1 [References](#)
- 7 [Related Posts](#)

YSI TOC 1030 V1.4.2 FW Patch

INSTALLATION INSTRUCTION

Please follow these steps to perform the upgrade:

Prepare the USB stick

- Download the Zip file for the FW Patch
- Copy the Patch zip file to a USB stick.
- Unzip the zip file

This will create an Upgrade folder on the root folder of the USB stick

Prepare the 1030 Instrument

- Power OFF the TOC1030 device
- Remove cover from right side of the 1030 unit
- Remove the USB stick currently installed in the SOM board
- Insert the Upgrade USB stick
- Power ON the TOC1030 device

Perform the Upgrade

- When the 1030 unit boots up, the desktop screen will appear, and the Upgrade program will launch automatically
- The upgrade process should take 10-15 seconds.



Once completed, simply remove the USB stick and the 1030 Unit will automatically reboot

Reinstall the cover on the 1030 unit

Update the 1030 Date and Time

- From the Config-System menu, click on the Date/Time screen
- Edit the Date /Time as needed, then click Save

Specifications:

- Model: TOC 1030
- Version: V1.4.2
- Firmware Patch: Included

Product Usage Instructions:

Installation:

1. Ensure the device is powered off before installation.
2. Locate the appropriate mounting location for the TOC 1030.
3. Securely mount the device using the provided screws and brackets.

Setup:

1. Power on the TOC 1030 by connecting it to a power source.
2. Follow the on-screen instructions to set up the device.
3. Configure any necessary settings according to your requirements.

Operation:

1. Use the control panel or remote to navigate through the device’s menu.
2. Refer to the user manual for specific functions and features of the TOC 1030.

FAQ


Q: How do I update the firmware on TOC 1030?

A: To update the firmware, download the latest patch from the manufacturer’s website and follow the provided instructions for installation.

Q: What should I do if the device does not power on?

A: Check the power source and connections to ensure proper power supply. If the issue persists, contact customer support for assistance.

Documents / Resources

	<p>YSI TOC 1030 V1.4.2 FW Patch [pdf] Instructions 1030, TOC 1030 V1.4.2 FW Patch, TOC 1030, V1.4.2 FW Patch, Patch</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.