

ZAGG Pro Keys Wireless Keyboard and Case Owner's Manual

Home » ZAGG » ZAGG Pro Keys Wireless Keyboard and Case Owner's Manual

ZAGG Pro Keys Wireless Keyboard and Case



Contents


- 1 Inserting Your Device
- 2 Attaching the Keyboard with Magnetic, Foldable Flap
- 3 Detaching the Case from the Keyboard
- **4 Removing Your Device**
- 5 Powering On/Off
- 6 Pairing the Keyboard with Your Device
- 7 Charging Your Keyboard
- **8 Disconnecting Your Keyboard**
- 9 Checking Your Battery Level
- 10 Trouble Shooting
- 11 FCC Caution
- 12 Documents / Resources
- **13 Related Posts**

Holding your device in landscape mode with the volume control buttons facing up, press the top half of your device into the case and apply light pressure to snap it snuggly into place. Press the bottom half of your device into the case and check each corner to make sure your device is seated properly.



Attaching the Keyboard with Magnetic, Foldable Flap

Attach the case to the keyboard by setting the case in one of the two cradles on the keyboard (above the keys). Place the top of the magnetized, foldable back flap against the top of the backof the case. You'll feel it magnetically snap into place. This should create a triangular stand at the base of the flap that props up your tablet in the case.



Simply pull the magnetized back fiap away from the case.


Removing Your Device

Hold on to the top lip of the case and press against the back of the case. Then, grasp the exposed side of your device and lift/pull it away from the cover.




Powering On/Off

Press the power button to turn your Pro Keys keyboard on. A green LED will light briefly. Press and hold the power button for three seconds to turn your Pro Keys keyboard off. A red LED will flash indicating it has turned off.




Pairing the Keyboard with Your Device

Verify your device's Bluetooth® settings are on. Press and hold Pro Key's Bluetooth I button for three seconds. A blue LED under the power button will flash until pairing is complete. Select "ZAGG Pro Keys" from your device's list of available devices to complete pairing.




To pair a second device, press and hold the Bluetooth 2 button for three seconds, and follow the same procedure.



Charging Your Keyboard

Plug the Type-C end of the charging cable into the keyboard and the other USB end into your preferred USB charging outlet. A red LED light on the battery key will illuminate to show that your keyboard is charging. When this light turns off, your Pro Keys keyboard is finished charging.

Disconnect the charging cable.



Disconnecting Your Keyboard

First, detach the keyboard from the case. See previous instructions. There are three ways to switch to your onscreen keyboard:


- 1. Press the Keyboard Hide/Show button.
- 2. Turn off the Bluetooth connection from your device.
- 3. Turn the Pro Keys keyboard off.



Checking Your Battery Level

To check your Pro Keys' battery life, press fn + the battery key. The LED light will flash one of the following three ways:

- 3 green flashes = 50% or more battery life
- 2 yellow flashes = 25-49% battery life
- I red flash = less than 25% battery life



If your device doesn't respond to Pro Keys, there may be a simple explanation. Try the following steps.

- 1. Restart your device.
- 2. Turn your Pro Keys off and back on.
- 3. Forget and re-pair your Pro Keys.
- 4. If your Pro Keys does not establ ish or maintain a Bluetooth connection, reset the Bluetooth module by charging yourkeyboard.
- 5. If, after charging, your keyboard doesn't operate correctly, please contact ZAGG Customer Service.

If you still experience problems, please contact ZAGG Customer Service.

zagg.com/support/contact.php | questions@zagg.com 1-800-700-ZAGG [9244] 00-1-801-839-3906 for international customers

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ZAGG® and Pro Keys™ are trademarks of ZAGG Intellectual Property Holding Co., Inc. iPad® is a trademark of Apple Inc., registered in the U.S. and other countries.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ZAGG Inc is under li cense. Other trademarks and trade names are those of their respective owners.

Documents / Resources



