

ZALMAN i3 Series ATX Mid Tower Computer Case User Manual


[Home](#) » [ZALMAN](#) » ZALMAN i3 Series ATX Mid Tower Computer Case User Manual 

ZALMAN
COOL INNOVATIONS

Contents

- 1 ZALMAN i3 Series ATX Mid Tower Computer Case User Manual
- 2 Precautions
- 3 Specification
- 4 Accessories Component
- 5 I/O Port
- 6 1. Separating the side panel
- 7 2. Mounting the main board
- 8 3. Mounting PCI-E (VGA) card
- 9 4. Mounting 2.5" SSD and HDD
- 10 5. Mounting the 3.5" and 2.5" HDD
- 11 6. Cable Connection
- 12 7. Mounting the top fan
- 13 8. Mounting the fan and radiator in the front
- 14 Documents / Resources
 - 14.1 References
- 15 Related Posts

ZALMAN i3 Series ATX Mid Tower Computer Case User Manual



i3 Series

To ensure safe and easy installation, please read the following precaution.
Product design and specifications may be revised to improve quality and performance.


www.ZALMAN.COM

Precautions


- Read this manual carefully before installing.
- Check the product and components before installing. If you find any abnormality, contact the location where you purchased the product for a replacement or refund.
Wear gloves to prevent accidents when installing the product.
- Severe damage may occur when mounting the system, so do not apply excessive force.
- Connecting the cable incorrectly may cause a fire due to a short circuit. Make sure to refer to the manual when connecting the cable.
- Be careful not to block the ventilation hole of the product when using the system.
- Avoid locations with direct sunlight, water, moisture, oil, and excessive dust. Store and use the product in a well-ventilated location.
- Do not wipe the surface of the product using chemicals. (organic solvents such as alcohol or acetone)
- Do not insert your hand or other object into the product during operation, as this may injure your hand or damage the object
- Store and use the product out of children's reach.
- Our company assumes no responsibility for any problem that occurs due to the use of the product for purposes other than its designated purposes and/or the carelessness of the consumer.
- The exterior design and specifications of the product are subject to change without prior notice to consumers for quality improvement.

Specification


| Model | | i3 | i3-edge |
|---------------------------|-------|--|---------|
| Case Form Factor | | ATX MID tower | |
| Dimensions | | 445 x 196 x 456(H)mm | |
| Weight | | 4.7kg | |
| Case Materials | | Steel, Plastic | |
| Motherboard Support | | ATX / M-ATX / M-ITX | |
| Maximum VGA Length | | 360mm | |
| Maximum CPU Cooler Height | | 156mm | |
| Maximum PSU Length | | 180mm | |
| PCI Expansion Slots | | 7 | |
| Case Drive Bays | | 2 x Combo (3.5" or 2.5"), 3 x 2.5" | |
| Fan Mount Locations | Front | 3 x 120mm | |
| | Top | 2 x 120mm | |
| | Rear | 1 x 120mm | |
| Fans Included | Front | 3 x 120mm(with White LED effect) | |
| | Rear | 1 x 120mm(with White LED effect) | |
| Radiator Mount Locations | Front | 120mm / 240mm | |
| I/O Ports | | 1 x Headphone, 1 x Mic, 2 x USB 2.0, 1 x USB 3.0, 1 x Fan controller | |



Accessories Component




I/O Port



| # | Part | # | Part |
|---|------------------|---|----------------|
| A | USB 3.0 | E | HDD LED |
| B | USB 2.0 | F | Power button |
| C | Power LED | G | Fan controller |
| D | Mic & Headphones | H | Reset button |





1. Separating the side panel

Side Panel Removal




2. Mounting the main board

As 6 stand-offs are mounted by default, insert an additional standoff according to the type of main board by referring to the mounting position of the main board, and mount the main board on the case.




3. Mounting PCI-E (VGA) card

Loosen the screw, separate the PCI cover, mount the graphic card, and fix it using the screw.





4. Mounting 2.5" SSD and HDD

2.5" HDD and SSDs can be installed on the right side of case as shown in the diagram below.




5. Mounting the 3.5" and 2.5" HDD

Separate the tool-free 2.5" and 3.5" combo HDD cage and assemble the HDD or SSD. Mount the assembled HDD on the slot.




6. Cable Connection




7. Mounting the top fan

As shown in the picture, install the fan on the top of the case using bolts







8. Mounting the fan and radiator in the front

After Front Cover Removal and Mount the fan or the radiator on the mount hole in the front as shown in the figure.
 (For liquid-coolers, only products with a hose length of 280 mm or more can be installed)



ZALMAN
 COOL INNOVATIONS

Read More About This Manual & Download PDF:

| | |
|---|---|
|  | <p>ZALMAN i3 Series ATX Mid Tower Computer Case [pdf] User Manual</p> <p>i3 Series, ATX Mid Tower Computer Case, i3 Series ATX Mid Tower Computer Case, Mid Tower Computer Case, Tower Computer Case, Computer Case</p> |
|  | <p>ZALMAN i3-SERIES ATX Mid Tower Computer Case [pdf] User Manual</p> <p>i3-SERIES, ATX Mid Tower Computer Case, i3-SERIES ATX Mid Tower Computer Case, Tower Computer Case, Computer Case, Case</p> |
|  | <p>ZALMAN i3 Series ATX MID Tower Computer Case [pdf] User Manual</p> <p>i3 Series ATX MID Tower Computer Case, i3 Series, i3 Series Computer Case, ATX MID Tower Computer Case, Computer Case, ATX MID Tower</p> |
|  | <p>ZALMAN i3-Series ATX Mid Tower Computer Case [pdf] User Manual</p> <p>i3-Series ATX Mid Tower Computer Case, i3-Series, ATX Mid Tower Computer Case, Mid Tower Computer Case, Tower Computer Case, Computer Case, Case</p> |

References

- [ANDPRO.RU - интернет магазин компьютерной и офисной техники с выгодными ценами и доставкой](#)