



ZALMAN N5 OF ATX MID Tower Computer Case User Manual

[Home](#) » [ZALMAN](#) » ZALMAN N5 OF ATX MID Tower Computer Case User Manual 

ZALMAN N5 OF ATX MID Tower Computer Case User Manual



To ensure safe and easy installation, please read the following precaution.

* Product design and specifications may be revised to improve quality and performance without notice.

www.zalman.com



Contents

- 1 Precautions
- 2 Specifications
- 3 Accessories
- 4 I/O Ports
- 5 Removing the side panels
- 6 Removing the front panel
- 7 Mounting the motherboard
- 8 Motherboard size
- 9 Mounting the PSU
- 10 Mounting the PCI-E(VGA) card
- 11 Mounting the 3.5" and 2.5" SSD / HDD
- 12 Mounting the 2.5" SSD / HDD
- 13 Mounting the fans
- 14 Fan(s) Included
- 15 Fan Controller
- 16 I/O Connectors
- 17 Product Warranty
- 18 Documents / Resources
 - 18.1 References
- 19 Related Posts

Precautions


- Read this manual carefully before installing.
- Check the product and components before installing. If you find any abnormality, contact the location where you purchased the product for a replacement or refund.
- Wear gloves to prevent accidents when installing the product.
- Severe damage may occur when mounting the system, so do not apply excessive force.
- Connecting the cable incorrectly may cause a fire due to a short circuit.
Make sure to refer to the manual when connecting the cable.
- Be careful not to block the ventilation hole of the product when using the system.
- Avoid locations with direct sunlight, water, moisture, oil, and excessive dust.
Store and use the product in a well-ventilated location.
- Do not wipe the surface of the product using chemicals. (organic solvents such as alcohol or acetone)
- Do not insert your hand or other object into the product during operation, as this may injure your hand or damage the object.
- Store and use the product out of children's reach.
- Our company assumes no responsibility for any problem that occurs due to the use of the product for purposes other than its designated purposes and/or the carelessness of the consumer.
- The exterior design and specifications of the product are

Specifications

Model	N5 OF
-------	-------


Case Form Factor		ATX Mid-Tower
Dimensions		437(D) x 200(W) x 450(H)mm
Weight		3.6kg
Case Materials		Plastic, Steel
Motherboard Support		ATX / mATX / Mini-ITX
Maximum VGA Length		365mm
Maximum CPU Cooler Height		158mm
Maximum PSU Length		160mm
PCI Expansion Slots		7
Drive Bays		2 x Combo(3.5" or 2.5"), 4 x 2.5" SSD, 1 x 5.25 ODD
Fan Support	Top	3 x 120mm
	Front	2 x 120mm
	Rear	1 x 120mm
	Bottom	2 x 120mm

Fan(s) Included	Front	2 x 120mm (with White LED Effect)
	Rear	1 x 120mm (with White LED Effect)
Radiator Support	Front	120mm / 240mm
	Rear	120mm
I/O Ports		1 x Headphone, 1 x Mic, 2 x USB 2.0, 1 x USB 3.0, Reset Button, Power Button, Fan-LED Controller (Change Fan Speed & LED Brightness)




Accessories

User’s Manual



Buzzer



Cable Ties x 5



Thumm Screws x 2



SSD / MB Screws x 20




PSU / HDD / VGA Screws x 8



Motherboard Standoffs x 3




I/O Ports




#	Part	#	Part	#	Part	#	Part
	Power Button		Fan Controller		HDD / Power L ED		Headphone Jack
	Microphone Jack		USB 2.0 Ports		USB 3.0 Port		Reset Button

Removing the side panels


1. Acrylic Panel





2. Steel Panel



Removing the front panel




Mounting the motherboard




Motherboard size

※ Pick out the 8-Pin auxiliary power cable(CPU power connector) through the groove on top before installing motherboard.


1. ATX




2. mATX




3. Mini-ITX



Mounting the PSU




Mounting the PCI-E(VGA) card



Mounting the 3.5" and 2.5" SSD / HDD


1. HDD






HDD Screws

2




2. SSD


1



SSD / MB Screws

2






Mounting the 2.5" SSD / HDD


1



SSD / MB Screws x 8




2




1



SSD / MB Screws x 4




2




1



SSD / MB Screws x 4




2




Mounting the fans

1. Mounting the top fans
2. Mounting the bottom fans




Fan(s) Included

1. Front : 2 x 120mm Fan
 - with White LED Effects



2. Rear : 1 x 120mm Fan

- with White LED Effects




Fan Controller

4 Control Modes of Fan speed & LED brightness

Mode	Fan Speed	LED Brightness
Mode 1.	High	High
Mode 2.	Low	Low
Mode 3.	Low	Off
Mode 4.	Off	Off

※ Caution: shutting off your system fans could cause increase of system temperature.

I/O Connectors




Product Warranty

product name		model name	
date of purchase	Year//Month//Day	Serial No.	
Where to buy		sale price	

1. Quality warranty period: 1 year from the date of purchase. (However, when there is a purchase receipt)
2. Free A/S: In case of defects or defects in the product's own performance within the warranty period.
3. Paid A/S: When a problem occurs in using the product after the warranty period. However, free A/S processing is not available for the following matters even within the warranty period. It is handled at the consumer's expense.
 1. If you do not follow the precautions and precautions before installation specified in this user manual.
 2. In case of deformation, damage/destruction due to the user's intention, negligence or negligence.
 3. In case of deformation or malfunction due to user's arbitrary modification.
 4. When the quality assurance sticker is removed or damaged.
 5. In case of malfunction due to natural disaster.
 6. In case of malfunction due to use in an abnormally humid environment or a space with a lot of dust and




other foreign substances (worms, etc.).

4. Parts retention period: 2 years from the date of product discontinuation (However, the time of discontinuation is based on the final shipment date of the discontinued product.)
5. A/S information
 1. Operating Hours: Weekdays 10:00 ~ 16:00 (Closed on holidays, Saturdays and Sundays)
 2. How to apply
 1. Visit to: Visit www.zalmansvc.com and register for service
 2. Delivery by courier: After accessing www.zalmansvc.com and registering as a member, receive service application after entering your name, contact information and symptoms courier delivery prepaid
 3. Reception desk ※ After checking the exact location and address of the A/S center on the website, visit or send by courier.
6. Product transportation cost
 1. In case of initial defect: In case of initial defect, the round-trip fare will be borne by us.
 2. In case of free A/S: In principle, the cost of courier delivery within the free period shall be borne by the customer once (prepaid).
 3. Paid A/S and after warranty period: All round-trip costs are borne by the customer.
7. How to check the date of manufacture

<div>example</div> <div><div>2070119A01A00001</div><div>①②</div></div>	① Year of production 19 years → 19, 20 years → 20, 21 years → 21
	② Year of production January → January, February → February, March → 3 October → A, November → B, December → C

ZALMAN

Documents / Resources

	<p>ZALMAN N5 OF ATX MID Tower Computer Case [pdf] User Manual N5 OF, ATX MID Tower Computer Case, N5 OF ATX MID Tower Computer Case, MID Tower C omputer Case, Tower Computer Case, Computer Case, Case</p>
	<p>ZALMAN N5 OF ATX Mid Tower Computer Case [pdf] User Manual N5 OF, ATX Mid Tower Computer Case, N5 OF ATX Mid Tower Computer Case, Mid Tower Co mputer Case, Tower Computer Case, Computer Case, Case</p>
	<p>ZALMAN N5 OF ATX MID Tower Computer Case [pdf] User Manual N5 OF ATX MID Tower Computer Case, N5 OF, ATX MID Tower Computer Case, MID Tower C omputer Case, Tower Computer Case, Computer Case, Case</p>

References

- [zalman.com](#)
- [ANDPRO.RU - интернет магазин компьютерной и офисной техники с выгодными ценами и доставкой](#)