



# ZALMAN S4 ATX Mid Tower Computer Case User Manual

[Home](#) » [ZALMAN](#) » ZALMAN S4 ATX Mid Tower Computer Case User Manual 

## Contents

- [1 ZALMAN S4 ATX Mid Tower Computer Case](#)
- [2 Precautions](#)
- [3 Specifications](#)
- [4 Accessories](#)
- [5 I/O Ports](#)
- [6 Removing the side panels](#)
- [7 Removing the front panel](#)
- [8 Mounting the motherboard](#)
- [9 Motherboard size](#)
- [10 Mounting the PCI-E\(VGA\) card](#)
- [11 Mounting the 3.5" and 2.5" SSD / HDD](#)
- [12 Mounting the 2.5" SSD / HDD](#)
- [13 Mounting the radiator](#)
- [14 Pre-Installed Fan\(s\)](#)
- [15 Mounting the fans](#)
- [16 I/O Connectors](#)
- [17 Documents / Resources](#)
  - [17.1 References](#)
- [18 Related Posts](#)

# ZALMAN

**ZALMAN S4 ATX Mid Tower Computer Case**





- To ensure safe and easy installation, please read the following precaution.
- Product design and specifications may be revised to improve quality and performance without notice.

## Precautions

- Read this manual carefully before installing.
- Check the product and components before installing. If you find any abnormality, contact the location where you purchased the product for a replacement or refund.
- Wear gloves to prevent accidents when installing the product.
- Severe damage may occur when mounting the system, so do not apply excessive force.
- Connecting the cable incorrectly may cause a fire due to a short circuit. Make sure to refer to the manual when connecting the cable.
- Be careful not to block the ventilation hole of the product when using the system.
- Avoid locations with direct sunlight, water, moisture, oil, and excessive dust. Store and use the product in a well-ventilated location.
- Do not wipe the surface of the product using chemicals. (organic solvents such as alcohol or acetone)
- Do not insert your hand or other object into the product during operation, as this may injure your hand or damage the object.
- Store and use the product out of children's reach.
- Our company assumes no responsibility for any problem that occurs due to the use of the product for purposes other than its designated purposes and/or the carelessness of the consumer.
- The exterior design and specifications of the product are subject to change without prior notice to consumers for quality improvement.

## Specifications


Model		S4
Case Form Factor		ATX Mid-Tower
Dimensions		380(D) x 206(W) x 458(H)mm
Weight		3.6kg
Case Materials		Steel, Plastic
Motherboard Support		ATX / mATX / Mini-ITX
Maximum VGA Length		315mm (Without fan, Radiator)
Maximum CPU Cooler Height		160mm
Maximum PSU Length		180mm
PCI Expansion Slots		7
Drive Bays		2 x 3.5"(1 x Combo) / 1 x 2.5" SSD
Fan Support	Top	2 x 120mm
	Front	3 x 120mm
	Rear	1 x 120mm
	Bottom	2 x 120mm
Pre-Installed Fan(s)	Front	1 x 120mm
	Rear	1 x 120mm
Radiator Support	Front	120mm / 240mm
	Rear	120mm
I/O Ports		1 x Headphone, 1 x Mic, 1 x USB 2.0, 1 x USB 3.0, Power Button, Reset Button



## Accessories



User's Manual



Buzzer




PCI Slot covers x 2



Cable ties x 5



Thumb Screws x 2



USB Rubber covers x 3



HDD Screws x 8



SSD / MB Screws x 22



PSU / VGA Screws x 8



Motherboard stand-offs x 6



Fan Screws x 2




HDD Slide Screws x 2





Media rubber covers x 2

## I/O Ports




#	Part	#	Part	#	Part	#	Part
(a)	Power Button	(b)	HDD / Power LED	(c)	Reset Button	(d)	USB 2.0 Port
(e)	Headphone Jack	(f)	Microphone Jack	(g)	USB 3.0 Port		

## Removing the side panels




1. Acrylic Panel
2. Steel Panel

## Removing the front panel




## Mounting the motherboard




## Motherboard size


1) ATX




2) mATX



3) Mini-ITX







## Mounting the PCI-E(VGA) card



## Mounting the 3.5" and 2.5" SSD / HDD






1. HDD

 HDD Screws




2. SSD

 SSD / MB Screws




**Mounting the 2.5" SSD / HDD**




## Mounting the radiator

1. Mounting the front radiator Radiator 120mm / 240mm
2. Mounting the rear radiator Radiator 120mm






## Pre-Installed Fan(s)





- Pre-Installed rear 120mm fan
- Pre-Installed front 120mm fan


## Mounting the fans



1. Mounting the top fans
2. Mounting the front fans
3. Mounting the bottom fans

## I/O Connectors

HDD LED




Reset



Power LED



Power



HD Audio



USB 3.0



USB 2.0



## Documents / Resources

	<p><a href="#">ZALMAN S4 ATX Mid Tower Computer Case</a> [pdf] User Manual S4, ATX Mid Tower Computer Case, S4 ATX Mid Tower Computer Case, Mid Tower Computer Case, Tower Computer Case, Computer Case, Case</p>
	<p><a href="#">ZALMAN S4 ATX Mid-Tower Computer Case</a> [pdf] User Manual S4 ATX Mid-Tower Computer Case, S4, ATX Mid-Tower Computer Case, Mid-Tower Computer Case, Tower Computer Case, Computer Case, Case</p>

## References

- [zalman.com](http://zalman.com)
- [ANDPRO.RU](http://andpro.ru) - интернет магазин компьютерной и офисной техники с выгодными ценами и доставкой