

# **ZALMAN T6 ATX MID TOWER Computer Case User Manual**

Home » ZALMAN » ZALMAN T6 ATX MID TOWER Computer Case User Manual

**ZALMAN T6 ATX MID TOWER Computer Case User Manual** 



#### Contents [ hide 1 Precautions 2 Specification 3 Dimension 4 Accessories 5 I/O Ports 6 Dismantling the side panels 7 Mounting the motherboard 7.1 Motherboard stand-of Vis SSD / MB Motherboard size 8 Mounting the PCI-E (VGA) Card 9 Mounting the power supply 10 Mounting the 3.5" hard drive 11 Mounting the 2.5" SSD 12 Montage "ODD" 13 Mounting the front fan 14 Mounting the side fan 15 Connection the Cable 16 Documents / Resources 16.1 References

#### **Precautions**


17 Related Posts


- · Read this manual carefully before installing.
- Check the product and components before installing. If you find any abnormality, contact the location where you purchased the product for a replacement or refund.
- Wear gloves to prevent accidents when installing the product.
- Severe damage may occur when mounting the system, so do not apply excessive force.
- Connecting the cable incorrectly may cause a fire due to a short circuit. Make sure to refer to the manual when connecting the cable.
- Be careful not to block the ventilation hole of the product when using the system.
- Avoid locations with direct sunlight, water, moisture, oil, and excessive dust. Store and use the product in a well-ventilated location.
- Do not wipe the surface of the product using chemicals. (organic solvents such as alcohol or acetone)
- Do not insert your hand or other object into the product during operation, as this may injure your hand or damage the object.
- Store and use the product out of children's reach.
- Our company assumes no responsibility for any problem that occurs due to the use of the product for purposes other than its designated purposes and/or the carelessness of the consumer.
- The exterior design and specifications of the product are subject to change without prior notice to consumers for quality improvement.

#### **Specification**

Model		T6		
Case Form Factor		ATX Mid Tower		
Dimensions		377(D) x 200(W) x 430(H) mm		
Weight		2.82 kg		
Case Materials		Steel, Plastic		
Motherboard Support		ATX / mATX / Mini-ITX		
Maximum VGA Length		280mm (But, 260mm or less when front HDD is installed)		
Maximum CPU Cooler Height		165mm (But, 140mm or less when Side fan is installed)		
Maximum PSU Length		160mm		
PCI Expansion Slots		7		
Case Drive Bays		2 x 3.5", 2 x 2.5", 1 x 5.25"		
	Front	2 x 120mm		
Fans Mount Locations	Rear	1 x 120mm		
	Side	1 x 120mm		
Fan Included	Rear	1 x 120mm		
I/O Ports		1 x Headphone, 1 x Mic, 2 x USB 2.0, 1 x USB 3.0		

### **Dimension**





#### **Accessories**

Manuel



• slot cover

PCI x 2




• cable tie

x 5



• Lid in USB rubber

х3



Media Rubber Cover





• Hard drive screws

x 8



• See SSD / MB

x 22



• Vis PSU / VGA


x 8



• Motherboard stand-off x 6




### I/O Ports



#	Part	#	Part	#	Part	#	Part
	Power button		Microphone jack		Headphone jac k		USB 2.0 Ports
6	USB 3.0 Port		HDD / Power LED	9	Reset button		

## Dismantling the side panels




## Mounting the motherboard



Motherboard stand-of




Vis SSD / MB




Motherboard size


1. ATX



## 2. mATX





## 3. Mini-ITX




## Mounting the PCI-E (VGA) Card









## **Mounting the power supply**



Mounting the 3.5" hard drive








Α

Mounting the 2.5" SSD




See SSD / MB


1





2














### Mounting the front fan







### Mounting the side fan




### **Connection the Cable**





#### **Documents / Resources**



#### References

- **Z** zalman.com