

ZEBRA ET6x Smart Card CAC Reader Installation Guide

[Home](#) » [ZEBRA](#) » ZEBRA ET6x Smart Card CAC Reader Installation Guide 

Contents

- [1 ZEBRA ET6x Smart Card CAC Reader](#)
- [2 FAQs](#)
- [3 Removing the Reader Door](#)
- [4 INSTALLATION](#)
- [5 Using the Smart Card / CAC Reader](#)
- [6 Removing the Hand Strap](#)
- [7 CONTACT INFORMATION](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



ZEBRA ET6x Smart Card CAC Reader



FAQs

Support and Information:


Before using the unit, ensure it is configured to operate in your facility's network and run your applications. If you face issues, contact your facility's Technical or System Support. In case of equipment problems, they will contact Zebra support at zebra.com/support. For the latest guide version, visit zebra.com/support.

Quick Links:

- [View Quick Answers and User Documentation](#)
- [Visit Knowledge Base](#)
- [Request a repair for your product](#)
- [Download product manuals, drivers, software, and view how-to videos](#)
- [Join Community Connection of Zebra users and ambassadors](#)
- [Learn about product patent information](#)

Removing the Reader Door


1. Open the Reader door (1).
2. Loosen two captive screws (2).
3. Pull the Reader door out of the reader.



INSTALLATION


Smart Card / CAC Reader

1. Open the Reader door (1).
2. Align the two tabs (2) on the Reader with the connector on the tablet.
3. Press down on each screw to puncture the mylar (3).
4. Secure the Reader to the tablet using five captive screws. Torque to 4.5 kgf-cm (3.9 lbf-in.).




Using the Smart Card / CAC Reader


- If the Reader door is installed, slide the door latch (1) to open the reader door.




- Insert the card (chip facing down) into the card slot (1).




- Close the reader door and press down







- If required, secure the door with a M1.6 screw. Torque to 1.5 kgf-cm (1.3 lbf-in.).



Removing the Hand Strap



Installing the Hand Strap



CONTACT INFORMATION

Before you use the unit, it must be configured to operate in your facility's network and run your applications. If you have a problem running your unit or using your equipment, contact your facility's Technical or System Support. If there is a problem with the equipment, they will contact Zebra support at zebra.com/support For the latest version of the guide, go to zebra.com/support

- View user documentation. zebra.com/et6x-info



- View Quick Answers and Knowledge Base zebra.com/knowledge



- Request a repair for your product. zebra.com/repair



- Download product manuals, drivers, and software, and view how-to videos zebra.com/support



- Join Community Connection of Zebrausers and Ambassadors. zebra.com/supportcommunity




- Learn about product patent information. ip.zebra.com





MN-004993-01EN-P Rev.A 5/24

Documents / Resources

	ZEBRA ET6x Smart Card CAC Reader [pdf] Installation Guide ET6x Smart Card CAC Reader, ET6x, Smart Card CAC Reader, Card CAC Reader, CAC Reader , Reader
---	---

References

-  [Zebra Support Community](#)
-  [Zebra Support Community](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.