

ZEBRA I1AS1X0000NA Kickstrap Rugged Android Tablet



ZEBRA I1AS1X0000NA Kickstrap Rugged Android Tablet User Guide

[Home](#) » [ZEBRA](#) » ZEBRA I1AS1X0000NA Kickstrap Rugged Android Tablet User Guide 

Contents

- [1 ZEBRA I1AS1X0000NA Kickstrap Rugged Android Tablet](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Package Contents](#)
- [6 Installation](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)



ZEBRA I1AS1X0000NA Kickstrap Rugged Android Tablet



Product Information

Specifications:

- Product Name: L10 Kickstrap
- Package Contents: Kickstrap, M3 x 14.3 Silver Screw (2)

Product Usage Instructions

1. Install Kickstrap

Package Contents: Kickstrap, M3 x 14.3 Silver Screw (2)

Steps:

1. Place the Kickstrap in the desired position on the product.
2. Use the provided M3 x 14.3 Silver Screws to secure the Kickstrap in place.

2. Secure Kickstrap

Follow the below steps to securely install the Kickstrap:

1. Ensure the top handle is installed properly.
2. Use the provided silver screws to fix the Kickstrap securely.
3. Do not remove the top handle screws from the right side.

FAQ

- Q: Can I use different screws to secure the Kickstrap?


- A: It is recommended to use the provided M3 x 14.3 Silver Screws for securing the Kickstrap to ensure proper fit and function.
- **Q: What should I do if the top handle screws need replacement?**
 - A: Contact customer support for assistance if you need replacement top handle screws to maintain the integrity of the product.

Package Contents

1. Kickstrap
2. M3 x 14.3 Silver Screw (2)


Installation

Install Kickstrap



- If Top Handle is installed proceed to step (1a).
- Keep Kickstrap closed during installation.
- Place Kickstrap as shown. Screws are captive.


Secure Kickstrap



- Hand-tighten all 9 captive screws.

Top Handle Installed


- Remove only left bracket of handle.
- Install Kickstrap.
- Install left top handle bracket using long silver screws provided.



Notice: The information in this publication is subject to change without notice. Zebra Technologies Corp shall not be held liable for technical or editorial errors or omissions contained herein nor for accidental or consequential damages resulting from the furnishing, performance, or use of this material. ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corporation, registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. ©2019 Zebra Technologies Corporation and/or its affiliates. All rights reserved.

PN: 176028

Documents / Resources

	ZEBRA I1AS1X0000NA Kickstrap Rugged Android Tablet [pdf] User Guide I1AS1X0000NA Kickstrap Rugged Android Tablet, I1AS1X0000NA, Kickstrap Rugged Android Tablet, Rugged Android Tablet, Android Tablet, Tablet
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.