



# ZEBRA KVHB\_Mini Bluetooth Tracker Keys Finder User Manual

[Home](#) » [ZEBRA](#) » ZEBRA KVHB\_Mini Bluetooth Tracker Keys Finder User Manual 

## Contents

- 1 ZEBRA KVHB\_Mini Bluetooth Tracker Keys Finder
- 2 Quick instructions
  - 2.1 1. Equipment startup
  - 2.2 2. Binding devices
  - 2.3 3. Enable 'Lost Mode'
  - 2.4 4. Delete device
- 3 Main Functions
- 4 Instructions for using device buttons
- 5 Common Problem
- 6 6. What is the "search" network? How does it work?
- 7 Important reminder
- 8 Firmware update
- 9 Reference website
- 10 Specifications
- 11 FAQ
  - 11.1 Q: What devices are compatible with KVHB\_Mini?
  - 11.2 Q: How do I update the firmware of KVHB\_Mini?
  - 11.3 Q: Is there a specific startup procedure for KVHB\_Mini?
- 12 Documents / Resources
  - 12.1 References
- 13 Related Posts

**ZEBRA KVHB\_Mini Bluetooth Tracker Keys Finder**



## USER MANUAL

### KVHB\_Mini

Thank you for choosing KVHB\_Mini. Please read this manual carefully before use to avoid damage caused by improper use.

## Quick instructions

### 1. Equipment startup

Press and hold the device button for 5 seconds, and the device will beep twice to turn on.

### 2. Binding devices

- Open the built-in "Find" app on Apple.
- Bring the device closer to your iPhone, tap the "Items" tab, click "+", and select "Add Other Items".
- For devices with the words KVHB\_Mini, tap "Connect".
- Fill in "Custom Name" to name your device and select an emoji.
- Agree to register the device with your Apple ID.
- Tap "Finish" to bind successfully. At this point, enter the item list, click on play sound, and you can hear the device alarm.

### 3. Enable 'Lost Mode'

Open the built-in "Find" app on Apple, click on "Items" at the bottom of the screen, and then click on the name of the item.

Under "Lost Mode", click "Enable".

Follow the on-screen instructions and click "Continue" to enter your contact phone number or email.

After clicking "Next" to verify the information, please click "Enable" again to complete the settings.

#### **4. Delete device**

Open the built-in “Find” app on Apple, click on “Items” at the bottom of the screen, and then click on the name of the item.

Find “Remove Item” at the bottom of the list and tap “Remove” to complete the operation.

Explanation: After deleting the device, it will emit a beep beep sound, and the device will not shut down and is in pairing mode. If there is no re pairing within 10 minutes, the device will leave the pairing state and cannot pair with the app. If you need to pair devices, you need to click the device button once. At this point, the device enters pairing mode and can be re paired with the app.

### **Main Functions**

#### **1. Find devices**

The phone and device are within Bluetooth range (usually around ?? meters). When searching for an app, click play sound, and the device will emit music to help you quickly find nearby items.

#### **2. Global positioning**

- a. Open the Apple Search app and select the “Items” tab
- b. Select the KVHB\_Pro? you want to use from the list
- c. The emoji you have set for the KVHB\_Mini will be displayed on the map
- d. Click the “Route” button on the right side of “Play Sound” to locate and navigate to the location of the device

#### **3. Tracking and anti tracking**

- a. Place the KVHB\_Pro1 on the elderly, children, pets, and luggage, and track its location remotely.
- b. When searching for App and finding someone else’s KVHB\_Mini tracking, it can be achieved by continuously pressing the button to reverse track.

### **Instructions for using device buttons**

#### **1. Click Mute**

When the device alarms, clicking the device button once can cancel the alarm.

#### **2. Equipment status confirmation**

Double click the device button twice, the device will sound, indicating that the device is working. If the device does not sound, it indicates that the device is in a shutdown state. Press and hold the button for five seconds to turn on the device.

#### **3. The device enters pairing mode again**

After deleting the device, the device will emit a prompt sound and will not shut down. It is in pairing mode. If there is no re pairing within ?? minutes, the device will leave the pairing state and cannot pair with the app. If you need to pair devices, you need to click the device button once. At this point, the device enters pairing mode and can be re paired with the app.

#### **4. Restore factory settings**

Firstly, in Find Myapp, remove the device. Then, after the device is turned on, double-click the device button and

the device will sound. Immediately press and hold the device button for about five seconds until the device emits a prompt sound. Continue to press and hold the button for three seconds until the device plays the prompt sound. Release the button and the factory settings are restored. The device can be paired with a new account.

## **Common Problem**

### **1. Shutdown**

When the device is turned on, press the device button ? times continuously within ? seconds, the device emits a prompt sound, and the device enters a shutdown state.

### **2. When can the device be located by other Apple phones?**

When the device is disconnected from the owner's Apple phone for a period of time, the device can start being located by other Apple phones, and the owner can start to obtain the location of the device.

### **3. How to confirm if the device is turned on?**

Please double-click the device button twice, the device will sound, indicating that the device is working. If the device does not sound, it indicates that the device is in a shutdown state. Please press and hold the button for five seconds to turn on the device.

### **4. How to prevent devices from being used for malicious tracking?**

When someone else's device mixes with your personal belongings and tracks them for a period of time, you will be reminded in the following two ways:

1. If you have an iPhone, iPad, or iPod touch or other Apple device, you will receive a reminder on the Apple device; This feature is available on Apple devices on iPad 14.5 and later versions.


2. If you don't have an Apple device, if someone else's KVHB\_Pro1 leaves their owner and tracks you for a period of time, it will emit music to remind you when it moves. Of course, if your friends happen to be carrying the device, or if many people on the subway you are taking have this device, there is no need to worry. Because as long as the device does not leave the owner's side, such a reminder will not be triggered.

### **4. How to protect my privacy?**

Where is your device, only you can see it yourself. Your location data and history will never be stored on Apple's servers. The device that transmits your device's location data always remains anonymous, and the location data is encrypted and protected at every step of the search. Therefore, Apple is unaware of the location of your device and the identity of the device that helped locate it.

### **5. How to replace the battery of the device?**

- 1) Pry open the casing from the hand buckle position on the side of the device.
- 2) Remove the old battery and insert the new button battery with the positive pole facing upwards (standard battery, can be purchased at the supermarket).
- 3) Once the device casing is installed, it can be connected and used.



## 6. What is the “search” network? How does it work?

The Apple FindMy network provides a simple and secure way to find compatible personal items on maps using the Find My application on iPhone, iPad, iPod touch, Mac, or Find Items application on Apple Watch. Simply pair your compatible product with Apple Find My app to view it together with your Apple device. If your item is lost, you can put it in lost mode to display messages and contact information to anyone who may have found it. The FindMy network is encrypted and anonymous, so no one else, even Apple, can view its location.

### Important reminder

When pairing a device with a search app, it is necessary to connect to the Apple server. If pairing is not possible, it is usually because the network you are using is temporarily unable to connect to the Apple server. It is recommended to do the following:

1. Change mobile network, such as switching between WIFI and mobile network; Or restart your iPhone ?. Restore device to factory settings: After the device is turned on, double-click the device button and the device will sound. Immediately press and hold the device button for five seconds until the device emits a prompt sound. Continue to press and hold the button for three seconds until the device plays the prompt sound. Release the button and the factory settings are restored.
2. Re pair with the search app.

### Firmware update

In the “Find” app page, find the corresponding device and slide up the device information page. If there is a new firmware release approaching the bottom, you can see “Available Updates”. After clicking, a pop-up window will prompt you. Then click on “Update” in the pop-up window and wait for about ? minutes. After the update is completed, the firmware version will automatically refresh.

### Reference website

How to set up “search” on iPhone, iPad, iPod touch, or Mac can refer to the website:

<https://support.apple.com/zh-en/HT210400>

Use AirTag and “Find” to search for keys, backpacks, and other items. You can refer to the website:

<https://support.apple.com/zh-cn/109021>

Use “Find” to find your lost Apple device or AirTag, refer to the website:

<https://support.apple.com/zh-cn/104978>

### Notes

**Attention:** When using the Apple FindMy application to search for this device, please use the latest version of iOS, iPadOS, watchOS, or macOS. Apple, Apple Watch, watchOS, iPad, iPadOS, iPod touch, Mac, and macOS are trademarks registered by Apple Inc. in the United States and other countries. iOS is a trademark or registered

trademark of Cisco in the United States and other countries, and is authorized for use

Specifications

- Works with: Apple Find My
- Model: KVHB\_Mini
- Compatibility: iPhone, iPad, iPod touch; iPad iOS
- Connection: Wi-Fi
- Reference Websites:
  - [How to set up search on iPhone, iPad, iPod touch, or Mac](#)
  - [Use AirTag and Find to search for keys, backpacks, and other items](#)
  - [Use Find to find your lost Apple device or AirTag](#)

FAQ

Q: What devices are compatible with KVHB\_Mini?

A: KVHB\_Mini is compatible with iPhone, iPad, iPod touch, and iPad iOS devices.


Q: How do I update the firmware of KVHB\_Mini?

A: To update the firmware, navigate to the Find app page and check for Available Updates. Follow the on-screen instructions to complete the update process.

Q: Is there a specific startup procedure for KVHB\_Mini?

A: Yes, press and hold the device button for 5 seconds to power on KVHB\_Mini. It will emit two beeps to indicate successful startup.

Documents / Resources

	<a href="#">ZEBRA KVHB_Mini Bluetooth Tracker Keys Finder</a> [pdf] User Manual KVHB-MINI, KVHB_Mini 2BHNI-KVHB-MINI, 2BHNIKVHBMINI, KVHB_Mini Bluetooth Tracker Keys Finder, KVHB_Mini, Bluetooth Tracker Keys Finder, Tracker Keys Finder, Keys Finder
---	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.