



ZEBRA RFD40 Premium Plus Mobile RFID Reader User Guide

[Home](#) » [ZEBRA](#) » ZEBRA RFD40 Premium Plus Mobile RFID Reader User Guide 

Contents

- [1 ZEBRA RFD40 Premium Plus Mobile RFID Reader](#)
- [2 RFD40 Technical Accessory Guide](#)
 - [2.1 Cradles and Charging](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)



ZEBRA RFD40 Premium Plus Mobile RFID Reader



Technical Accessory Guides (TAGs)

For Associates, Resellers, ISVs and Alliance Partners Global



Version: Active-Only

Will only show products that are known to be available for sale

Need to provide an update or change?

Contact <mailto:pgw786@zebra.com>

Proprietary and Confidential. ZEBRA and the stylized Zebra head are trademarks of Zebra Technologies Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners. ©Zebra Technologies Corp. and/or its affiliates. All rights reserved.

RFD40 Technical Accessory Guide



NOTE: This document is only for general reference. Solutions Pathway and related PMBs should be used for product availability, pricing, and final solution selection.




* Zebra does not endorse or specifically recommend any third-party products, accessories, or hardware . ZEBRA DISCLAIMS ANY AND ALL LIABILITY, INCLUDING ANY EXPRESS OR IMPLIED WARRANTIES, WHETHER ORAL OR WRITTEN, FOR SUCH THIRD PARTY PRODUCTS, ACCESSORIES, OR HARDWARE. THE CUSTOMER ACKNOWLEDGES THAT NO REPRESENTATION HAS BEEN MADE BY ZEBRA AS TO THE FITNESS OF THE THIRD-PARTY PRODUCTS, ACCESSORIES, OR HARDWARE FOR THE CUSTOMER'S INTENDED PURPOSE.

Cradles and Charging


Single Device




Cradles and Charging
Single Device



Part Number	Picture	Description	Notes	Required Items
				For charging one cradle: <ul style="list-style-type: none"> ▶ Power Supply (PWR-
CRD1S0T-RFD49-UNIV-CHG-1R		Single Slot Charging ShareCradle – Universal/3rd Party 	<ul style="list-style-type: none"> ▶ Cradle will charge RFD 40. ▶ Does not charge spare batteries. ▶ Includes USB-A port on rear of cradle cup which is reserved for future enhancements. ▶ NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	BGA12V50W0WW <ul style="list-style-type: none"> ▶ DC Line Cord (CBL-DC-388A1- 01) ▶ AC Line Cord (2 3844-00-00R), or country specific version For charging up to 4 cradles from one power supply: <ul style="list-style-type: none"> ▶ Power Supply (PWR- BGA12V108 W0WW) ▶ 4-Way DC Line Cord (CBL-DC- 380 A1-01) ▶ AC Line Cord (2 3844-00-00R)
				For charging one cradle: <ul style="list-style-type: none"> ▶ Power Supply (PWR-
				BGA12V50W0WW <ul style="list-style-type: none"> ▶ DC Line Cord (CBL-DC-388A1-
			▶ Cradle will charge both RFD40 and EC50/EC55 and supports: <ul style="list-style-type: none"> – RFD40 charging by itself 	01)
		Single Slot Charging	– EC50/EC55 charging by itself	country specific version
CRD1S0T-RFD40-EC5X-CHG-1R		ShareCradle – RFD40 and	– Both RFD40 and EC50/EC55 when attached together	

		EC50/EC55	ther		<p>For charging up to 4 cradles</p> <p>from one power supply:</p> <ul style="list-style-type: none"> ► Power Supply (PWR-
			<ul style="list-style-type: none"> ► Does not charge spare batteries. 		
			<ul style="list-style-type: none"> ► NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 		BGA12V108W0WW)
					<ul style="list-style-type: none"> ► 4-Way DC Line Cord (CBL-DC-380A1-01) ► AC Line Cord (23844-00-00R
	 				<p>For charging one cradle:</p> <ul style="list-style-type: none"> ► Power Supply (PWR-
					BGA12V50W0WW
				<ul style="list-style-type: none"> ► Cradle will charge both RFD40 and TC21/TC26 and supports: 	<ul style="list-style-type: none"> ► DC Line Cord (CBL-DC-388A1-
			– RFD40 charging by itself		01)
			– TC21/TC26 charging by itself		<ul style="list-style-type: none"> ► AC Line Cord (23844-00-00R), or
		Single Slot Charging			country specific version
CRD1S0T-RFD40-TC2X-CHG-1R		ShareCradle – RFD40 and		– Both RFD40 and TC21/TC26 when attached together	
		TC21/TC26		<ul style="list-style-type: none"> ► Does not charge spare batteries. 	<p>For charging up to 4 cradles</p> <p>from one power supply:</p> <ul style="list-style-type: none"> ► Power Supply (PWR-
			<ul style="list-style-type: none"> ► NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 		BGA12V108W0WW)
					<ul style="list-style-type: none"> ► 4-Way DC Line Cord (CBL-DC-

			380A1-01) <ul style="list-style-type: none"> ▶ AC Line Cord (2 3844-00-00R
--	--	--	--




				For charging one cradle: <ul style="list-style-type: none"> ▶ Power Supply (PWR-
CRD1S0T-RFD49-UNIV-COM-1R		Single Slot Charge - Communication ShareCradle – Universal/3rd Party	<ul style="list-style-type: none"> ▶ Cradle will charge RFD 40. ▶ Also provides USB communication to RFD40. ▶ Does not charge spare batteries. ▶ Includes USB-A port on rear of cradle cup which is reserved for future enhancements. ▶ NOTE: Charging cup uses enhanced 	BGA12V50W0WW <ul style="list-style-type: none"> ▶ DC Line Cord (CBL-DC-388A1- 01) ▶ AC Line Cord (2 3844-00-00R), or country specific version For charging up to 4 cradles from one power supply: <ul style="list-style-type: none"> ▶ Power Supply (PWR-
			Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.	BGA12V108W0WW) <ul style="list-style-type: none"> ▶ 4-Way DC Line Cord (CBL-DC- 380 A1-01) ▶ AC Line Cord (2 3844-00-00R
				▶ USB Cable (25-124330-01R) for
				PC connection
				For charging one cradle: <ul style="list-style-type: none"> ▶ Power Supply (PWR-
			▶ Cradle will charge both	BGA12V50W0WW <ul style="list-style-type: none"> ▶ DC Line Cord (CBL-DC-388A1-



	 		RFD40 and EC50/EC55 and supports:	01)
			– RFD40 charging by itself	► AC Line Cord (23844-00-00R), or
CRD1S0T-RFD40-EC5X-COM-1R		Single Slot Charge - Communication ShareCradle – RFD40 and EC50/EC55	– EC50/EC55 charging by itself	country specific version
			– Both RFD40 and EC50/EC55 when attached together	For charging up to 4 cradles from one power supply:
			► Also provides USB communication to RFD40, not EC50/EC55.	► Power Supply (PWR-
			► Does not charge spare batteries.	BGA12V108W0WW)
			► NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.	► 4-Way DC Line Cord (CBL-DC-
				380A1-01)
				► AC Line Cord (23844-00-00R
				► USB Cable (25-124330-01R) for
				PC connection
				For charging one cradle:
				► Power Supply (PWR-
				BGA12V50W0WW
				► DC Line Cord (CBL-DC-388A1-
				01)
			► Cradle will charge both RFD40 and TC21/TC26 and supports:	► AC Line Cord (23844-00-00R), or
			– RFD40 charging by itself	country specific version
			– TC21/TC26 charging by itself	
			– Both RFD40 and TC21/TC26 when attached together	



CRD1S0T-RFD40-TC2X-COM-1R		Single Slot Charge - Communication ShareCradle – RFD40 and TC21/TC26	<ul style="list-style-type: none"> ▶ Also provides USB communication to RFD40, not TC21/TC26. ▶ Does not charge spare batteries. ▶ NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	<p>For charging up to 4 cradles from one power supply:</p> <ul style="list-style-type: none"> ▶ Power Supply (PWR-
				BGA12V108W0WW)
				<ul style="list-style-type: none"> ▶ 4-Way DC Line Cord (CBL-DC-
				380A1-01)
				<ul style="list-style-type: none"> ▶ AC Line Cord (23844-00-00R
				<ul style="list-style-type: none"> ▶ USB Cable (25-124330-01R) for PC connection
				<ul style="list-style-type: none"> ▶ Cradle Cup
CRD1S0T-RFD49-BASE-CHG-1R		Single Slot Charging ShareCradle Base	<ul style="list-style-type: none"> ▶ Includes Charge-Only Base for attaching Cradle cup. ▶ Does not charge spare batteries. ▶ NOTE: Base accepts Charging cups using enhanced Zebra common ShareCradle design which allows the 	<p>For charging one cradle:</p> <ul style="list-style-type: none"> ▶ Power Supply (PWR-BGA12V50W0WW ▶ DC Line Cord (CBL-DC-388A1-01) ▶ AC Line Cord (23844-00-00R), or country specific version
			cup to be easily removed and swapped	For charging up to 4 cradles


			with different cups using a simple coin turned screw.	from one power supply: <ul style="list-style-type: none"> ► Power Supply (PWR- BGA12V108 W0WW) ► 4-Way DC Line Cord (CBL-DC-
				380A1-01) <ul style="list-style-type: none"> ► AC Line Cord (2 3844-00-00R



				► Cradle Cup
				For charging one cradle: <ul style="list-style-type: none"> ► Power Supply (PWR-
			► Includes Charge + Communication	BGA12V50W0WW <ul style="list-style-type: none"> ► DC Line Cord (CBL-DC-388A1-
		Single Slot Charge +	Base for attaching Cradle cup. <ul style="list-style-type: none"> ► Does not charge spare batteries. ► NOTE: Base accepts Charging cups 	01) <ul style="list-style-type: none"> ► AC Line Cord (2 3844-00-00R), or country specific version
CRD1S0T-RFD49-BASE-COM-1R		Communication ShareCradle Base	using enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped	For charging up to 4 cradles from one power supply: <ul style="list-style-type: none"> ► Power Supply (PWR-
			with different cups using a simple coin turned screw.	BGA12V108W0WW) <ul style="list-style-type: none"> ► 4-Way DC Line Cord (CBL-DC-
				380A1-01) <ul style="list-style-type: none"> ► AC Line Cord (2 3844-00-00R


				► USB Cable (25-124330-01R) for
				PC connection
Multi-Device				
Part Number	Picture	Description	Notes	Required Items
			<ul style="list-style-type: none"> ► Cradle will charge up to three RFD40. ► Also charges up to four spare RFD40 	<ul style="list-style-type: none"> ► Power Supply (PWR-BGA12V108W0WW) ► DC Line Cord (CBL-DC- 382A1-01) ► AC Line Cord (23844-00- 00R)
			batteries. <ul style="list-style-type: none"> ► Includes USB-A port on rear of cradle 	
		Multi-Slot Charging	cups which are reserved for future	
CRD3S4T-RFD49-UNIV-CHG-1R		ShareCradle – Universal/3rd Party 	enhancements. <ul style="list-style-type: none"> ► NOTE: Charging cup uses enhanced 	
			Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw.	
			<ul style="list-style-type: none"> ► Cradle will charge up to three RFD40 and EC50/EC55 pairings and supports: <ul style="list-style-type: none"> – RFD40 charging by itself 	<ul style="list-style-type: none"> ► Power Supply (PWR-)
			<ul style="list-style-type: none"> – EC50/EC55 charging by itself – Both RFD40 and EC50/EC55 when attached together 	

CRD3S4T-RFD40-EC5X-CHG-1R		Multi-Slot Charging ShareCradle – RFD40 and EC50/EC55	<ul style="list-style-type: none"> ▶ Also charges up to four spare RFD40 batteries. ▶ NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	BGA12V108W0WW) <ul style="list-style-type: none"> ▶ DC Line Cord (CBL-DC- 382A1-01) ▶ AC Line Cord (23844-00-
				00R)
			<ul style="list-style-type: none"> ▶ Cradle will charge up to three RFD40 and TC21/TC26 pairings and supports: <ul style="list-style-type: none"> – RFD40 charging by itself – TC21/TC26 charging by itself – Both RFD40 and TC21/TC26 when attached together ▶ Also charges up to four spare RFD40 batteries. ▶ NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	<ul style="list-style-type: none"> ▶ Power Supply (PWR-)
CRD3S4T-RFD40-TC2X-CHG-1R		Multi-Slot Charging ShareCradle – RFD40 and TC21/TC26		BGA12V108W0WW) <ul style="list-style-type: none"> ▶ DC Line Cord (CBL-DC- 382A1-01) ▶ AC Line Cord (23844-00-
				00R)


<p>CRD3S4T-RFD49-UNIV-COM-1R</p>		<p>Multi-Slot Charge + Ethernet ShareCradle – Universal/3rd Party</p> 	<ul style="list-style-type: none"> ► Cradle will charge up to three RFD40. ► Also provides Ethernet communications to each RFD40 to enable management, firmware updating and device health. ► Also charges up to four spare RFD40 batteries. ► Includes USB-A port on rear of cradle cups which are reserved for future enhancements. ► NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	<ul style="list-style-type: none"> ► Power Supply (PWR-BGA12V108W0WW) ► DC Line Cord (CBL-DC- 382A1-01) ► AC Line Cord (23844-00- 00R)
----------------------------------	---	---	---	---



<p>CRD3S4T-RFD40-EC5X-COM-1R</p>		<p>Multi-Slot Charge + Ethernet ShareCradle – RFD40 and EC50/EC55</p>	<ul style="list-style-type: none"> ▶ Cradle will charge up to three RFD40 and EC50/EC55 pairings and supports: <ul style="list-style-type: none"> – RFD40 charging by itself – EC50/EC55 charging by itself – Both RFD40 and EC50/EC55 when attached together ▶ Also provides Ethernet communications to each RFD40 and EC50/EC55 to enable management, firmware updating and device health. ▶ Also charges up to four spare RFD40 batteries. ▶ NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	<ul style="list-style-type: none"> ▶ Power Supply (PWR-BGA12V108W0WW) ▶ DC Line Cord (CBL-DC- 382A1-01) ▶ AC Line Cord (23844-00- 00R)
----------------------------------	---	---	--	---

<p>CRD3S4T-RFD40-TC2X-COM-1R</p>		<p>Multi-Slot Charge + Ethernet ShareCradle – RFD40 and TC21/TC26</p>	<ul style="list-style-type: none"> ▶ Cradle will charge up to three RFD40 and TC21/TC26 pairings and supports: <ul style="list-style-type: none"> – RFD40 charging by itself – TC21/TC26 charging by itself – Both RFD40 and TC21/TC26 when attached together ▶ Also provides Ethernet communications to each RFD40 and TC21/TC26 to enable management, firmware updating and device health. ▶ Also charges up to four spare RFD40 batteries. ▶ NOTE: Charging cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	<ul style="list-style-type: none"> ▶ Power Supply (PWR-BGA12V108W0WW) ▶ DC Line Cord (CBL-DC- 382A1-01) ▶ AC Line Cord (23844-00- 00R)
<p>CRD3S4T-RFD49-BASE-CHG-1R</p>		<p>Multi-Slot Charging ShareCradle Base</p>	<ul style="list-style-type: none"> ▶ Includes Charge-Only Base for attaching up to three Cradle cups. ▶ Includes pre-installed 4-Slot Battery Charger for charging up to four spare RFD40 batteries. ▶ NOTE: Base accepts Charging cups using enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	<ul style="list-style-type: none"> ▶ Three Cradle Cups ▶ Power Supply (PWR- BGA12V108W0WW) ▶ DC Line Cord (CBL-DC-382A1- 01) ▶ AC Line Cord (23844-00-00R)



CRD3S4T-RFD49-BASE-COM-1R		Multi-Slot Charge + Ethernet ShareCradle Base	<ul style="list-style-type: none"> ► Includes Charge + Communication Base for attaching up to three Cradle cups. ► Also provides Ethernet communications to each RFD40 and mobile computer to enable management, firmware updating and device health. ► Includes pre-installed 4-Slot Battery Charger for charging up to four spare RFD40 batteries. ► NOTE: Base accepts Charging cups using enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	<ul style="list-style-type: none"> ► Three Cradle Cups ► Power Supply (PWR- BGA12V108 W0WW) ► DC Line Cord (CBL-DC-382A1- 01) ► AC Line Cord (2 3844-00-00R)
---------------------------	---	---	--	---


Cradle Accessories


Part Number	Picture	Description	Notes	Required Items
CUP-RFD49-UNIV-1R		Cradle Cup for RFD40, Universal/3rd Party	<ul style="list-style-type: none"> ► Cup can be installed on Single Slot SharedCradle Base or Multi-Slot ShareCradle Base. ► Provides Charge-Only support or Charge+Communications support for an RFD40 unit , depending on which Cradle Base type installed on . ► Includes USB-A port on rear of cup which is reserved for future enhancements. ► Cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	ShareCradle Base

CUP-RFD40-EC5X-1R		Cradle Cup for RFD40 and EC50/EC55	<ul style="list-style-type: none"> ▶ Cup can be installed on Single Slot SharedCradle Base or Multi-Slot ShareCradle Base. ▶ Provides Charge-Only support or Charge+Communications support for an RFD40 and/or EC50/EC55 unit, depending on which Cradle Base type installed on. ▶ Cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	ShareCradle Base
CUP-RFD40-TC2X-1R		Cradle Cup for RFD40 and TC21/TC26	<ul style="list-style-type: none"> ▶ Cup can be installed on Single Slot SharedCradle Base or Multi-Slot ShareCradle Base. ▶ Provides Charge-Only support or Charge+Communications support for an RFD40 and/or TC21/TC26 unit, depending on which Cradle Base type installed on. ▶ Cup uses enhanced Zebra common ShareCradle design which allows the cup to be easily removed and swapped with different cups using a simple coin turned screw. 	ShareCradle Base



Battery Charging Charge/Communication Cables



BRKT-SCRD-SMR K-01		Multi-Slot ShareCradle Wall/Rack Mount Bracket	<ul style="list-style-type: none"> ▶ Allows for rack and wall mounting of one Multi-Slot ShareCradle or up to four Single-Slot ShareCradles. ▶ Bracket can be mounted on standard 19" network rack or on a wall. ▶ Cable routing slots & removable power supply holder tray. ▶ Adjustable tabs & screw mounts for easy hanging/installation. ▶ Adjustable orientations – horizontal, vertical, angled. ▶ See the Bluetooth-Generic Accessories TAG for info on 3rd party Network Racks that can be used for mounting this bracket. 	
ADP-TC7X-PLT-FX		5-Slot ShareCradle Mounting Bracket Adapter Plate for Honeywell	<ul style="list-style-type: none"> ▶ Allows Zebra Multi-Slot ShareCradles to be mounted on legacy Honeywell Flex Cradle Wall Mount Brackets (HON SKU #203-641-002). ▶ Includes hardware to attach plate to HON wall bracket and secure ShareCradle to plate. ▶ NOTE: This is a custom product. Please work with your Zebra representative to open a Custom Product Request (CPR) if you would like to order this cable. 	
Battery Charging				
Part Number	Picture	Description	Notes	Required Items

SAC-TC8X-4SCHG-01		4-Slot Battery Charger	<ul style="list-style-type: none"> ► Charges up to four spare batteries. ► Can be used standalone or up to four chargers can be installed on Multi-Slot Wall/Rack Mount Bracket (BRKT-SCRD- SMRK-01) 	<p>To power single 4-slot Charger:</p> <ul style="list-style-type: none"> ► Power Supply (PWR-BGA12V50W0WW) ► DC Line Cord (CBL-DC-388A1- 01) ► AC Line Cord (2 3844-00-00R) or country specific version <p>To power two sets of 4-slot Chargers from one power supply:</p> <ul style="list-style-type: none"> ► Power Supply (PWR- BGA12V108 W0WW) ► DC Y-Cable Line Cord (CBL-DC- 5 23A1-01) ► AC Line Cord (2 3844-00-00R) or country specific version
Charge/Communication Cables				
Part Number	Picture	Description	Notes	Required Items

<p>CBL-TC5X-USBC2A-01</p> <p>or</p> <p>CBL-TC2Y-USBC90A-01</p>		<p>USB-C cable</p>	<ul style="list-style-type: none"> ▶ USB-A to USB-C cable ▶ Connects directly to USB-C port on RFD40 to charge device and allows the RFD40 to be used as a tethered RFID reader. ▶ Cable length is 1M (~3.25 ft.) ▶ CBL-TC2Y-USBC90A-01 features USB-A connector with a 90° bend allowing cable to be used in tighter locations. Cable length is about 1.1M (45"). 	
--	---	--------------------	--	--



Device Adapters









<p>CBL-TC2X-USBC-01</p>		<p>USB-C cable</p>	<ul style="list-style-type: none"> ▶ to be discontinued 10/2021, see PMB 10621 ▶ USB-A to USB-C cable ▶ Connects directly to USB-C port on RFD40 to charge device and allows the RFD40 to be used as a tethered RFID reader. ▶ Cable length is 1.5M (~5 ft.) ▶ This cable includes an additional ferrite bead and is typically used with TC25 devices. 	
<p>3rd party *</p>		<p>USB-C cable</p>	<ul style="list-style-type: none"> ▶ Connects directly to USB-C port on RFD40 to charge device and allows the RFD40 to be used as a tethered RFID reader. 	










25-124330-01R		Single Slot Cradle to PC/Host USB cable	<ul style="list-style-type: none"> ► Used with Single Slot ShareCradles ► Micro USB connection on cradle end 	
CBL-RFD49-USB1-01	coming soon	Snap-on USB Communication/Charging Cable	<ul style="list-style-type: none"> ► Attaches to charge/communicator port on bottom of RFD40 and allows the RFD40 to be used as a tethered RFID reader. ► Will charge battery in RFD40 from 0- 90% in as little as X.X hours when used with USB Power Supply (PWR- WUA5V12W0xx) 	<p><u>For standalone charging:</u> Indoor use: order Country Specific version of USB Power Supply (PWR-WUA5V12W0xx)</p> <p>In Vehicle use: USB Cigarette Lighter Adapter (CHG-AUTO-USB1-01)</p>
Device Adapters				
Part Number	Picture	Description	Notes	Required Items
ADP-RFD40-BLNK-1R		Replacement Blank Cover for eConnect™ Adapter Slot	<ul style="list-style-type: none"> ► This is a spare/replacement cover that typically ships with each RFD40 unit. ► Cover snaps into place on RFD40 unit. 	

<p>ADP-RFD40-EC5X-1E</p>		<p>eConnex™ Adapter for EC50/ EC55</p> 	<ul style="list-style-type: none">▶ Allows EC50/EC55 to be mounted on top of RFD40 and communicate directly to the reader.▶ Requires EC50/EC55 configuration with 8-Pin Connector Back I/O connector.▶ Adapter also allows both the RFD40 and EC50/EC55 to be docked as a pair in Single or Multi-Slot ShareCradles.	
--------------------------	---	---	--	--

ADP-RFD40-TC2X-1E		<p>eConnex™ Adapter for TC21/TC26</p> 	<ul style="list-style-type: none"> ► Allows TC21/TC26 to be mounted on top of RFD40 and communicate directly to the reader. ► Requires TC21/TC26 configuration with 8-Pin Connector Back I/O connector. ► Adapter also allows both the RFD40 and TC21/TC26 to be docked as a pair in Single or Multi-Slot ShareCradles. 	
SG-RFD49-ADPSCRWS-01		Replacement Screws for eConnex™ Adapters	<ul style="list-style-type: none"> ► Includes four screws which are included with each eConnex™ Adapter. 	
Power Cords/Power Supplies				
Part Number	Picture	Description	Notes	Required Items

CBL-DC-388A1-01		DC Power Cord	<ul style="list-style-type: none"> ► Used along with Power Supply PWR- BGA12V50 W0WW to power Single Slot ShareCradles or Spare Battery Charger. ► Cable length is 1.8 meters 	
PWR-BGA12V50W0WW		Power Supply	<ul style="list-style-type: none"> ► Used to power Single Slot ShareCradles. ► 100-240 VAC, 12V, 4.16A, 50W ► Provides US DOE Level VI compliance for power efficiency. ► Replaces PWRS-14000-148R and PWRS-14000-148C 	<ul style="list-style-type: none"> ► DC Line Cord (CBL-DC- 388A1-01) ► AC Line Cord (23844-00- 00R) or country specific version

KIT-PWR-12V50W		Power Supply Kit	<ul style="list-style-type: none"> ► Includes Power Supply (PWR-BGA12V50W0WW) and DC Line Cord (CBL-DC-388A1-01) ► Used to power Single Slot ShareCradles. 	► AC Line Cord (23844-00-00R) or country specific version
CBL-DC-381A1-01		DC Power Cord	<ul style="list-style-type: none"> ► Used with Power Supply PWR-BGA12V108W0WW to power Multi-Slot ShareCradles. ► This cable does not include the black extension release latch which is not required when used on Multi-Slot ShareCradles. 	
CBL-DC-382A1-01		DC Power Cord	<ul style="list-style-type: none"> ► Used with Power Supply PWR-BGA12V108W0WW to power Multi-Slot ShareCradles. ► Cable has black extension tab for releasing the cable from the back of the cradle. This isn't required when using Multi-Slot ShareCradles. ► NOTE: CBL-DC-381A1-01 is the recommended cable to be used. 	
CBL-DC-523A1-01		2-Way DC Y Power Cord	► Used to power two 4-Slot Battery Chargers from one Power Supply (PWR-BGA12V108W0WW)	
CBL-DC-380A1-01		4-Way Power Cable	► Used with Power Supply PWR-BGA12V108W0WW for powering up to four Single Slot Cradles.	
PWR-BGA12V108W0WW		Power Supply	<ul style="list-style-type: none"> ► Used to power Multi-Slot ShareCradles. ► 100-240 VAC, 12V, 9A, 108W ► Provides US DOE Level VI compliance for power efficiency. ► Replaces PWRS-14000-241R 	<ul style="list-style-type: none"> ► DC Power Cable (CBL-DC-382A1-01) or 4-Way Power Cable (CBL-DC-380A1-01) ► AC Line Cord (23844-00-00R) or country specific version
23844-00-00R		AC Line Cord	► This AC Line Cord is for use in North America. See the AC Line Cords by Country TAG for comparable line cords to use in other countries.	
PWR-WJA5V6W0WW		USB Power Supply	<ul style="list-style-type: none"> ► Includes four international plugs for use in US, UK, EU, and AU. Additional plugs can be purchased separately for other countries. ► 5.2V, 1.2A, 6W output ► Provides US DOE Level VI compliance for power efficiency 	USB-C Cable or Snap-On Charge/Communication Cable (CBL-RFD49-USB1-01)

CN-000803-01		<u>Spare/Replacement</u> USB Power Supply AC Clip for Australia (AUS)	► This AC Clip is normally included with PWR-WUA5V6W0WW ► 2 pin Australia plug	USB Power Supply (PWR-WUA5V6W0WW)
CN-000803-02		USB Power Supply AC Clip for Argentina (ARG)		USB Power Supply (PWR-WUA5V6W0WW)
CN-000803-03		USB Power Supply AC Clip for Korea (KOR)		USB Power Supply (PWR-WUA5V6W0WW)
CN-000803-04		<u>Spare/Replacement</u> USB Power Supply AC Clip for US (US)	► This AC Clip is normally included with PWR-WUA5V6W0WW ► 2 pin US plug	USB Power Supply (PWR-WUA5V6W0WW)
CN-000803-05		<u>Spare/Replacement</u> USB Power Supply AC Clip for Europe (EU)	► This AC Clip is normally included with PWR-WUA5V6W0WW	USB Power Supply (PWR-WUA5V6W0WW)
CN-000803-06		<u>Spare/Replacement</u> USB Power Supply AC Clip for UK (UK)	► This AC Clip is normally included with PWR-WUA5V6W0WW	USB Power Supply (PWR-WUA5V6W0WW)
CN-000803-07		USB Power Supply AC Clip for China (CHN)	► straight pins China plug	USB Power Supply (PWR-WUA5V6W0WW)
CN-000803-08		USB Power Supply AC Clip for Brazil (BRA)	► 2 pin Brazil plug	USB Power Supply (PWR-WUA5V6W0WW)
CN-000803-09		USB Power Supply AC Clip for India (IND)		USB Power Supply (PWR-WUA5V6W0WW)
Batteries				
Part Number	Picture	Description	Notes	Required Items
BTRY-RFD49-70MA1-01 BTRY-RFD49-70MA1-IN (for India)		RFD40 Spare/Replacement Battery (7000 mAh) with PowerPrecision Plus 	► This is the standard battery that is included with each RFD40 unit. ► Provides 8 hours of continuous usage. ► Battery is same form factor as TC8X series devices, but is labeled differently for regulatory compliance. TC8X series batteries should not be used in the RFD40.	
SG-RFD40-LOCKFT-01		Battery Locking Foot	► Foot screws onto bottom of device to prevent battery from being removed. 	


DCS Product Line – RFD40 TAG

Zebra Confidential. For recipient's internal use only

Document Update date: 7/12/21

NOTE: Items highlighted in grey may not be orderable/available

Documents / Resources

	<p>ZEBRA RFD40 Premium Plus Mobile RFID Reader [pdf] User Guide</p> <p>RFD40 Premium Plus Mobile RFID Reader, RFD40, Premium Plus Mobile RFID Reader, Plus Mobile RFID Reader, RFID Reader, Reader</p>
---	--

