



Zennio Z70 v2 Icon List ZVIZ70V2 User Guide

[Home](#) » [Zennio](#) » Zennio Z70 v2 Icon List ZVIZ70V2 User Guide 

Contents

- 1 [Zennio Z70 v2 Icon List ZVIZ70V2](#)
- 2 [LIGHT THEME ICONS](#)
- 3 [DARK THEME ICONS](#)
- 4 [BUTTONS](#)
- 5 [MENU](#)
- 6 [Documents / Resources](#)
 - 6.1 [References](#)
- 7 [Related Posts](#)



Zennio Z70 v2 Icon List ZVIZ70V2



Application program version: [3.5]

Document Edition: [3.5]_a

<http://www.zennio.com>

LIGHT THEME ICONS

Nº	Name	Icon
1	No Icon	
4	Air Cond Off	
7	On	
10	Profiles	
13	Mode Auto	
16	Mode Fan	
19	Heat/Cool Off	
22	Special Mode Comfort	

Nº	Name	Icon
2	Clock	
5	Air Cond On	
8	Lock	
11	Brightness Off	
14	Mode Heat	
17	Mode Dry	
20	Heat/Cool On	
23	Special Mode Standby	

Nº	Name	Icon
3	Reset	
6	Off	
9	Unlock	
12	Brightness On	
15	Mode Cool	
18	Heat/Cool	
21	Special Mode Auto	
24	Special Mode Economy	

25	Special Mode Protection	
28	Do Not Disturb	
31	Eco	
34	Clapperboard Stop	
37	Night	
40	Tool	
43	New Text	New
46	Warning Heat	

26	Special Mode Protection Heat	
29	Make Up Room	
32	Clapperboard Play	
35	Enter	
38	Exit	
41	Off Text	Off
44	Auto Text	Auto
47	Warning Cold	

27	Special Mode Protection Cool	
30	Room Normal	
33	Clapperboard Pause	
36	Star	
39	Frame	
42	On Text	On
45	Warning	
48	Warning Fan	

49	Alarm	
52	Alarm Flooding	
55	Alarm Power	
58	Door Open	
61	Door Closed 2	
64	Window Open	
67	Shutter Up	
70	Light Off 1	
73	Light On 2	

50	Not Alarm	
53	Alarm Smoke	
56	Alarm Door	
59	Door Closed	
62	Door Open 3	
65	Window Closed	
68	Shutter Middle	
71	Light On 1	
74	Light Off 3	

51	Alarm Presence	
54	Alarm Gas	
57	Alarm Windoor	
60	Door Open 2	
63	Door Closed 3	
66	Prohibited	
69	Shutter Down	
72	Light Off 2	
75	Light On 3	

76	Light Off 4	
79	Light On 5	
82	Light Off 7	
85	Light On 8	
88	Volume Off	
91	Music On	
94	Pause	
97	Fan Off	
100	2	2
103	5	5
106	8	8

109	11	11
112	Curtain Half Open	
115	Slat Stop	
118	Blind Down	
121	Radiator Off	
124	Towel Rack On	
127	Heart	
130	Bluetooth	
133	Cleaning 1	
136	Ceiling Fan Speed 1/1	
139	Ceiling Fan Speed 2/2	

77	Light On 4	
80	Light Off 6	
83	Light On 7	
86	Led Off	
89	Volume On	
92	Play	
95	Next	
98	Fan On	
101	3	3
104	6	6
107	9	9

110	12	12
113	Curtain Closed	
116	Blind Up	
119	Underfloor Heating Off	
122	Radiator On	
125	Socket Off	
128	Moon	
131	Aux	
134	Cleaning 2	
137	Ceiling Fan Speed 0/2	
140	Ceiling Fan Speed 0/3	

78	Light Off 5	
81	Light On 6	
84	Light Off 8	
87	Led On	
90	Music Off	
93	Stop	
96	Previous	
99	1	1
102	4	4
105	7	7
108	10	10

111	Curtain Open	
114	Slat Move	
117	Blind Middle	
120	Underfloor Heating On	
123	Towel Rack Off	
126	Socket On	
129	Pairing	
132	TV	
135	Ceiling Fan Speed 0/1	
138	Ceiling Fan Speed 1/2	
141	Ceiling Fan Speed 1/3	

142	Ceiling Fan Speed 2/3	
145	Internal Call	
148	Chronothermostat (Calendar) Off	
151	Chronothermostat (Clock) On	

143	Ceiling Fan Speed 3/3	
146	VoIP DND Enabled	
149	Chronothermostat (Calendar) On	
152	Irrigation On	

144	Intercom	
147	VoIP DND Disabled	
150	Chronothermostat (Clock) Off	
153	Irrigation Off	

DARK THEME ICONS

Nº	Name	Icon
1	No Icon	
4	Air Cond Off	
7	On	
10	Profiles	
13	Mode Auto	
16	Mode Fan	
19	Heat/Cool Off	
22	Special Mode Comfort	
25	Special Mode Protection	
28	Do Not Disturb	

Nº	Name	Icon
2	Clock	
5	Air Cond On	
8	Lock	
11	Brightness Off	
14	Mode Heat	
17	Mode Dry	
20	Heat/Cool On	
23	Special Mode Standby	
26	Special Mode Protection Heat	
29	Make Up Room	

Nº	Name	Icon
3	Reset	
6	Off	
9	Unlock	
12	Brightness On	
15	Mode Cool	
18	Heat/Cool	
21	Special Mode Auto	
24	Special Mode Economy	
27	Special Mode Protection Cool	
30	Room Normal	

31	Eco	
34	Clapperboard Stop	
37	Night	
40	Tool	
43	New Text	New
46	Warning Heat	
49	Alarm	
52	Alarm Flooding	

55	Alarm Power	
58	Door Open	
61	Door Closed 2	
64	Window Open	
67	Shutter Up	
70	Light Off 1	
73	Light On 2	
76	Light Off 4	
79	Light On 5	
82	Light Off 7	
85	Light On 8	

32	Clapperboard Play	
35	Enter	
38	Exit	
41	Off Text	Off
44	Auto Text	Auto
47	Warning Cold	
50	Not Alarm	
53	Alarm Smoke	

56	Alarm Door	
59	Door Closed	
62	Door Open 3	
65	Window Closed	
68	Shutter Middle	
71	Light On 1	
74	Light Off 3	
77	Light On 4	
80	Light Off 6	
83	Light On 7	
86	Led Off	

33	Clapperboard Pause	
36	Star	
39	Frame	
42	On Text	On
45	Warning	
48	Warning Fan	
51	Alarm Presence	
54	Alarm Gas	

57	Alarm Window	
60	Door Open 2	
63	Door Closed 3	
66	Prohibited	
69	Shutter Down	
72	Light Off 2	
75	Light On 3	
78	Light Off 5	
81	Light On 6	
84	Light Off 8	
87	Led On	

88	Volume Off	
91	Music On	
94	Pause	
97	Fan Off	
100	2	2
103	5	5
106	8	8
109	11	11
112	Curtain Half Open	

89	Volume On	
92	Play	
95	Next	
98	Fan On	
101	3	3
104	6	6
107	9	9
110	12	12
113	Curtain Closed	

90	Music Off	
93	Stop	
96	Previous	
99	1	1
102	4	4
105	7	7
108	10	10
111	Curtain Open	
114	Slat Move	

115	Slat Stop	
118	Blind Down	
121	Radiator Off	
124	Towel Rack On	
127	Heart	
130	Bluetooth	
133	Cleaning 1	
136	Ceiling Fan Speed 1/1	
139	Ceiling Fan Speed 2/2	
142	Ceiling Fan Speed 2/3	
145	Internal Call	
148	Chronothermostat (Calendar) Off	
151	Chronothermostat (Clock) On	

116	Blind Up	
119	Underfloor Heating Off	
122	Radiator On	
125	Socket Off	
128	Moon	
131	Aux	
134	Cleaning 2	
137	Ceiling Fan Speed 0/2	
140	Ceiling Fan Speed 0/3	
143	Ceiling Fan Speed 3/3	
146	VoIP DND Enabled	
149	Chronothermostat (Calendar) On	
152	Irrigation On	

117	Blind Middle	
120	Underfloor Heating On	
123	Towel Rack Off	
126	Socket On	
129	Pairing	
132	TV	
135	Ceiling Fan Speed 0/1	
138	Ceiling Fan Speed 1/2	
141	Ceiling Fan Speed 1/3	
144	Intercom	
147	VoIP DND Disabled	
150	Chronothermostat (Clock) Off	
153	Irrigation Off	

BUTTONS

Nº	Name	Icon
1	No Icon	
4	On/Off	
7	Heat	
10	Close	
13	On	
16	Down Arrow	∨
19	Off Text	OFF
22	Cancel	✕
25	TV	TV

Nº	Name	Icon
2	Point	○
5	Do Not Disturb	
8	Cool	
11	Up Arrow	∧
14	On Text	ON
17	Minus	—
20	Left Arrow	←
23	Aux	AUX
26	RGB	

Nº	Name	Icon
3	Play	▶
6	Make Up Room	
9	Open	↔
12	Plus	+
15	Right Arrow	➤
18	Off	○
21	OK	✓
24	Bluetooth	
27	Light Dimming	

28	Intercom Preview	
31	Microphone Off	
34	Volume Decrease	—
37	Gear	
40	Stop	□
43	Previous	◀

29	Call Log	
32	Microphone On	
35	Speaker On	
38	Clock	
41	Pause	
44	Play/Pause	▶

30	Internal Call	
33	Volume Increase	+
36	Speaker Off	
39	Calendar	
42	Next	▶
45	Play/Stop	▶◻

MENU

Nº	Name	Icon
1	No Icon	
4	Bathroom	
7	Children Bedroom	
10	First Floor	
13	Garden	
16	Office	
19	Swimming Pool	
22	Settings	
25	Basement	
28	Dinning Room	
31	Weather Station	

Nº	Name	Icon
2	Kitchen	
5	Bathtub	
8	Single Bedroom	
11	Second Floor	
14	Tv Room	
17	Shelf Books	
20	Sauna	
23	Lighting	
26	Home	
29	Machine Room	

Nº	Name	Icon
3	Living Room	
6	Master Bedroom	
9	Garage	
12	Attic	
15	Laundry	
18	Library	
21	Restaurant	
24	Climate	
27	Cinema	
30	Playroom	

Technical Support: <https://support.zennio.com>

Join and send us your inquiries about Zennio devices:

<https://support.zennio.com>

Zennio Avance y Tecnología S.L. C/ Río Jarama, 132. Nave P-8.11 45007 Toledo (Spain).

Tel. +34 925 232 002. www.zennio.com info@zennio.com

Documents / Resources

	Zennio Z70 v2 Icon List ZVIZ70V2 [pdf] User Guide Z70 v2 Icon List ZVIZ70V2, Z70 v2, Icon List ZVIZ70V2, ZVIZ70V2, Icon List
---	---

References

- [Home En | Zennio](#)
- [Home En | Zennio](#)

- [● Home En | Zennio](#)
- [● Home En | Zennio](#)

Manuals+.