



ZEPHYR Trail 200 R Hand Torch LED Light User Manual

[Home](#) » [ZEPHYR](#) » ZEPHYR Trail 200 R Hand Torch LED Light User Manual 

Contents

- [1 ZEPHYR Trail 200 R Hand Torch LED Light](#)
- [2 Zephyr Trail™ 200 R Product Information](#)
- [3 Product Usage Instructions](#)
- [4 TO REPLACE BATTERY](#)
- [5 Documents / Resources](#)

Zephyr Trail™

ZEPHYR Trail 200 R Hand Torch LED Light




Zephyr Trail™ 200 R Product Information

The Zephyr Trail™ 200 R is a handheld flashlight designed for outdoor use. It features an integrated power button on the hand grip and multiple modes for versatile lighting options. The flashlight requires two AA batteries for operation.

Product Usage Instructions


1. To turn on the flashlight, locate the power button (1) on the hand grip and press and hold it for 2-3 seconds.
2. Once the flashlight is turned on, you can cycle through different modes by pressing the power button repeatedly.
3. To turn off the flashlight, press and hold the power button for 2-3 seconds.
4. If the batteries need to be replaced, locate the battery compartment on the bottom of the flashlight.
5. Remove the old batteries and replace them with two new AA batteries, ensuring that they are inserted correctly with the positive and negative ends aligned.
 - To turn on, press and hold power button (1) that is integrated in to the hand grip for 2-3 seconds.
 - Press repeatedly to cycle through modes.
 - To turn off, press and hold power button for 2-3 seconds.

TO REPLACE BATTERY





Documents / Resources

 <p>NORTHMAN Zephyr Trail™ 200 R</p> <p>USAGE INSTRUCTIONS</p> <ul style="list-style-type: none">→ To operate, press and hold the power button (located on the handle) for 3 seconds.→ Press and hold the power button for 3 seconds to turn the torch on.→ Press and hold the power button for 3 seconds to turn the torch off. <p>TO REPLACE BATTERY:</p> <ul style="list-style-type: none">→ Remove the battery cover (located on the handle).→ Remove the old battery.→ Insert the new battery (AA or AAA).→ Replace the battery cover.	<p>ZEPHYR Trail 200 R Hand Torch LED Light [pdf] User Manual</p> <p>Trail 200 R Hand Torch LED Light, Trail 200 R, Hand Torch LED Light, LED Light, Light</p>
--	---