

## ZERO-G LCD Watch Instruction Manual

[Home](#) » [ZERO-G](#) » ZERO-G LCD Watch Instruction Manual 

### Contents


- [1 ZERO-G LCD Watch](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

# Zero-G


### ZERO-G LCD Watch



Example 1 : 4:35



Example 2 : 10:43



### How to set the time

- Hold Key B for about 5 seconds, the Hour segment will blink (Minute segment is not blinking): press Key A to increase the Hours,
- Press Key B to confirm and move to Minute segments
- Press Key A to increase the Minutes, Press Key B to confirm and exit.

### Battery replacement


- One Lithium battery CR1620 provides the power to operate the lights
- If you notice your watch's light is getting dimmer, this is an indication that your battery needs to be replaced
- Do not wait until your watch stops functioning
- Weak or dead battery left in your product for an extended time may damage the movement
- To avoid the possibility of damaging your product, we recommend that you send it to watch specialist to have the battery replaced and the case back properly sealed

### Cautions

- Don't press buttons under water nor with excessive moisture on the product surface.
- Avoid long-term exposure to extreme temperature, direct sunlight. This can cause material coloring to fade or discoloration.
- Please avoid rough use or dropping this product. Do not use strong detergent, sprays or chemicals as this will dis-color the case or strap.

- To clean your watch use only soft cloth, moistened lightly.

## Documents / Resources



[ZERO-G LCD Watch](#) [pdf] Instruction Manual  
LCD Watch, Watch

[Manuals+.](#)