



Zgrmbo Digital Wall Clock with Date Indoor Temperature Instruction Manual

[Home](#) » [Zgrmbo](#) » Zgrmbo Digital Wall Clock with Date Indoor Temperature Instruction Manual 

Zgrmbo Digital Wall Clock with Date Indoor Temperature Instruction Manual



Contents

- 1 Alarm Clock Setting
- 2 Alarm Switch Button
- 3 Select °C/°F Format
- 4 Select 12/24-hour Format
- 5 Volume Setting
- 6 Set whether the time colon(seconds point) flashes for switching
- 7 Time Setting
- 8 Music mode
- 9 Memory function
- 10 Brightness Setting
- 11 Night Brightness Setting (Auto-Brightness)
- 12 Reset
- 13 Documents / Resources
 - 13.1 References
- 14 Related Posts

Alarm Clock Setting

Step 1: Press and hold the “ALARM SET” button to display the “alarm clock 1” icon and time,

Step 2: Press the +/- button to set the hour of the alarm clock 1” time, and press the “ALARM SET” button to switch to the next step,

Step 3: Press the “+/-” button to set the minute of the alarm clock 1 time, and press the “ALARM SET” button to switch to the next step,


Step 4: Press the “+/-” button to select the alarm for the alarm clock 1, and press the ‘ALARM SET” button to display the “alarm clock 2” icon and time,

Step 5: Press the +/- button to set the hour of the alarm clock 2 time, and press the “ALARM SET” button to switch to the next step,

Step 6: Press the +/- button to set the minute of the “alarm clock 2” time, and press the ‘ALARM SET” button to switch to the next step,

Step 7: Press the “+/-” button to select the alarm for the “alarm clock 1”, and press the ‘ALARM SET” button to exit the alarm clock setting. “TIME SET” button to complete the time setting.

Alarm Switch Button

Press the alarm switch button() to quickly turn on or off the alarm clock. When the alarm clock is turned on, the alarm clock icon on the clock screen will be displayed, otherwise it will not be displayed, When the alarm clock rings, the alarm icon will flash, press any button to turn off the alarm, otherwise the alarm will continue to ring for 2 minutes.

Select °C/°F Format

Directly press the*+* button to quickly switch the “C/”F Format

Select 12/24-hour Format


Directly press the ‘TIME SET” button to quickly switch the 12/24-hour Format

Volume Setting

Directly press the button to quickly adjust the volume, and click any key to end the volume setting.

Set whether the time colon(seconds point) flashes for switching

Press the*+* button and hold for 6 seconds to switch the time colon from flashing or not.



Simple outlook and high definition LED display	Low power consumption
40 high quality music for music appreciation and ringtone	Time temperature date display simultaneously
2 sets individual alarm clock switch	Ringtone volume setting
Memory function	Product size: 265X70X35MM
Product net weight: 275 g	Power input: 5V1A, working current: 120 ma

Time Setting

Step1: Press and hold the “TIME SET” button to activate the time setting,

Step2: Press the “+/-” button to set the year, and press the “TIME SET” button to switch to the next step,


Step3: Press the “+/-” button to set the month of the date, and press the “TIME SET” button to switch to the next step,

Step4: Press the “+/-” button to set the day of the date, and press the “TIME SET” button to switch to the next step,

Step5: Press the “+/-” button to set the hour of the time, and press the “TIME SET” button to switch to the next step,

Step6: Press the “+/-” button to set the minute of the time, and press the “TIME SET” button to complete the time setting.


Music mode

In normal time mode, Press music button  to play music.



Memory function

Build-in CR2025 3V button cell battery. there is no need to reset when the power supply is changed or the power is cut off, but the screen will be turned off.

Brightness Setting

Directly press the ‘LIGHT’ button (icon ) to quickly adjust the brightness. (5 levels of brightness, the last level is to turn off the display.)

Night Brightness Setting (Auto-Brightness)

Under the time display mode, press “LIGHT” button (icon ) for 3 seconds to enter night mode setting, press “Up” or “Down” button to turn night setting on or off, press “LIGHT” button (icon ) again to end the setting and return to time display mode. After the night mode is turned on, the clock displays high brightness between 6:00-18:00, medium brightness between 18:00-23:00, low brightness between 23:00-6:00. And daily automatic cycle brightness switching.

Note:

Even after the night mode is turned on, you can manually adjust the display brightness of the above three time zones to the appropriate brightness you want, and the clock will be automatically remembered as the default setting and automatically cycle the brightness to switch the brightness you set in these three time zones every day.

Reset

If the product is malfunctioned, please try to press the “reset” button to restart the clock

- **Daily maintenance**


please use soft tissue or cloth to clean the clock. Keep the clock clean and dry to function normally.

- **Environment protection**

Electronic product should be disposed according to the related laws and regulations, please take the broken product to the nearest collecting point for disposal.

For better use of the product, please read the product instruction manual carefully Thank you!

Documents / Resources

	<p>Zgrmbo Digital Wall Clock with Date Indoor Temperature [pdf] Instruction Manual Digital Wall Clock with Date Indoor Temperature, Digital, Wall Clock with Date Indoor Temperature, Clock with Date Indoor Temperature, Date Indoor Temperature, Indoor Temperature, Temperature</p>
---	--

References

- [User Manual](#)