



Zintronic How to Configure E-Mail Notifications for Camera Instructions

[Home](#) » [Zintronic](#) » Zintronic How to Configure E-Mail Notifications for Camera Instructions 

Zintronic How to Configure E-Mail Notifications for Camera




Contents

- 1 [G-mail Account Configuration](#)
 - 1.1 [G-mail security settings](#)
 - 1.2 [Getting G-mail generated password for authentication](#)
- 2 [Turning On e-mail Notifications On Camera](#)
 - 2.1 [Notifications via SMTP](#)
 - 2.2 [SMTP protocol configuration](#)
- 3 [Customer Support](#)
- 4 [Documents / Resources](#)
- 5 [Related Posts](#)


G-mail Account Configuration

G-mail security settings

1. Open Chrome browser.
2. Log in to your Gmail account.
3. In the top right corner click the icon of your account and go to 'Manage your Google Account'.



4. Go to 'Security'.



5. Turn on '2-Step Verification'.

Signing in to Google



Password

Last changed Feb 7, 2022



2-Step Verification

☒ On



App passwords

None



Getting G-mail generated password for authentication

1. Click 'App passwords' to generate new password, which you will use during camera configuration. Gmail will ask you once again to log in, before it lets you create the new password.
2. Click 'Choose app' then, other option.

← Passwords for the application

The app password is used to sign in to your Google account from within the app on devices that do not support two-step verification. You do not need to remember it - you only need to enter it once. More information [More info](#)

You do not have passwords for applications.

Select the application and device for which you want to create a new password.

Choose app



Choose device



GENERATE

3. Name new application on your own, for example: Camera/CCTV/Message. And click on 'Generate'.

← Passwords for the application

The app password is used to sign in to your Google account from within the app on devices that do not support two-step verification. You do not need to remember it - you only need to enter it once. More information [More info](#)

You do not have passwords for applications.

Select the application and device for which you want to create a new password.

Camera

×

GENERATE

Note: After doing this password generated by google will show up. Write it down without, spaces and click 'OK'. Password will be shown only once, there is no way to get it to show again!

4. Generated password will show up on your 2-step login, you can delete it, or generate new one in case you forgot the original one.

Generated password for the application

Your application password (device)

vrpl owlq rulx oxqi

Method of use

Open your Google account settings in the app or on the device you are configuring. Replace your password with the above password of 16 characters. The app password, like your regular password, gives you full access to your Google account. You don't need to remember it, so don't save it or share it with anyone. The app's password, like your regular password, gives you full access to your Google account. You don't have to remember it, so don't save it or share it with anyone.

OK


Turning On e-mail Notifications On Camera

Notifications via SMTP

1. In the Web browser panel choose 'Configuration' tab, then 'Events'>'Ordinary Event', then mark options as

shown on the picture below.

2. Click 'Save' to save the config.



SMTP protocol configuration

1. Sender: Your e-mail address.
2. SMTP Server: smtp@gmail.com.
3. Port: 465.
4. Upload via SMTP: JPEG (for pictures only) Message (for message only).
5. Username: Your e-mail address.
6. Password: Google-generated password.
7. Confirm password: Type Google-generated password again.
8. E-mail 1/2/3: More e-mail options to get notifications on multiple accounts.
9. Click 'Save' to save your config.

Local Configuration

Local Configuration

System

Storage

Network

Basic Setup

Advance Setup

Video

Image

Events

DDNS

FTP

SMTP

P2P

Sender

Sender

User@domain.com

SMTP Server

SMTP.domain.com

Port

25

Upload Via SMTP

MESSAGE

☐ My Server Requires Authentication

User Name

User@domain.com

Password

.....

Confirm Password

.....

Receiver

Email1

User@domain.com

Test

Email2

Test

Email3

Test

Save

Customer Support



ul. J. K. Branickiego 31A 15-085 Białystok




+48 (85) 6TT 70 55



biuro@zintronic.pl



Documents / Resources

<div><div>How to configure e-mail notifications for camera</div><div>This manual refers to Zintronic IP & CV product series.</div><div></div><div>Table of Contents:</div><div><div>Section 1-1: Email server configuration</div><div><ul style="list-style-type: none">1-1-1 Email server settings1-1-2 Setting email protocol according to notification</div><div><div>Section 1-2: Setting up e-mail addresses on camera</div><div><ul style="list-style-type: none">1-2-1 Address setup1-2-2 E-mail content configuration</div></div></div></div>	<div><div><h1><u>Zintronic How to Configure E-Mail Notifications for Camera</u> [pdf] Instructions</h1><h2>How to Configure E-Mail Notifications for Camera</h2></div></div>
--	--

