


ZKTECO BioTime Change Log User Guide

Home » **ZKTECO** » **ZKTECO** BioTime Change Log User Guide **1**

Contents 1 ZKTECO BioTime Change Log 2 Key Updates 3 Dashboard 4 Personnel Module 5 Attendance Module 6 System Module 7 MORE INFO 8 Documents / Resources 8.1 References



ZKTECO BioTime Change Log





Key Updates

Implemented Change	Description
Dashboard	Person In/Out Board
Personnel Module	 Custom Attribute-Combo Box Visible Light Face Example Image
Attendance Module	Display Paycode Units
System Module	 Database Operation Authentication Database Backup - Encryption Database Restore - Console Information Backfilling Add Multiple Zoom Accounts

Dashboard

• Click the icon to view personnel entry and exit status in full screen. This feature is primarily utilized in locations where displaying personnel movement on the screen is necessary







• The dashboard switches to full screen mode to display the entry and exit status of personnel.

Personnel Module


- Custom Attribute-Combo Box
- The custom field function now includes a combo box mode, enabling users to customize the name and options of the selection box.
- To access, navigate to Personnel ->Configurations Custom Attribute, click Add, and select Combobox, as shown in the following figure



• Enter the name and click on icon to add new options. The system allows creating of up to five options




• Once this combobox is enabled, you can locate it in the Person -> Employee -> Add/Edit interface



Visible Light Face Example Image


Navigate to Personnel ->Employee ->Add/Edit ->Device Access Settings. Move the cursor over
the icon , and the system displays a sample image. Simultaneously, the interface will display the format
requirements for photos




Attendance Module

Display Paycode Units

• Access Attendance>Setup>Paycode>Add/Edit, select the Paycode unit, and click Confirm to save the settings.




• The field name in the report will display the unit in which it is used



System Module


Database Operation Authentication

• Before proceeding to backup and restore databases, users must use a super administrator account for verification.




Database Backup – Encryption

- The database backup encryption function is enabled by default with the default password being the login password of the initially created super administrator.
- To disable this feature or change the default password, go to System->Configuration->Security Settings->Export Security.




• Super administrators also have the option to customize passwords when backing up databases



Database Restore – Console Information Backfilling


 When the user selects Sync to console, the system will backfill the database name and password to the console




Add Multiple Zoom Accounts

• The system supports users to add multiple Zoom accounts, solving the problem of only having one online

meeting at a time



• Users can choose different accounts to create different Zoom online meetings



MORE INFO

- ZKTeco Middle East, Bay Square, Building 1, Office 502 & 503, Business Bay, Dubai, UAE
- Phone: +971 4 392 7649
- www.zkteco.me



Documents / Resources

ZKTECO BioTime Change Log [pdf] User Guide 8.0, 9.5, BioTime Change Log, BioTime, Change Log, Log

References

- 4 Leading Suppliers of Smart Security Solutions and Systems
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.