

ZKTECO
ZKH300 Smart Android
Handheld Terminal



ZKTECO ZKH300 Smart Android Handheld Terminal User Manual

[Home](#) » [ZKTECO](#) » ZKTECO ZKH300 Smart Android Handheld Terminal User Manual 

Contents

- [1 ZKTECO ZKH300 Smart Android Handheld Terminal](#)
- [2 Packing List](#)
- [3 Instructions for Appearance](#)
- [4 Quick Entry](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

ZKTECO

ZKTECO ZKH300 Smart Android Handheld Terminal




Due to regular upgrades of systems and products, ZKTeco could not guarantee exact consistency between the actual product and the written information in this manual.

Packing List

Check the components after opening the box; if any products are missing or the product description appears to have missing pages or has another serious impact on the reading, please contact the seller.

Item	Model/Spec	Quantity
SmartPOS	ZKH300	1pcs
PrinterPaper	57(width)* <D40(,;;40mm)	1pcs
Charger	5V/2A	1pcs
USB charging cable	MicroUSBSP	1pcs
Battery	7.4V 2800mAh	1pcs

Instructions for Appearance



1. The state of the charging lamp
2. Power button
3. Mini USB interface
4. Micro USB interface
5. NFC reader indicator light
6. Contactless card reaction area
7. LCD
8. Paper exit button
9. Camera(SM)
10. Label

Quick Entry

1. Open the device and connect it to the network.
2. Open the POS trade system.
3. Choose the transaction amount.
4. Swipe your card.
5. Enter password.
6. Print the purchase order.
7. The transaction is completed.

User Manual


1. Switch machine

- Power on: Long-press the power button until the LCD lights up. Then, after releasing the button, the terminal starts.

- **Shutdown:** To shut down the computer, hold down the power button for several seconds, then click off, and then enter the shutdown procedure.


2. **Swipe a contactless card**

As shown above, please put the RFID cards on the RFID/NFC contactless card reader.



3. **Contactless card operation**

Put the contactless card into the terminal area, where you can finish card-swiping. Immediately.



4. **Printer**

The printer prints the purchase order when the transaction is completed.

5. **Terminal battery charging**

You can charge the terminal by using the machine's USB data cable to connect it to the charger. If you plan to

use the terminal for an extended period, it is recommended that you turn it off and charge the battery every three months.

6. The charge status lights

- The two-color charge status indicator light is as follows:
- The left side of the red light is on: Charging.
- The left side of the light is off: Charging is over.

7. Set aside an RS232 interface Mini USB interface

Notes on Using Lithium Batteries

1. Do not damage the USB cable. If the USB cable is damaged, you can not continue to use it.
2. Do not use other charger, you should use our built-in charger to charge the terminal. In case, if the voltage of other chargers is high, then it will damage the equipment.
3. Do not place in the sun directly, high temperature, humidity, or in the dusty place.
4. Please stay away from the liquid.
5. Do not insert any matter into any of the terminal interface, that may seriously damage the terminal.
6. The terminal can't work well, please contact a dedicated POS maintenance personnel, the user shall not be allowed to repair the terminal.
7. It is strictly prohibited in the explosion of dangerous places to dismantle terminal, and use the external interface.
8. Please wipe with a damp cloth while cleaning.

ZKTeco Industrial Park, No. 32, Industrial Road, Tangxia Town, Dongguan, China.

Phone: +86 769 – 82109991


Fax +86 755 – 89602394



www.zkteco.com

Copyright©2011 ZKTECO CO., LTD. All Rights Reserved.

Documents / Resources

	<p>ZKTECO ZKH300 Smart Android Handheld Terminal [pdf] User Manual ZKH300 Smart Android Handheld Terminal, ZKH300, Smart Android Handheld Terminal, Android Handheld Terminal, Handheld Terminal</p>
---	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.