

ari®
IAN 459912_2401
Cat Scratching
Post Climbing Tree




Contents

- [1 zoofari IAN 459912_2401 Cat Scratching Post Climbing Tree](#)
- [2 Package contents](#)
- [3 Assembly](#)
- [4 Storage cleaning](#)
- [5 Disposal](#)
- [6 FAQs](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)


zoofari®

zoofari IAN 459912_2401 Cat Scratching Post Climbing Tree



Congratulations! You have chosen to purchase a high-quality product. Familiarise yourself with the product before using it for the first time. Read the following instructions for use carefully. Use the product only as described and only for the given areas of application. Store these instructions for use carefully. When passing the product on to third parties, please also hand over all accompanying documents.

Package contents



- 1 x scratching post, disassembled (1–4)
- 1 x assembly materials (5–7)
- 1 x instructions for use

Technical data

Total dimensions

- approx. 30 x 42 x 30cm (W x H x D)
- 6 Maximum load: 6kg
- Date of manufacture (month/year): 07/2024

Intended use

The product serves as a scratching post for cats. The product is for private use and is not intended for commercial use.

Safety information

Important: read these assembly instructions carefully and keep them in a safe place!

Life-threatening hazard!

- Never leave children unattended with the packaging materials. There is a risk of suffocation.
- The product is not a toy or a climbing apparatus! Ensure that persons, especially children, do not pull themselves up on the product or stand on it. The product can tip over.

Risk of injury!

- Ensure the product is properly stabilised before it is used!
- Place the product on a level, solid surface. Do not place it near stairs.
- Do not place hazardous items, such as candles, near the product.
- The product may be used only for its intended purpose.
- Do not exceed the maximum load capacity.
- Not a toy for children!
- Keep away from children!
- Only use under supervision.
- Supervise animals while playing.
- Replace the product when it shows signs of wear.
- No modifications may be made to the product! Preventing damage to the product!
- The manufacturer accepts no liability for accidents that occur as a result of ignoring the safety information above or inappropriate handling.
- Check the product for damage or wear before each use. Use the product only if it is in perfect condition!

Assembly

Note: to assemble the product, you require a hex key (7).

1. Remove the packaging and place all the parts of the product on the floor.
2. Assemble all parts of the product as shown in Fig. A.

Storage cleaning

When not in use, always store the product clean and dry at room temperature. Only vacuum the product.

IMPORTANT! Never clean the product with harsh cleaning agents.

Disposal

Dispose of the product and packaging materials in accordance with current local regulations. Store the packaging materials (foil bags, for example) out of the reach of children. For further information about the disposal of the product no longer needed, contact your local council. Dispose of the product and the packaging in an environmentally friendly manner.

- The Recycling Code distinguishes different materials to be returned for recycling. The Code consists of the recycling symbol for the recycling process and a number that identifies the material.

Notes on the guarantee and service handling

The product was produced with great care and under continuous quality control. DELTA-SPORT HANDELSKONTOR GmbH gives private end customers a three-year guarantee on this product from the date of purchase (guarantee period) in accordance with the following provisions. The guarantee is only valid for material and manufacturing defects. The guarantee does not cover parts that are subject to normal wear and tear and that are thus considered wear parts (e.g., batteries), and it does not cover fragile parts such as switches or parts that are made of glass.

Claims under this guarantee are excluded if the product has been used incorrectly, improperly, or contrary to the intended purpose, or if the provisions in the instructions for use were not observed, unless the end customer proves that a material or manufacturing defect exists that was not caused by one of the aforementioned circumstances. Claims under the guarantee can only be made within the guarantee period by presenting the original sales receipt. Please, therefore, keep the original sales receipt. The guarantee period is not extended by any repairs carried out under the guarantee, under statutory guarantees, or as a gesture of goodwill. This also applies to replaced and repaired parts.

If you wish to make a claim, please first contact the service hotline mentioned below or contact us by email. If there is a guarantee case, then the product will be repaired or replaced free of charge to you or the purchase price will be refunded, depending on our choice. There are no further rights from the guarantee. Your legal rights, in particular, guarantee claims against the respective seller are not limited by this guarantee.

- **IAN:** 459912_2401 Service Great Britain
- **Tel.:** 0800 404 7657
- **E-Mail:** deltasport@lidl.co.uk

DELTA-SPORT HANDELSKONTOR GMBH

- Wragekamp 6
- 22397 Hamburg
- GERMANY
- M 07/2024
- Delta-Sport-Nº: KM-13193

FAQs

Q: Can the massage brush be removed for cleaning?

A: The massage brush is not designed to be removed for cleaning. It is recommended to gently vacuum or brush off any debris.

Q: What materials are used in the construction of the scratching post?

A: The scratching post is constructed using durable materials suitable for cat scratching behavior.

Documents / Resources

