

## Contents [ [hide](#) ]

[1 ZOOM F8 Multi Track Field Recorder](#)

[2 Product Usage Instructions:](#)

[3 FAQs](#)

[4 Documents / Resources](#)

[4.1 References](#)



## ZOOM F8 Multi Track Field Recorder



### Specifications:

- Version: 6.4
- Functions: Audio file management, SD card formatting
- Manufacturer: ZOOM CORPORATION
- Address: 4-4-3 Kanda-surugadai, Chiyoda-ku, Tokyo 101-0062 Japan

### Product Information:

The Version 6.4 Supplementary Manual provides detailed information on the functions revised and added in this version. It includes changes in naming audio files during long

recordings, resumption of audio interface mode, and the addition of an SD card formatting menu at startup.

## **Product Usage Instructions:**

### **Naming of Audio Files When Long Recordings Are Split:**

When the maximum file size is exceeded during recording, the file will be split. A sequential number (long recording file number) will be added to the audio file name. Follow these steps:

1. Refer to the operation manual for setting the maximum file size (File Max Size).

## **Version 6.4 Supplementary Manual**

- You must read the Usage and Safety Precautions before use.
- © 2025 ZOOM CORPORATION
- Copying or reprinting this manual in part or in whole without permission is prohibited.
- Product names, registered trademarks and company names in this document are the property of their respective companies. All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners. Proper display is not possible on grayscale devices.

## **Functions revised and added in Version 6.4**

- **Changed naming of audio files when long recordings are split**

When the maximum file size (File Max Size) is exceeded, a new audio file will be created with a sequential number (long recording file number) added to its name rather than with the take number increased by one.

- **Resumption of audio interface mode when restarting enabled**

If the unit was shut down during audio interface mode, this mode will automatically be reactivated when next started up.

- **Function added to show an SD card formatting menu at startup**

An SD card formatting menu can be shown by pressing a specific button during startup.

## Naming of audio files when long recordings are split

- When the maximum file size (File Max Size) is exceeded during recording, the file will be split. Now, however, a sequential number (long recording file number) will be added to the audio file name.
- See the operation manual for information about setting the maximum file size (File Max Size).


Version	Audio file name example (for stereo file)	Explanation
Previous version	Scene001_T002_Tr1_2.wav <div style="text-align: center;">①</div>	① Take number The take number is advanced by one each time the file is split. (For example: T001, T002, T003...)
Version 6.4	Scene001_T001_0002_Tr1_2.wav <div style="text-align: center;">①</div>	① Sequential number (long recording file number) The long recording file number is advanced by one each time the file is split. (For example: 0001, 0002, 0003...)


## Showing a menu to format SD cards at startup



### NOTE

Be aware that all data on the SD card will be deleted when it is formatted.



### SD cards can be formatted by pressing a specific button during startup.


1. Insert an SD card.
2. Turn on the power while pressing the  (REC) button.



3. Use the  (selection encoder) to select the slot with the SD card to format. Then, press the  (selection encoder).



4. Use the  (selection encoder) to select “Yes”. Then, press the  (selection encoder).



SD Card formatting will start.

## HINT

- SD cards can also be formatted from the Menu Screen.

## ZOOM CORPORATION

- 4-4-3 Kanda-surugadai, Chiyoda-ku, Tokyo 101-0062 Japan
- [zoomcorp.com](http://zoomcorp.com)

## FAQS

**Q: Can SD cards be formatted from the Menu Screen?**

A: Yes, SD cards can also be formatted from the Menu Screen in addition to using a specific button during startup.

## Documents / Resources

	<a href="#">ZOOM F8 Multi Track Field Recorder [pdf]</a> Instruction Manual v6.4, F8 Multi Track Field Recorder, F8, Multi Track Field Recorder, Track Field Recorder, Field Recorder, Recorder
--	--

## References

- [User Manual](#)

Zoom

F8, F8 Multi Track Field Recorder, Field Recorder, Multi Track Field Recorder, Recorder, Track Field Recorder, v6.4, zoom

—Previous Post

[ZOOM R4 MultiTrak 4 Track Recorder User Guide](#)

Next Post—

[ZOOM H5studio Handheld Recorder Installation Guide](#)

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.