



# Zoom H6essential Bit Float Portable Audio Recorder Installation Guide

[Home](#) » [Zoom](#) » ZOOM H6essential Bit Float Portable Audio Recorder Installation Guide 




**H6essential Accessibility Installation Guide**  
Copyright(C) 2024 ZOOM CORPORATION. All Rights Reserved.  
Proper display is not possible on grayscale devices.

## Contents

- [1 Introduction](#)
- [2 Installing the Guide Sound Accessibility Feature](#)
- [3 Confirm that the guide sound accessibility feature has been installed correctly](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)

## Introduction


- Item to prepare



H6essential



microSD card



Windows or macOS computer with Internet access

Supported recording media microSDHC: 4 GB – 32 GB microSDXC: 64 GB – 1 TB

Always format microSD cards on the H6essential after purchasing them new or using them with a different device.

## ■Accessibility Installation process

1. Download the accessibility installation file.
2. Extract the ZIP file.
3. Copy the extracted accessibility installation file to a microSD card.
4. Install the guide sound accessibility feature.
5. Confirm that the guide sound accessibility feature has been installed correctly.

## Installing the Guide Sound Accessibility Feature

This guide explains installing guide sound of English version 1.00 as an example.

1. Download the accessibility installation file.



Download the ZIP file that contains the accessibility installation file from the H6essential download page.



On Windows


2. Extract the ZIP file.

Select the folder that contains the downloaded ZIP file. Click ①“Compressed Folder Tools” and then click ② “Extract all”. This extracts the ZIP file.



3. Copy the accessibility installation file to a microSD card.


Copy the “H6eAccessibility\_ENG.BIN” file to a microSD card.



## On macOS


2. Extract the ZIP file.

After downloading, open the ①“Downloads” folder which appears at the right end of the Dock by default. Then, click ②. Downloaded files will be shown.



3. Copy the accessibility installation file to a microSD card.

Copy the “H6eAccessibility\_ENG” file to a microSD card.




**The following procedures are the same on both Windows and macOS.**



4. Install new batteries in the H6essential or connect an AC adapter.


### NOTE

The accessibility installing is not possible if the remaining battery power is low.

5. Insert the microSD card into the H6essential.







6. Slide  toward  until the display becomes active.




This turns the H6essential power on and opens the Home Screen on the display.




7. On the Home Screen, use  to select  (System) and press .




This opens the System Setting Screen.





8. Use  to select "Accessibility" and press  .




9. Use  to select "Version" and press  .



10. Use  to select "Install" and press  .



11. Use  to select "Execute" and press  .



The installation will be executed.

**NOTE**




During the accessibility installation, do not turn the power off or remove the microSD card.


If the installation fails, "Please Update Accessibility!" will appear.

If this happens, turn the power off once and confirm that the microSD card is loaded correctly. Then, turn the power on and try installing again.


**Confirm that the guide sound accessibility feature has been installed correctly**

Check the guide sound information used by the H6essential.


1. On the Home Screen, use  to select  (System) and press  .




This opens the System Setting Screen.




2. Use  to select "Accessibility" and press  .



3. Use  to select "Version" and press  .






4. Check the language and version used for the accessibility guide sound.



● ZOOM CORPORATION will bear no responsibility for any losses or third-party claims resulting from the use of this software. Moreover, distribution, sale, leasing, rental, alteration, and reverse engineering without permission of this software are prohibited. The specifications of this software and the contents of this document could be changed without notice in the future.

- Copying or reprinting this manual in part or in whole without permission is prohibited.
- Microsoft and Windows are trademarks of the Microsoft corporate group.
- macOS is a trademark of Apple Inc.
- microSDXC logos are trademarks of SD-3C LLC.
- Other product names, registered trademarks and company names in this document are the property of their respective companies.
- All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.
- The illustrations in these instructions might differ from actual screens.

|   |  |
|---|--|
|  | <p><b><a href="#">ZOOM H6essential Bit Float Portable Audio Recorder</a></b> [pdf] Installation Guide</p> <p>H6essential Bit Float Portable Audio Recorder, H6essential, Bit Float Portable Audio Recorder, Float Portable Audio Recorder, Portable Audio Recorder, Audio Recorder</p> |
|---|--|

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.