Angetube 862Pro Streaming Webcam with Microphone User Manual

Contents

Angetube 862Pro Streaming Webcam with Microphone

what is in the Box?

862PRO

INSTALLATION

Stream Webcam

LED

OFF

ON

2

1/4inch

How To Fixed

Specification

|	
Video Resolution	1920x1080, 1280 * 720, 640x480 etc
Frame Rate	1080p@60FPS/sec;
Image sensor	2.0M, 1/2.7 inch
Fomat	JPEG, YUY2
Aperture F value	F/N2.0
View Angle	76 degree, Vertical distortion-free
Private shutter	Yes, built in
Focos method	Auto focus (AF);
MIC	35db+ high sensitivity, SNR65d2 signal-to-noise ratio, 2-channel stereo noise reduction dual MIC, 3m long-distance pickup clear and natural.
Light	Rotating Infinitely dimmable, Touch 3 colors beauty fill-in light
App	Photo or video: use camera software of systems(for Windows camera and for MAC OS photo shown) ect.
System Compatible	Windows® XP SP2, Windows 7 / 8 / 10/ Mac OS 10.6Linux 2.6.24 OR /Chrome OS 29.0.1547.70/, Android V 5.0/Smart TV and TV BOX , XBox One™; Ubuntu® Linux 10.04;OBS, Facebook, YouTube, Xbox one, xsplit, Skype
Configuration requirements	2.4GHZ Intel Core2 DuoProcessor or higher, 2GB of ram or higher, USB2.0 port (USB3.0 is required for 4K products);

REMOTE FUNCTIONS

1 Touch ↕↑ (Mute) = 🎤̸ / 🎤

2 Touch ↕↑ (+) = Initial → → → Max

3 Touch ↕↑ (–) = Max → → → Initial

4 Touch ↕↑ = ☀ → ☀ → ☀ → ☀ → ☀

5 Touch ↕↑ (Default) = { ☀ / ☀ / ☀ } → ☀
Any   Default

6 Touch ↕↑ (Default) = 0X → 1X → 2X → MaxX

7 Touch ↕↑ (∧) = [▢] → [▢]

8 Touch ↕↑ (∨) = [▢] → [▢]

9 Touch ↕↑ (>) = [▢] → [▢]

10 Touch ↕↑ (<) = [▢] → [▢]

11 Touch ↕↑ = (OFF) → (ON)

Documents / Resources

| | **Angetube 862Pro Streaming Webcam with Microphone** [pdf] User Manual
862Pro Streaming Webcam with Microphone, 862Pro, Streaming Webcam with Microphone, Streaming Webcam, Webcam |