Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun Braun AS 330

Braun Satin Hair 3 AS330 Air Styler Instruction Manual

Model: Braun AS 330 | Brand: Braun

Introduction

The Braun Satin Hair 3 AS330 Air Styler is designed to help you create various hairstyles while drying your hair gently. This manual provides detailed instructions on how to safely and effectively use your air styler and its accessories to achieve shiny, healthy-looking hair.



Image: The Braun Satin Hair 3 AS330 Air Styler, showcasing the main unit, the volume comb attachment, and the small round brush attachment.

Safety Warnings

Please read all safety instructions carefully before using the appliance. Keep this manual for future reference.

- Do not use this appliance near water (e.g., in a bathtub, shower, or near a basin).
- Always unplug the appliance after use.

- If the appliance is used in a bathroom, unplug it after use as the proximity of water presents a hazard even when the appliance is switched off.
- Do not use the appliance if the cord is damaged.
- This appliance is not a rotating brush.
- Keep out of reach of children.

Setup

Unboxing and Components

Upon unboxing, ensure all components are present:

- Braun Satin Hair 3 AS330 Air Styler main unit
- Volume comb attachment
- Small round brush attachment

Attaching Accessories

To attach an accessory, align the attachment with the main unit and push firmly until it clicks into place. To remove, press the release button (if present) or twist and pull the attachment off.



Image: The Braun Satin Hair 3 AS330 Air Styler with the large round brush attachment securely in place.



Image: The Braun Satin Hair 3 AS330 Air Styler with the volume comb attachment attached, ready for use.

Power Connection

Plug the power cord into a suitable electrical outlet. Ensure the voltage matches the specifications of the appliance.

Operating Instructions

Powering On and Settings

To turn on the air styler, slide the switch to your desired setting. The AS330 features multiple heat/airflow settings to suit different hair types and styling needs. The ceramic coating ensures even heat distribution, protecting your hair from excessive heat.

- **Setting "I" (Low Heat/Airflow):** Ideal for gentle drying and styling, especially for fine or damaged hair.
- **Setting "II" (High Heat/Airflow):** Suitable for faster drying and more intense styling, particularly for thick or damp hair.
- **Setting "O" (Off):** Turns the appliance off.

Using the Attachments

The Braun Satin Hair 3 AS330 comes with two primary attachments for versatile styling:

Volume Comb Attachment





Image: A detailed view of the volume comb attachment, designed to lift hair at the roots and add volume.

Use the volume comb to lift hair at the roots and add volume. Section your hair and place the comb close to the scalp, lifting upwards as you dry. This attachment is excellent for creating body and fullness.

Small Round Brush Attachment



Image: A close-up of the small round brush attachment, ideal for creating curls, waves, or smoothing ends.

The small round brush is perfect for creating curls, waves, or smoothing the ends of your hair. Wrap sections of hair around the brush and slowly pull through while drying. The special roll-out function helps prevent hair from tangling or breaking during styling.

General Styling Tips

- For best results, use on towel-dried hair.
- Section your hair before styling to ensure even drying and consistent results.
- Always move the air styler continuously to avoid concentrating heat on one spot.
- The appliance allows you to dry and style in one step, making it efficient for daily use.

Maintenance

Cleaning the Appliance

Regular cleaning ensures optimal performance and extends the life of your air styler.

1. Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. Wipe the main unit with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
3. Remove any hair or debris from the attachments using a small brush or your fingers. The attachments can be rinsed under running water, but ensure they are completely dry before reattaching to the main unit.
4. Clean the air inlet filter (if accessible) regularly to prevent dust buildup, which can affect airflow and performance.

Storage

Store the air styler in a dry place, away from direct sunlight and moisture. Ensure the cord is not tightly wrapped around the appliance, as this can cause damage over time.

Troubleshooting

If you encounter any issues with your Braun Satin Hair 3 AS330, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; Power outlet issue; Damaged cord.	Ensure the plug is fully inserted. Test the outlet with another device. If the cord is damaged, do not use and contact customer support.
No or weak airflow.	Air inlet filter blocked; Motor malfunction.	Clean the air inlet filter. If the problem persists, contact customer support.
Appliance gets too hot.	Airflow obstruction; Prolonged use.	Ensure air inlets/outlets are clear. Allow the appliance to cool down before resuming use.
Hair tangles in the brush.	Incorrect technique; Hair section too large.	Use smaller hair sections. Utilize the roll-out function of the round brush. Ensure hair is detangled before styling.

Specifications

Product Name	Air Styler for hair
Model Number	Braun AS 330
Brand	Braun
Power	400 Watts
Material	Ceramic
Color	Black
Dimensions (L x W x H)	50 x 50 x 28 cm
Weight	430 grams

Number of Speeds	2
Special Feature	Ceramic Heating system
Country of Origin	China

Warranty and Support

This product is covered by a manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Braun website. For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact Braun customer service.
You can find contact information for customer support on the official Braun website or through your retailer.

© 2023 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00008K62L

More documents and user manuals: **https://manuals.plus/**