Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gardena 2849-20

Gardena Profi System (Maxi Flow) Spray Lance Instruction Manual

Model: 2849-20

1. Product Overview

The Gardena Profi System (Maxi Flow) Spray Lance is designed for efficient and versatile watering in your garden. This multi-purpose spray lance is particularly suitable for use with longer hoses or pumps, allowing you to reach less accessible areas with ease. Its robust construction ensures reliable performance for various watering tasks.



Image 1.1: The Gardena Profi System (Maxi Flow) Spray Lance.

Key Features:

- Multifunctional Spray Lance for diverse watering needs.
- Designed for the Gardena Profi System (Maxi Flow) for enhanced water flow.
- Constructed from durable Stainless Steel.
- Manufactured in Germany, ensuring high quality standards.

2. Setup and Installation

To ensure proper function and a secure connection, follow these steps for setting up your Gardena Profi System Spray Lance:

1. **Connect to Hose:** Ensure your garden hose is equipped with a Gardena Profi System hose connector. Insert the spray lance's connector end firmly into the hose connector until it clicks into place. A secure connection is essential to prevent leaks and maintain optimal water pressure.

2. **Check for Leaks:** Turn on the water supply gradually and check all connections for any leaks. Tighten connections if necessary.
3. **System Compatibility:** This spray lance is designed for the Gardena Profi System (Maxi Flow). For optimal performance, ensure all connecting components (hoses, taps, other accessories) are compatible with the Profi System.



Image 2.1: Example of a Gardena hose connector for system compatibility.

3. Operating Instructions

The Gardena Profi System Spray Lance offers versatile watering options for various garden tasks.

Watering Plants and Flowers:

Use the adjustable spray pattern to provide a gentle shower for delicate plants and flowers. The extended reach of the lance helps water plants in hard-to-reach areas without stepping on garden beds.



Image 3.1: Watering flowers with a gentle spray.



Image 3.2: Providing water to various garden plants.

General Garden Watering:

For larger areas or more robust plants, adjust the spray to a wider or more powerful stream. The long handle provides

comfortable use and extended reach.



Image 3.3: Efficiently watering a garden bed.



Image 3.4: Watering lawn areas.

Cleaning Tasks:

The powerful jet setting is suitable for cleaning garden tools, pathways, or other outdoor surfaces. Always ensure the surface can withstand the water pressure before applying a strong jet.



Image 3.5: Cleaning a wheelbarrow.



Image 3.6: Cleaning patio surfaces.

4. Maintenance

Proper maintenance extends the life of your Gardena Spray Lance and ensures continued optimal performance.

- **Cleaning:** After each use, rinse the spray lance with clean water to remove any dirt, debris, or chemical residues.
- **Storage:** Store the spray lance in a dry, frost-free environment when not in use, especially during winter months. Freezing water inside the lance can cause damage.
- **Inspection:** Periodically inspect the spray lance for any signs of wear, damage, or blockages in the nozzle. Clean or replace parts as needed.

5. Troubleshooting

If you encounter issues with your Gardena Profi System Spray Lance, consider the following common solutions:

- **Low Water Pressure:** Check your water source and hose for kinks or blockages. Ensure all connections are tight

and that your Gardena Profi System components are correctly assembled.

- **Leaking Connections:** Verify that the hose connector is fully engaged with the spray lance and that the rubber seals (O-rings) are intact and properly seated. Replace worn seals if necessary.
- **Irregular Spray Pattern:** The nozzle might be partially blocked by debris or mineral deposits. Try cleaning the nozzle head. If adjustable, ensure the spray pattern mechanism moves freely.
- **Difficulty Attaching/Detaching:** Ensure the quick-connect mechanism is clean and free of debris. Apply a small amount of silicone grease to the O-rings if they are stiff.

6. Specifications

Model Number	2849-20
Brand	Gardena
Material	Stainless Steel
Item Dimensions (L x W x H)	38.39 x 7.87 x 3.74 inches
Item Length	30 Centimeters
Item Weight	420 Grams
Connector Type	Barb
Thread Size	3/4 inch
Thread Type	BSP
Exterior Finish	Painted
Number of Pieces	1

7. Quality and Manufacturing

Gardena products, including the Profi System Spray Lance, are developed and manufactured with a focus on durability, functionality, and user experience. The manufacturing process incorporates high-quality materials, advanced techniques, and rigorous quality control to ensure each product meets stringent standards. Products undergo extensive testing for resistance to environmental factors like UV radiation and frost, as well as continuous pressure and usage cycles, ensuring long-lasting performance in various garden conditions.

▶ **Watch video online**
Gardena 1948 7-Setting Circular Sprinkler Vario With Base.Gardena 19487-setting aspersor circular...

Video 7.1: This video showcases the manufacturing process, quality control, and various applications of the Gardena Original System, including spray lances, hose connectors, and sprinklers, highlighting their durability and ease of use.

8. Warranty and Support

The Gardena Profi System (Maxi Flow) Spray Lance comes with a**1-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or further assistance, please refer to the contact information provided on the official Gardena website or your product packaging. Keep your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0001E3UKC

More documents and user manuals: **https://manuals.plus/**