Howard Miller 645-579

Howard Miller Regent Table Clock (Model 645-579) Instruction Manual

PRODUCT OVERVIEW

The Howard Miller Regent Table Clock, Model 645-579, is a modern tabletop alarm clock designed to enhance any space with its elegant and functional design. It features a sleek beveled glass arch, a sturdy glass base, and a polished silver-tone bezel. The white dial displays black Roman numerals, hour markers, and black hands with luminous inserts for clear visibility. Powered by a silent quartz movement, this clock ensures precise timekeeping without disruptive ticking sounds.

Figure 1: Front view of the Howard Miller Regent Table Clock, showcasing its beveled glass arch and white dial with Roman numerals.

Video 1: This video provides a general overview of the Howard Miller Regent Table Clock, Model 645-579.

SETUP

1. Battery Installation

The Howard Miller Regent Table Clock requires one (1) AA battery (not included) for operation. Follow these steps to install the battery:

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.

3. Insert one AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.

4. Close the battery compartment cover securely.

Figure 2: Back view of the clock, highlighting the battery compartment for easy access.

2. Setting the Time

To set the correct time on your Regent Table Clock, use the time-setting knob located on the back of the clock. Gently rotate the knob until the hour and minute hands display the desired time.

Video 2: This video demonstrates the process of setting the time on a Howard Miller alarm clock, which is applicable to the Regent Table Clock.

OPERATING INSTRUCTIONS

1. Timekeeping

Once the battery is installed and the time is set, the quartz movement will ensure accurate timekeeping. The clock features a silent sweep second hand, eliminating any ticking noise for a peaceful environment.

Figure 3: A close-up view of the clock's white dial, showing the black Roman numerals and luminous hands for easy reading.

2. Alarm Function

The Regent Table Clock includes an alarm function. To set and activate the alarm:

1. Locate the alarm setting knob on the back of the clock.
2. Rotate the alarm setting knob to move the alarm hand to your desired alarm time.
3. Locate the alarm ON/OFF switch (if present on your model) and slide it to the "ON" position to activate the alarm.
4. To turn off the alarm when it sounds, slide the ON/OFF switch to the "OFF" position.

MAINTENANCE

1. Cleaning

To maintain the appearance of your clock, regularly wipe the glass and metal surfaces with a soft, dry, lint-free cloth. Avoid using abrasive cleaners or chemical sprays, as these may damage the finish.

2. Battery Replacement

When the clock begins to lose time or stops running, it is an indication that the battery needs to be replaced. Follow the battery installation steps outlined in the "Setup" section to replace the AA battery.

TROUBLESHOOTING

- **Clock Not Running:**
  - Ensure the AA battery is correctly installed with the proper polarity (+/-).
  - Replace the battery with a fresh one.

- **Alarm Not Sounding:**
  - Verify that the alarm ON/OFF switch is in the "ON" position.
  - Check that the alarm hand is correctly set to the desired wake-up time.
  - Ensure the battery has sufficient power.

- **Inaccurate Timekeeping:**
  - Replace the battery with a new one. A weak battery can cause the clock to run slowly.
 - Ensure the clock is placed on a stable, level surface.

SPECIFICATIONS

Feature	Detail
Brand	Howard Miller
Model Number	645-579
Display Type	Analog
Special Feature	Alarm
Power Source	Battery Powered
Battery Type	1 AA battery (not included)
Material	Glass
Height	6.25 inches (16 cm)
Width	5 inches (13 cm)
Depth	1.5 inches (4 cm)
Item Weight	11.2 ounces (317 Grams)

WARRANTY AND SUPPORT

This Howard Miller Regent Table Clock comes with a 3-month manufacturer warranty. For warranty claims, technical assistance, or further support, please refer to the contact information provided with your product packaging or visit the official Howard Miller website.

For additional product information and to explore other Howard Miller products, visit the Howard Miller Store on Amazon.

Related Documents - 645-579

[Howard Miller Tripod Floor Clock Quartz Movement and Pendulum Instructions Manual](#)

Comprehensive user manual for the Howard Miller Tripod Floor Clock. Includes setup, time setting, melody selection, volume control, pendulum installation, battery replacement, and warranty details.

[Howard Miller Wall and Mantel Clock Instruction Manual](#)

Comprehensive instruction manual for Howard Miller wall and mantel clocks, covering setup, winding, time regulation, chime selection, maintenance, troubleshooting, and warranty information.

[Howard Miller 625-236 Radio Controlled Clock User Manual and Setup Guide](#)

Detailed guide for the Howard Miller 625-236 radio-controlled clock, covering setup, time zone settings, signal reception, manual time adjustment, and alarm functions.

[Howard Miller Floor Clock Instruction Manual: Setup, Operation, and Maintenance](#)

Comprehensive instruction manual for Howard Miller floor clocks, covering setup, basic operation, timekeeping, chime selection, care, maintenance, and troubleshooting. Includes detailed steps for cable and chain-driven models.

[Howard Miller Wall and Mantel Clock Instruction Manual](#)

Comprehensive guide for setting up, operating, maintaining, and troubleshooting Howard Miller wall and mantel clocks. Includes chime selection, time regulation, and warranty details.

[Howard Miller Wall and Mantel Clock Instruction Manual](#)

Comprehensive instruction manual for Howard Miller Wall and Mantel Clocks, covering setup, time setting, winding, regulation, chime selection, maintenance, troubleshooting, and warranty information.