Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Duracell DL1/3NBPK

Duracell DL1/3NBPK Photo Batteries User Manual

Model: DL1/3NBPK (Dur-6388)

Introduction

This manual provides essential information for the safe and effective use of your Duracell DL1/3NBPK Photo Batteries. These 3.0 Volt Lithium batteries are designed to provide reliable power for various electronic devices, particularly cameras and other photo equipment. Please read this manual thoroughly before use.



Image: Duracell DL1/3NBPK Photo Battery, showing the battery within its retail packaging, highlighting the 1/3N size and Duracell branding.

Safety Information

Always handle batteries with care. Improper use can lead to leakage, heat generation, explosion, or fire, which may cause injury. Observe the following precautions:

- Do not recharge, disassemble, heat above 100°C (212°F), or incinerate.
- Do not mix new and used batteries, or different types of batteries.
- Insert batteries correctly, observing polarity (+ and -).
- Keep batteries out of reach of small children. If swallowed, seek immediate medical attention.
- Remove exhausted batteries promptly from devices.
- Store batteries in a cool, dry place away from direct sunlight.

Setup and Installation

To install your Duracell DL1/3NBPK Photo Battery:

1. Identify the battery compartment on your device (e.g., camera, calculator).
2. Open the battery compartment cover.
3. Observe the polarity markings (+ and -) inside the compartment.
4. Insert the Duracell DL1/3NBPK battery, aligning its positive (+) and negative (-) terminals with the corresponding markings in the compartment.
5. Close the battery compartment cover securely.

Ensure the battery is firmly seated to establish proper electrical contact.

Operating Instructions

Once installed, the Duracell DL1/3NBPK battery will power your compatible device. These lithium batteries are known for their long-lasting performance and stable voltage output, making them ideal for high-drain devices like digital cameras.

- **Power On:** Turn on your device as per its own operating instructions.
- **Performance:** Expect consistent power delivery throughout the battery's life. Performance may vary based on device power consumption and usage patterns.
- **Low Battery Indication:** Most devices will provide an indication when the battery level is low. Replace batteries when this occurs to ensure uninterrupted operation.

Maintenance and Storage

Proper maintenance and storage extend battery life and ensure safety:

- **Storage:** Store unused batteries in their original packaging or a non-conductive container to prevent short circuits. Keep them in a cool, dry place at room temperature. Avoid extreme temperatures.
- **Cleaning:** If battery terminals become dirty, gently wipe them with a clean, dry cloth. Do not use water or cleaning agents.
- **Disposal:** Do not dispose of batteries in household waste. Lithium batteries should be recycled according to local regulations. Many retail stores and recycling centers offer battery drop-off points.

Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Incorrect battery insertion, depleted battery, or poor contact.	Check battery polarity. Replace with a new battery. Clean battery terminals and device contacts.
Battery life is shorter than expected.	High power consumption of device, extreme operating temperatures, or old battery.	Ensure device is used within recommended temperature ranges. Replace with a fresh battery.
Battery leakage observed.	Overheating, physical damage, or improper disposal.	Immediately remove the battery using protective gloves. Dispose of safely. Do not touch leaked material.

Specifications

Feature	Detail
Model Number	DL1/3NBPK (Dur-6388)
Battery Cell Composition	Lithium
Voltage	3.0 Volts
Recommended Uses	Cameras, Calculators, other compatible electronic devices
Package Dimensions	5 x 4 x 3 inches
Package Weight	1 Pound

Feature	Detail
Country of Origin	Switzerland
First Available Date	June 12, 2006

Warranty and Support

Duracell batteries are manufactured to high quality standards. While specific warranty details for individual batteries may vary, Duracell stands behind its products. For detailed warranty information or technical support, please visit the official Duracell website or contact their customer service.
You can find more information and contact details on theDuracell Store on Amazon.

© 2024 Duracell. All rights reserved.
This manual is for informational purposes only. Duracell is a registered trademark.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000GARV2Y

More documents and user manuals: **https://manuals.plus/**