Fluke TL81A

Fluke TL81A Deluxe Electronic Test Lead Kit User Manual

Model: TL81A

1. Introduction

The Fluke TL81A Deluxe Electronic Test Lead Kit is designed for a wide range of electronic testing and design applications. This kit provides various components to facilitate precise measurements and connections in electronic circuits, including those with small surface-mount device (SMD) test points.
This manual provides instructions for the proper use, maintenance, and care of your Fluke TL81A kit.

2. Product Components

The Fluke TL81A Deluxe Electronic Test Lead Kit includes the following components:

- 3 test leads (red, black, green) connected to low-leakage probes.
- 3 alligator clips (red, black, green).
- 2.6m lead length for extended reach.
- 26mm maximum jaw opening on alligator clips.
- Precision electronic probes with multiple spring-loaded sharp tips for SMD testing.
- Micro-grabbers and leads for fine SMD tests.
- Mini alligator clips, grabbers, and probes for various electronic needs.
- A quadfold nylon pouch for organized storage and transport.



Figure 2.1: Overview of the Fluke TL81A Deluxe Electronic Test Lead Kit components, including test leads, probes, alligator clips, and storage pouch.

3. Setup

Before using the test lead kit, ensure all components are clean and free from damage. Proper setup is crucial for accurate measurements and user safety.

1. **Inspect Components:** Visually inspect all test leads, probes, and clips for any signs of wear, cuts, cracks, or exposed wiring. Do not use damaged components.
2. **Connect Test Leads:** Insert the banana plugs of the test leads into the appropriate input jacks of your multimeter or test instrument. Typically, the black lead connects to the COM (common) jack, and the red lead connects to the VΩmA (voltage, resistance, current) jack.

3. **Attach Probes/Clips:** Select the appropriate probe or clip for your measurement task. The kit includes various options such as sharp-tipped probes for SMD, micro-grabbers, and alligator clips. Attach these securely to the ends of the test leads.



Figure 3.1: Detail of test lead connections, showing the right-angle and straight banana plugs for secure attachment to a multimeter.



Figure 3.2: Fluke test probes with various interchangeable tips, including sharp points for precision measurements.

4. Operating Instructions

Always prioritize safety when performing electrical measurements. Refer to your multimeter's instruction manual for specific operating procedures.

1. **Safety First:** Ensure the circuit under test is de-energized if possible, or take appropriate safety precautions for live circuits. Wear personal protective equipment (PPE) as required.
2. **Select Measurement Type:** Set your multimeter to the correct function and range for the measurement you intend to make.
3. **Make Connections:**
    - For voltage measurements, connect the probes in parallel across the component or circuit point.
    - For current measurements, connect the probes in series with the circuit, ensuring the circuit is broken to insert the meter.
    - For resistance measurements, ensure the circuit is de-energized before connecting the probes across the component.
4. **Read Measurement:** Observe the reading on your multimeter.
5. **Disconnect Safely:** Always disconnect the test leads from the circuit before changing the multimeter function or range, or before moving to a different measurement point. Disconnect the red (hot) lead first, then the black (common) lead.



Figure 4.1: A selection of test lead tips and adapters, including fine-point probes and insulation-piercing probes, designed for diverse testing requirements.



Figure 4.2: Red and black Fluke alligator clips, providing secure, hands-free connections for various testing applications.

5. Maintenance

Proper maintenance extends the life of your test lead kit and ensures continued accuracy and safety.

- **Cleaning:** Clean test leads and probes with a damp cloth and mild detergent. Do not use abrasive cleaners or solvents. Ensure all components are completely dry before storage or next use.
- **Inspection:** Regularly inspect leads for cuts, abrasions, or damage to the insulation. Check probes and clips for bent tips, loose connections, or corrosion. Replace any damaged components immediately.
- **Storage:** Store the test lead kit in its provided nylon pouch in a clean, dry environment, away from direct sunlight and extreme temperatures. Avoid kinking or sharply bending the leads during storage.

6. Troubleshooting

If you encounter issues with your test lead kit, consider the following common troubleshooting steps:

- **No Reading or Erratic Readings:**
  - Check that leads are securely connected to both the multimeter and the circuit.
  - Ensure the multimeter is set to the correct function and range.
  - Inspect leads and probes for internal breaks or damage. Use a known good lead to test the multimeter's functionality.

- **Poor Connection:**
  - Ensure probe tips or alligator clips are making firm contact with the test point.
  - Clean any dirt or oxidation from the probe tips or test points.
- **Damaged Insulation:**
  - Immediately discontinue use of any lead with damaged insulation. Replace the lead to prevent electrical shock hazards.

7. Specifications

Key specifications for the Fluke TL81A Deluxe Electronic Test Lead Kit:

Feature	Specification
Brand	Fluke
Model Number	TL81A
Style	TEST LEAD SET
Lead Length	2.6 meters (approx. 8.5 feet)
Alligator Clip Jaw Opening	26 mm (maximum)
Material	Silicone Test Leads
Color	Black/Red
Item Weight	0.88 Pounds (approx. 14.1 ounces)
Product Dimensions (L x W x H)	9.45 x 10.6 x 2.4 inches
Upper Temperature Rating	200 Degrees Celsius
Measurement Type	Multimeter
Usage	Professional

8. Warranty Information

Fluke products are designed for reliability and durability. For specific warranty terms and conditions applicable to the TL81A Deluxe Electronic Test Lead Kit, please refer to the warranty card included with your product or visit the official Fluke website. Warranty coverage typically addresses defects in materials and workmanship under normal use.

9. Support Information

For technical assistance, product inquiries, or service, please contact Fluke customer support through their official channels. You can find contact information, FAQs, and additional resources on the official Fluke website:
Official Fluke Website: www.fluke.com
Ensure you have your product model number (TL81A) available when contacting support for faster service.

© 2025 Fluke Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question