Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coleman 1000L Deluxe Propane Lantern

Coleman 1000L Deluxe Propane Lantern User Manual

Model: 1000L Deluxe Propane Lantern

Introduction

This manual provides essential information for the safe and effective operation, maintenance, and care of your Coleman 1000L Deluxe Propane Lantern. This 2-mantle propane lantern features a hard carry case, adjustable light output, and a PerfectFlow propane pressure control system for consistent performance. It is designed for outdoor use, providing bright illumination for various activities.



Image: The Coleman 1000L Deluxe Propane Lantern shown with its included hard carry case.

Safety Information

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.

- Always operate the lantern in a well-ventilated area.
- Keep children and pets away from the lantern during operation.
- Do not touch the globe or other hot surfaces during or immediately after use.
- Ensure the lantern is stable on a flat surface or securely hung before lighting.
- Turn off the fuel valve and allow the lantern to cool completely before handling or storing.
- Use only Coleman 16.4 oz propane cylinders.

Setup

1. Attaching the Propane Cylinder

1. Ensure the fuel valve on the lantern is in the "OFF" position.
2. Remove the protective cap from the propane cylinder (sold separately).
3. Carefully screw the lantern onto the threaded valve of the propane cylinder. Hand-tighten only. Do not overtighten.
4. Check for any gas leaks by applying a soapy water solution to the connection point. If bubbles appear, tighten the connection or replace the cylinder if damaged.

2. Installing Mantles

The lantern comes with 2 Insta-Clip #21 mantles. Mantles are fragile and should be handled with care.

1. Remove the top ventilator and glass globe by unscrewing the top nut and lifting the bail handle.
2. Locate the mantle clips on the burner tubes.
3. Clip the new mantles onto the burner tubes. Ensure they are securely attached.
4. Burn off the new mantles: Light the mantles with a match or lighter until they turn white and ash. This process prepares them for use.
5. Replace the glass globe and top ventilator, securing them with the top nut.



Image: A hand demonstrating the installation of a mantle onto the burner tube of the lantern.

3. Deploying the Collapsible Footed Base

The lantern features a collapsible footed base for increased stability.

- Gently pull out the foldable feet from the base of the lantern until they lock into place.
- Ensure all feet are fully extended and the lantern is stable on a flat, level surface.



Image: The Coleman propane lantern with its collapsible feet fully extended, providing a wide and stable base.

Operating Instructions

1. Lighting the Lantern

1. Ensure the lantern is on a stable surface or securely hung.
2. Turn the fuel valve knob counter-clockwise to the "LIGHT" position (indicated by a flame icon).
3. Immediately place a lit match or lighter near the mantles. The mantles should ignite.
4. If the mantles do not light, turn the fuel valve to "OFF", wait a few moments, and repeat the process.



Image: A detailed view of the control knob, showing the "OFF" and "LIGHT" positions, and the connection to the propane cylinder.

2. Adjusting Brightness

- Once lit, rotate the fuel valve knob to adjust the light output.
- Turn clockwise for lower brightness and counter-clockwise for higher brightness. The lantern provides up to 1000 lumens on high.

3. Turning Off the Lantern

- Rotate the fuel valve knob fully clockwise to the "OFF" position.
- Allow the lantern to cool completely before moving or storing.

Maintenance

1. Replacing Mantles

Mantles are consumable and will need replacement when they become damaged or lose their brightness.

- Ensure the lantern is completely cool and the fuel valve is off.
- Remove the top ventilator and glass globe.

- Carefully remove the old, brittle mantles.
- Install new Insta-Clip #21 mantles as described in the Setup section.
- Burn off the new mantles before reassembling the lantern.

2. Cleaning the Lantern

- Wipe down the exterior of the lantern with a damp cloth.
- Clean the glass globe with a soft, lint-free cloth. Avoid abrasive cleaners.
- The porcelain-coated 2-tier ventilator is designed to resist corrosion and rust, requiring minimal cleaning.

3. Storage

- Always disconnect the propane cylinder before storing the lantern.
- Collapse the footed base for compact storage.
- Store the lantern in its hard carry case to protect the globe and mantles from damage.
- Store in a cool, dry place away from direct sunlight and heat sources.

Troubleshooting

- **Lantern does not light:** Ensure the propane cylinder is securely attached and has fuel. Check if mantles are properly installed and burned off.
- **Flickering or dim light:** This may indicate low fuel in the propane cylinder or damaged mantles. Replace the cylinder or mantles as needed.
- **Gas leak detected:** Immediately turn off the fuel valve. Check all connections for tightness. If the leak persists, do not use the lantern and contact customer support.
- **Glass globe cracking:** The high-temperature globe is designed to resist cracking. Ensure the lantern is not subjected to sudden temperature changes or impacts.

Specifications

Model	1000L Deluxe Propane Lantern
Light Output	Up to 1000 lumens (on high)
Illumination Range	Up to 23 meters
Fuel Type	Propane (16.4 oz cylinder, sold separately)
Run Time	Up to 7.5 hours on high, 13 hours on low (per 16.4 oz cylinder)
Mantles Included	2 Insta-Clip #21 mantles
Pressure Control	PerfectFlow™ system
Base	Collapsible footed base for stability
Ventilator	Porcelain-coated 2-tier ventilator
Carry Case	Hard carry case included
Item Weight	5.2 Pounds

Warranty

This Coleman 1000L Deluxe Propane Lantern is covered by a **3-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For warranty claims or further details, please refer to the official Coleman website or contact their customer service.

Support

For additional support, product information, or to purchase replacement parts and accessories, please visit the official Coleman website or contact Coleman Customer Service.

- **Website:** www.coleman.com
- **Customer Service:** Refer to the contact section on the Coleman website for phone numbers and email support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000PGHCNC

More documents and user manuals: **https://manuals.plus/**