Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Duracell MN1500B4Z

Duracell Alkaline Powerboost AA4 Battery User Manual

Brand: Duracell | **Model:** MN1500B4Z

Product Overview

The Duracell Alkaline Powerboost AA4 Battery pack provides reliable and long-lasting power for a wide range of electronic devices. These CopperTop batteries are engineered to deliver consistent performance and are guaranteed against manufacturing defects. They feature Duralock Power Preserve technology, ensuring a freshness guarantee for up to 10 years in storage. This product contains no added mercury, contributing to environmental protection.



Figure 1: A pack of four Duracell CopperTop AA batteries, showcasing the Duralock Power Preserve technology and a 10-year storage guarantee.

- Sold as a pack of 4 AA batteries.
- Engineered for long-lasting, reliable power in most electronic devices.
- Contains no added mercury.
- Rated for reliable operation in temperatures ranging from -4°F to 129°F (-20°C to 54°C).
- Individually date-coded for freshness.

Safety Information

WARNING: Improper use of batteries can result in serious injury or damage. Please observe the following safety precautions:

- Batteries may explode or leak, and cause burn injury, if recharged, disposed of in fire, mixed with a different battery type, inserted backwards, or disassembled.

- Replace all used batteries at the same time. Do not mix old and new batteries, or different types of batteries.
- Do not carry batteries loose in your pocket or purse to prevent short circuits.
- Do not remove the battery label.
- Keep batteries away from children. If swallowed, consult a physician at once. For information on treatment, call (202) 625-3333 collect.

Legal Disclaimer: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Setup

To set up your Duracell AA batteries for use:

1. Carefully remove the batteries from their packaging.
2. Identify the positive (+) and negative (-) terminals on each battery. The positive terminal is typically the raised end, and the negative terminal is the flat end.
3. Refer to your device's instruction manual for specific battery insertion guidelines. Most devices will have markings indicating the correct polarity.
4. Insert the batteries into the device, ensuring that the positive (+) terminal of the battery aligns with the positive (+) marking in the device, and the negative (-) terminal aligns with the negative (-) marking.
5. Close the battery compartment securely.

Operating Guidelines

Duracell AA batteries are designed for general purpose use in a wide variety of electronic devices. For optimal performance and safety:

- Always use the correct size and type of battery specified by the device manufacturer.
- Ensure batteries are inserted with correct polarity (+ and -).
- Remove batteries from devices that will not be used for extended periods to prevent potential leakage.
- Do not attempt to recharge non-rechargeable batteries.
- Do not expose batteries to excessive heat or direct sunlight.

Maintenance and Storage

Proper maintenance and storage can extend the life and ensure the safety of your Duracell batteries:

- Store unused batteries in their original packaging in a cool, dry place at room temperature.
- Avoid storing batteries in extreme temperatures, both hot and cold, as this can affect performance and shelf life.
- Do not store batteries with metal objects like coins or keys, as this can cause a short circuit.
- The Duralock Power Preserve technology guarantees freshness for up to 10 years in storage under normal conditions.
- Check the date code on the battery for optimal use within its freshness period.

Troubleshooting

If you encounter issues with your Duracell batteries, consider the following:

- **Device Not Powering On:**
  - Ensure batteries are inserted with correct polarity (+ and -).
  - Check if the batteries are fully charged or if they need replacement.
  - Clean battery contacts in the device and on the batteries with a dry cloth to remove any dirt or corrosion.
- **Short Battery Life:**
  - Verify that the device is not drawing excessive power.
  - Ensure the batteries are not expired.
  - Consider the operating temperature; extreme temperatures can reduce battery life.
- **Battery Leakage:**
  - If a battery leaks, avoid contact with skin and eyes.
  - Clean the device's battery compartment carefully with a cotton swab and vinegar (for alkaline leaks) or lemon juice, then wipe dry.
  - Dispose of leaked batteries according to local regulations.

Specifications

Feature	Detail
Product Type	Alkaline Battery
Battery Size	AA
Model Number	MN1500B4Z
Quantity	4 Count
Product Dimensions	0.6 x 3.7 x 4.5 inches
Item Weight	1.44 ounces
Manufacturer	Duracell
Shelf Life (in storage)	Up to 10 years (Duralock Power Preserve)
Operating Temperature Range	-4°F to 129°F (-20°C to 54°C)

Warranty Information

Duracell CopperTop batteries are guaranteed against defects in materials and workmanship. Additionally, these batteries feature Duralock Power Preserve technology, guaranteeing freshness for up to 10 years in storage under normal conditions. For warranty claims or further details, please refer to the official Duracell website or contact customer support.

Customer Support

For any questions, concerns, or technical assistance regarding your Duracell Alkaline Powerboost AA4 Batteries,

please visit the official Duracell website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.
For immediate safety concerns related to battery ingestion, please call (202) 625-3333 collect.

© 2025 Duracell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000YHO5MI

More documents and user manuals: **https://manuals.plus/**