Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Campingaz Bleuet Micro Plus

Campingaz Bleuet Micro Plus Camping Stove User Manual

Model: Bleuet Micro Plus (204184UK)
Brand: Campingaz

Introduction

The Campingaz Bleuet Micro Plus is an ultra-compact and lightweight single-burner gas stove designed for outdoor use, including camping, backpacking, and festivals. Its robust design ensures stability, even in windy conditions or on uneven surfaces. This stove features an adjustable 1250 W burner, capable of boiling 1 liter of water in approximately 5 minutes and 25 seconds. It is compatible with Campingaz CV300 Plus and CV470 Plus gas cartridges, offering convenient and quick cartridge replacement.

Setup

Before first use, ensure all components are present and undamaged. The stove is designed for use with Campingaz CV300 Plus or CV470 Plus gas cartridges.

1. Unfolding the Pan Supports

Carefully unfold the four metal pan supports from their folded position until they click securely into place, forming a stable platform for your cookware.



Image: A pair of hands demonstrating the unfolding of the metal pan supports on the Campingaz Bleuet Micro Plus stove, preparing it for use.

2. Attaching the Gas Cartridge

Ensure the stove's control knob is in the "OFF" position. Align the stove's connection point with the gas cartridge. Push the stove firmly onto the cartridge and twist clockwise until it locks into place. The Campingaz EasyClic system allows for secure attachment and detachment even if the cartridge is not empty.



Image: Close-up of hands connecting the Campingaz Bleuet Micro Plus stove to a blue gas cartridge, illustrating the attachment process.





Image: The Campingaz Bleuet Micro Plus stove fully assembled and securely attached to a gas cartridge, ready for operation.

Operating Instructions

Always operate the stove in a well-ventilated outdoor area, away from flammable materials. Do not use indoors.

1. Ignition

Slowly turn the control knob counter-clockwise to release a small amount of gas. Immediately ignite the gas using a match or lighter held near the burner head. If the gas does not ignite within a few seconds, turn the knob to "OFF", wait for the gas to disperse, and try again.

2. Flame Adjustment

Once ignited, adjust the flame intensity by rotating the control knob. Turn clockwise to decrease the flame and counter-clockwise to increase it. The stove provides precise flame control for various cooking needs.



Image: A close-up view of the Campingaz Bleuet Micro Plus stove's burner head, showing a steady blue flame, indicating proper operation.

3. Shutting Down

To turn off the stove, rotate the control knob fully clockwise to the "OFF" position. Ensure the flame is completely extinguished. Allow the stove to cool down completely before handling or disassembling.

Maintenance

Proper maintenance ensures the longevity and safe operation of your stove.

Cleaning

After each use, once the stove has cooled, wipe down the metal surfaces with a damp cloth to remove any food residue or spills. For stubborn stains, a mild soap solution can be used. Ensure the burner head and gas outlet are free from obstructions. Do not use abrasive cleaners or harsh chemicals.

Storage

Detach the gas cartridge from the stove. Fold the pan supports inward for compact storage. Store the stove in a dry, cool place, away from direct sunlight and sources of heat. Keep out of reach of children.



Image: The Campingaz Bleuet Micro Plus stove in its folded, compact state, held in the palm of a hand, highlighting its portability and ease of storage.

Troubleshooting

If you encounter issues with your stove, refer to the following common problems and solutions:

- **No Flame or Weak Flame:**
  - Check if the gas cartridge is empty and replace if necessary.
  - Ensure the gas cartridge is securely attached to the stove.
  - Verify that the control knob is turned sufficiently to allow gas flow.
  - Check for any blockages in the burner head or gas outlet.
- **Gas Leak Smell:**
  - Immediately turn off the stove and move to a well-ventilated area.
  - Ensure the gas cartridge is properly connected.
  - If the smell persists, disconnect the cartridge (if safe to do so) and do not use the stove. Contact Campingaz customer support or a qualified technician.
- **Unstable Flame:**
  - Ensure the stove is on a level, stable surface.
  - Check for strong drafts or wind, which can affect flame stability. Consider using a wind shield if available.

Specifications

Brand	Campingaz
Model Name	Bleuet Micro Plus
Model Number	204184UK
Power	1,300 W
Boil Time (1 Litre)	5 min 15 sec
Runtime (CV270 Plus)	> 2 h 30 min

Runtime (CV300 Plus)	> 2 h 40 min
Runtime (CV470 Plus)	> 5 h
Weight	180 g (Stove only) / 200 g (Product weight including packaging)
Product Dimensions (Folded)	13.49 x 13.49 x 10.01 cm
Fuel Type	Liquefied Petroleum Gas (Butane/Propane mix)
Material	Lightweight metal or composite

Warranty and Support

For information regarding the product warranty, please refer to the documentation provided at the time of purchase or visit the official Campingaz website. Warranty terms and conditions may vary by region.
For technical support, spare parts, or further assistance, please contact Campingaz customer service through their official website or the contact details provided in your product packaging. Always provide your product model number (204184UK) and purchase details when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001P80GR8

More documents and user manuals: **https://manuals.plus/**