Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bushnell 111545

Bushnell Imageview 15-45x70mm 5MP Camera Spotting Scope User Manual

Model: 111545

Introduction

The Bushnell Imageview 15-45x70mm 5MP Camera Spotting Scope is a versatile optical instrument designed for both observation and digital image capture. It combines a high-magnification spotting scope with a 5-megapixel digital camera, allowing users to view distant subjects and record them as high-resolution photos or videos. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your device.

Key features include 15-45x magnification, a 70mm objective lens, a 5.0 Megapixel camera, and a flip-up 2.5-inch LCD screen for viewing and playback. The device is powered by two AA batteries and supports storage on an SD card. It also comes with a table tripod and a remote shutter cable for enhanced usability.

Setup

1. Unpacking

Carefully remove all components from the packaging. Ensure you have the spotting scope, table tripod, remote shutter cable, and soft case.

2. Battery Installation

1. Locate the battery compartment on the device.
2. Open the compartment cover.
3. Insert two (2) AA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

3. SD Card Installation

1. Locate the SD card slot.
2. Insert a compatible SD card (not included) into the slot until it clicks into place. Ensure the card is inserted in the correct orientation.

4. Attaching the Tripod

1. Extend the legs of the table tripod.
2. Locate the tripod mounting screw on the bottom of the spotting scope.
3. Align the scope with the tripod and gently screw the scope onto the tripod until secure. Do not overtighten.

5. Connecting the Remote Shutter Cable

1. Locate the remote shutter port on the spotting scope.
2. Plug one end of the remote shutter cable into this port.
3. The other end connects to the remote control (if applicable) for hands-free image capture.

Operating Instructions

1. Powering On/Off

Press and hold the **ON/OFF** button (labeled with a power symbol) to turn the device on or off.

2. Adjusting Magnification

Rotate the magnification ring located near the eyepiece to adjust the zoom level from 15x to 45x.

3. Focusing

The Imageview features a sync focus system. Rotate the focus knob to simultaneously sharpen the image seen through the eyepiece and on the LCD screen for optimal clarity.

4. Using the LCD Screen

The 2.5-inch flip-out color LCD screen can be opened for viewing subjects, navigating menus, and reviewing captured media. Adjust its angle for comfortable viewing.

5. Switching Between Eyepiece and Camera Modes

Use the slider switch labeled **Eyepiece** and **Camera** to select your desired viewing/capture mode.

6. Capturing Images and Videos

1. Ensure the device is in **Camera** mode.
2. Press the **MODE** button to switch between photo and video capture modes.
3. Frame your subject using the LCD screen.
4. Press the **SNAP** button (with a camera icon) to take a photo or start/stop video recording.
5. Use the directional arrow buttons to navigate menus or adjust settings. Press **OK** to confirm selections.



This image shows the Bushnell Imageview spotting scope from an angled top-down perspective. The device is black, with a large objective lens at the front and an eyepiece at the rear. A 2.5-inch flip-out LCD screen is open, displaying a clear image of an elk in a grassy field. Below the screen, control buttons are visible, including 'ON/OFF', 'MODE', directional arrows, 'OK', and 'SNAP' (with a camera icon). A slider switch allows selection between 'Eyepiece' and 'Camera' modes. The Bushnell logo with 'B ESTD 1948' is prominently displayed.

Maintenance

1. Cleaning Optics

Use a soft, lint-free cloth specifically designed for optical lenses to clean the objective lens and eyepiece. Avoid using abrasive materials or harsh chemicals. Gently wipe in a circular motion to remove dust and smudges.

2. Battery Care

Remove batteries if the device will not be used for an extended period to prevent leakage. Use fresh, high-quality AA batteries for optimal performance.

3. Storage

Store the spotting scope in its soft case in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the lens caps are in place to protect the optics.

4. Water Resistance

This device is waterproof. While it can withstand exposure to moisture, avoid submerging it in water for prolonged periods. Always dry the device thoroughly after exposure to water.

Troubleshooting

- **Device does not power on:** Check battery installation and ensure batteries are fresh.
- **Blurry image:** Adjust the focus knob. Ensure the eyepiece diopter (if present) is set correctly for your vision.
- **Cannot take photos/videos:** Ensure an SD card is inserted and has sufficient free space. Check that the device is in Camera mode.
- **LCD screen not displaying:** Ensure the screen is fully flipped out and the device is powered on.
- **Remote shutter not working:** Verify the cable is securely connected to both the scope and the remote. Check remote battery if applicable.

Specifications

Model Name	Bushnell Imageview 15-45x70mm 5 MP 2.5"LCD
Magnification	15-45x
Objective Lens Diameter	70mm
Camera Resolution	5.0 Megapixel
LCD Screen	2.5 inch Flip-up Color LCD
Field of View (at 1000 yards)	121.5 ft (at 15x) / 17.5 ft (at 45x)
Close Focus	26 feet
Eye Relief	11mm
Exit Pupil	1.1mm
Lens Coating	Multi-Coated
Water Resistance	Waterproof
Power Source	2x AA Batteries
Weight	0.71 kg (25.4 ounces)
Length	11.6 inches
Model Number	111545

Warranty and Support

Warranty Information

This Bushnell Imageview Spotting Scope includes a limited two-year manufacturer's warranty. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty card included with your product or visit the official Bushnell website.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Bushnell customer support. You can find contact information and additional resources on the official Bushnell website: www.bushnell.com

© 2023 Bushnell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002008N1G

More documents and user manuals: **https://manuals.plus/**