Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Best Price Square K11960XD

Kasp K11960XD Combination Padlock User Manual

Model: K11960XD | Brand: Kasp

Product Overview

The Kasp K11960XD is a high-security combination padlock designed for robust protection. It features a closed shackle design for enhanced resistance against cutting and prying attacks. This padlock utilizes a 4-dial resettable combination mechanism, offering convenience without the need for keys.



Image: Angled view of the Kasp K11960XD Combination Padlock, highlighting the 4-dial combination mechanism.

Key Features:

- **Super tough molybdenum steel shackle:** Provides extra protection against hacksaw and cropping attacks.
- **Hardened steel electro-plated lock body:** Ensures extra strength and resistance to corrosion.
- **Double bolted locking mechanism:** Enhances strength to resist torsion and pulls.
- **Anti-manipulation locking system:** Protects against manipulation attacks.
- **4-dial resettable combination:** Offers convenience and security.
- **Rust-free internal components and dual drainage system:** Provides extra resistance against corrosion.
- **Closed shackle design:** Adds shackle protection to resist shackle attack.

Package Contents

Upon opening your Kasp K11960XD Combination Padlock package, please ensure all the following items are present:

- One (1) Kasp 119 High Security Combination Padlock 60mm Close Shackle
- Combination code setting instructions (integrated into this manual)
- One (1) Change Key (used for re-setting the combination code)



Image: The small metal change key used for resetting the padlock's combination.

Setup: Setting Your Combination

Your Kasp K11960XD padlock comes with a factory preset combination, typically 0-0-0-0. It is highly recommended to change this to a personal, memorable combination immediately after purchase.

1. **Open the Padlock:** Set the dials to the current combination (factory default is 0-0-0-0) and pull the shackle open.
2. **Locate the Reset Mechanism:** On the side or bottom of the padlock body, you will find a small hole. This is where the change key is inserted.



Image: Close-up of the combination dials, showing the numbers clearly.

3. **Insert and Turn the Change Key:** Insert the provided change key into the reset hole. Turn the key 90 degrees clockwise (or counter-clockwise, depending on the model, refer to the small arrow if present) until it clicks into place. The key should remain in this position.
4. **Set Your New Combination:** While the change key is engaged, rotate the four dials to your desired new combination. Ensure the numbers are perfectly aligned with the indicator line.
5. **Lock the New Combination:** Turn the change key back 90 degrees to its original position and remove it. This action locks in your new combination.
6. **Test the New Combination:** Scramble the dials and then enter your new combination. The shackle should now open. If it does not, repeat the steps carefully.

Important: *Remember your new combination. There is no master key or backdoor to reset the combination if forgotten without the change key and following these steps. Keep the change key in a safe place.*

Operating the Padlock

To Open:

1. Rotate the dials to align your secret 4-digit combination with the indicator line.
2. Pull the shackle upwards to release it from the lock body.

To Close and Lock:

1. Ensure the shackle is fully inserted into the lock body.
2. Scramble the dials to a random set of numbers. This secures the padlock.



Image: The Kasp K11960XD padlock with its shackle fully closed and locked.

Maintenance

The Kasp K11960XD padlock is designed for durability and weather resistance. To ensure its longevity and smooth operation:

- **Cleaning:** Periodically wipe the padlock body and shackle with a clean, dry cloth to remove dirt and grime. For stubborn dirt, a slightly damp cloth can be used, followed by drying.
- **Lubrication:** If the dials become stiff or the shackle movement is not smooth, apply a small amount of graphite powder or a silicone-based lubricant to the dial mechanism and shackle opening. Avoid oil-based lubricants as they can attract dust and dirt.
- **Environmental Exposure:** While weather resistant, prolonged exposure to extreme conditions (e.g., saltwater, highly corrosive environments) may accelerate wear. Consider additional protective measures if used in such conditions.

Troubleshooting

Problem	Possible Cause	Solution
Padlock will not open with the correct combination.	Dials not perfectly aligned; combination forgotten or incorrectly set; internal mechanism obstruction.	Ensure each number is precisely centered on the indicator line. Double-check your combination. Try wiggling the shackle gently while entering the combination. If you have the change key, attempt to reset the combination following the "Setup" instructions.
Dials are stiff or difficult to turn.	Dirt/grime accumulation; lack of lubrication.	Clean the dials and surrounding areas. Apply graphite powder or silicone-based lubricant to the dial mechanism.

Problem	Possible Cause	Solution
Change key does not turn or is stuck.	Incorrect insertion; internal obstruction; padlock not in open position.	Ensure the padlock is open (shackle pulled up) before inserting the change key. Verify the key is fully inserted and oriented correctly. Do not force the key.

Specifications

Attribute	Detail
Model Name	K11960XD
Brand	Kasp (Manufactured by CARKA)
Lock Type	Combination Lock
Material	Alloy Steel
Special Feature	Weather Resistant
Dimensions (L x W x H)	2.05 x 1.38 x 3.54 inches (5.2 x 3.5 x 9 cm)
Item Weight	1.45 pounds (0.66 Kilograms)
Color	Gray
UPC	616268313433



Image: The Kasp K11960XD padlock in its retail packaging, illustrating its approximate size (7.6 inches / 19 cm in height).

Warranty and Support

The Kasp K11960XD Combination Padlock is designed for long-lasting performance. Spare part availability is indicated for 1 year from the date of purchase in the EU.
For further assistance, technical support, or inquiries regarding your padlock, please contact the manufacturer or your point of

purchase. Always refer to your purchase receipt for warranty claims.

© 2024 Kasp Security. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002JCTQX4

More documents and user manuals: **https://manuals.plus/**