Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun M90

Braun M90 Mobile Electric Shaver Instruction Manual

Essential information for safe and effective use.

Introduction

This manual provides essential information for the safe and effective use of your Braun M90 Mobile Electric Shaver. Please read all instructions carefully before use and retain for future reference. This device is designed for personal grooming and is suitable for dry shaving.

Safety Information

WARNING:

- Do not use in the shower or near water.
- Do not charge or use the shaver if the battery cover is damaged or missing to prevent the risk of battery explosion.
- Be cautious when using the precision trimmer to avoid cuts.
- Always use the shaver on dry skin to prevent skin irritation.

Product Overview

The Braun M90 Mobile Electric Shaver is designed for convenient shaving on the go. It features a wide floating foil for a close shave, a precision trimmer for detailing, and is fully washable for easy cleaning.



Image: The Braun M90 Mobile Electric Shaver with its protective cap rotated open, showing the foil shaving head and the integrated precision trimmer.

Key Features

- **SmartFoil:** Unique foil pattern designed to capture hairs growing in different directions for an efficient shave.
- **Flexibility:** The shaving head adjusts to facial contours for a comfortable experience.
- **Washable:** The shaver can be easily cleaned under running water.
- **Cordless:** Battery-operated for maximum portability, requiring no power cord during use.
- **Precision Trimmer:** An extendable trimmer for shaping sideburns and moustaches.
- **Protective Twist Cap:** Safeguards the foil when not in use and acts as a power switch.



Image: A visual representation of the Braun M90's key features, including SmartFoil technology, flexible shaving, washable design, and cordless operation.

Setup

Battery Installation

1. Ensure the shaver is turned off and the protective cap is in the 'close' position.
2. Locate the battery compartment cover at the bottom of the shaver.
3. Slide the cover open according to the indicator.
4. Insert two AA batteries, ensuring correct polarity (+/-) as marked inside the compartment.
5. Close the battery compartment cover securely until it clicks into place.



Image: The Braun M90 shaver positioned alongside two AA batteries, illustrating the power source required for operation.

Operating Instructions

Shaving

1. To prepare for shaving, turn the twisting protective cap until it clicks into the 'open' position, revealing the foil head.
2. To switch the shaver on, push the power button located on the side of the shaver.
3. Hold the shaver at a right angle (90°) to your skin.
4. Stretch your skin and shave against the direction of hair growth.
5. Apply gentle pressure, moving the shaver in straight lines or small circular motions.
6. After shaving, push the power button to turn off the shaver.
7. Rotate the protective cap back to the 'close' position to cover the foil.

Using the Precision Trimmer

1. Ensure the shaver is turned on.
2. Slide the precision trimmer switch upwards to extend the trimmer blade.
3. Use the trimmer for precise shaping of sideburns, moustaches, or for pre-trimming longer hairs before shaving.
4. After use, slide the trimmer switch downwards to retract the blade.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your Braun M90 shaver.

Cleaning Under Running Water

1. After each shave, turn off the shaver and remove the foil head.
2. Rinse the shaver head and the cutting elements under warm running tap water.
3. You may use a small amount of liquid soap if desired, then rinse thoroughly.
4. Allow the shaver parts to air dry completely before reassembling or storing.

Using the Cleaning Brush

1. For dry cleaning, especially to remove loose hair from the shaver body or trimmer, use the provided cleaning brush.
2. Brush gently to avoid damaging the foil or cutting elements.
3. The cleaning brush is typically stored in a dedicated slot on the shaver body.



Image: The Braun M90 shaver with its cleaning brush extended from the bottom, ready for use.

Foil Protection

The shaver features a twist cap that protects the foil when the shaver is not in use. Always ensure the cap is in the 'close' position during storage or travel to prevent damage to the delicate foil.



Image: The Braun M90 shaver with its protective twist cap fully closed, safeguarding the foil head.

Troubleshooting

- **Shaver not turning on:** Check if the batteries are correctly inserted and have sufficient charge. Replace with new AA batteries if necessary. Ensure the protective cap is fully twisted to the 'open' position and the power button is pressed.
- **Poor shaving performance:** The foil and cutter block are wear parts. Over time, they may become dull. For optimal performance, consider replacing the foil and cutter block unit every 18 months, or when you notice

reduced shaving efficiency. Ensure the shaver head is clean and free of hair debris.

- **Skin irritation:** Ensure you are shaving on dry skin. Avoid applying excessive pressure. Shave against the direction of hair growth for a closer shave, but if irritation occurs, try shaving with the grain.
- **Trimmer not working:** Ensure the trimmer is fully extended and the shaver is powered on. Clean any hair debris from the trimmer area.

Specifications

- **Model Name:** M-90
- **Power Source:** Battery Powered (2 AA batteries required)
- **Special Features:** Dry Shave, Wide Floating Foil, Precision Trimmer, Washable
- **Recommended Uses:** Beard
- **Product Dimensions:** Approximately 1.5 x 3.11 x 5.16 inches (3.8 x 7.9 x 13.1 cm)
- **Item Weight:** Approximately 3.21 ounces (91 grams)
- **Manufacturer:** Procter & Gamble



Image: A visual representation of the Braun M90 shaver's approximate height, indicating it is 4.9 inches (12 cm) tall.

Warranty and Support

Braun products are manufactured to meet high quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official Braun website. For further assistance or to purchase replacement parts, please contact Braun customer support.
You can find more information and support resources on the officialBraun website.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002TQ4AO0

More documents and user manuals: **https://manuals.plus/**