Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun MR300

Braun Multiquick 3 MR300 Hand Blender Instruction Manual

Model: MR300 | Brand: Braun

Introduction

Thank you for choosing the Braun Multiquick 3 MR300 Hand Blender. This manual provides essential information for the safe and efficient operation, maintenance, and care of your appliance. Please read these instructions carefully before first use and keep them for future reference.

Important Safety Instructions

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions before using the appliance.
- Do not immerse the motor unit in water or other liquids.
- Keep hands, hair, and clothing, as well as spatulas and other utensils, away from moving blades during operation to prevent injury.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Blades are sharp. Handle with care.

Product Overview

The Braun Multiquick 3 MR300 is a versatile hand blender designed for various kitchen tasks such as blending, mixing, and pureeing. It features a powerful motor and a detachable shaft for easy cleaning.




BRAUN
450 Watt



Image 1: The Braun Multiquick 3 MR300 Hand Blender. This image displays the complete hand blender unit, including the motor housing, control buttons, and the detachable blending shaft with its blade guard.

Components:

- **Motor Unit:** Contains the motor and control buttons.
- **Blending Shaft:** Detachable shaft with sharp blades for blending.
- **Beaker:** A 600 ml capacity beaker for blending ingredients.

Setup and Assembly

Before first use, ensure all packaging materials are removed and clean all parts that will come into contact with food.

1. **Attach the Blending Shaft:** Align the blending shaft with the motor unit and twist until it locks securely into place. You should hear a click.
2. **Prepare Ingredients:** Place your ingredients into the provided beaker or another suitable container. Ensure the liquid level is appropriate for blending without overflowing.
3. **Connect to Power:** Plug the hand blender into a suitable electrical outlet (220 Volts).



Image 2: The Braun Multiquick 3 MR300 Hand Blender shown with its accompanying beaker. This illustrates how the blending shaft connects to the motor unit and the typical container used for blending.

Operating Instructions

The Braun Multiquick 3 MR300 features two speed settings for optimal blending control.

1. **Immersion:** Immerse the blending shaft into the ingredients before switching on the appliance to prevent splashing.
2. **Select Speed:**
    - Press the **Speed 1** button for normal blending tasks.
    - Press the **Speed 2** button for faster, more powerful blending, ideal for tougher ingredients or quicker results.

3. **Blending Technique:** Move the hand blender gently up and down in the container to ensure all ingredients are processed evenly.
4. **Completion:** Release the button to stop the appliance. Wait for the blades to stop completely before removing the blending shaft from the ingredients.

Note: Do not operate the appliance continuously for more than 1 minute. Allow it to cool down for a few minutes before resuming operation.

Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your hand blender.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Detach Shaft:** Twist and pull the blending shaft to detach it from the motor unit.
3. **Clean Blending Shaft and Beaker:** The blending shaft and beaker are dishwasher safe. Alternatively, they can be washed by hand in warm soapy water. Rinse thoroughly and dry. *Caution:* The blades are very sharp. Handle with extreme care.
4. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water or any other liquid.
5. **Storage:** Store the hand blender and its accessories in a dry place.

Troubleshooting

If you encounter any issues with your Braun Multiquick 3 MR300, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not switch on.	Not plugged in; power outage; motor unit not correctly attached to shaft.	Check power connection; check household fuse/circuit breaker; ensure shaft is securely locked.
Poor blending results.	Too little liquid; ingredients too large; blending time too short.	Add more liquid; cut ingredients into smaller pieces; blend for a longer duration.
Appliance stops during operation.	Overheating due to prolonged use or processing very tough ingredients.	Unplug and let the appliance cool down for at least 15-20 minutes. Reduce load for next use.

Specifications

Feature	Detail
Brand	Braun
Model Number	MR300
Power / Wattage	450 watts
Voltage	220 Volts
Number of Speeds	2

Feature	Detail
Capacity (Beaker)	600 Milliliters
Material	Plastic (Motor Unit), Metal (Blending Shaft)
Special Features	Portable, Detachable Shaft
Item Weight	998 g
Product Dimensions	2.54 x 2.54 x 2.54 cm (approximate, as per product data)

Warranty and Support

This Braun Multiquick 3 MR300 Hand Blender comes with an international warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or contact Braun customer service in your region.

For technical support, spare parts, or service inquiries, please visit the official Braun website or contact their authorized service centers. Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 Braun. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B002XLTRX0

More documents and user manuals: **https://manuals.plus/**