Duracell 4332762387

Duracell 303/357/76 Silver Oxide Button Battery User Manual

Model: 4332762387

Product Overview

The Duracell Silver Oxide 303/357 Button Batteries are designed to provide reliable power for a variety of small electronic devices. These 1.5 Volt batteries are suitable for applications such as watches, calculators, laser pointers, and other compatible electronics. They are engineered for long-lasting performance and come in child-secure packaging for enhanced safety.



Image: Front packaging of Duracell 303/357/76 Silver Oxide Button Batteries, showing two batteries and child safety icons.

Safety Information

WARNING: Keep batteries away from children. If swallowed, consult a physician at once.

- Battery can explode or leak if heated, disassembled, shorted, recharged, exposed to fire or high temperature, or inserted incorrectly.
- Do not carry batteries loose in your pocket or purse to prevent short-circuiting.
- For information on treatment if swallowed, call (202) 625-3333 collect.
- The packaging is designed to be child-secure and requires scissors to open.

Setup and Installation

These button batteries are designed for easy installation into compatible devices. Always refer to your device's specific instruction manual for precise battery replacement procedures.

1. **Identify Battery Compartment:** Locate the battery compartment on your device. This is often secured with a small screw or latch.
2. **Open Compartment:** Carefully open the battery compartment using appropriate tools if necessary (e.g., a small screwdriver).
3. **Remove Old Battery (if applicable):** If replacing an old battery, note its orientation (positive (+) and negative (-) terminals) before removal. Dispose of old batteries responsibly.
4. **Insert New Battery:** Insert the new Duracell 303/357/76 battery, ensuring the positive (+) side aligns with the positive indicator in the compartment. The positive side is typically marked with a plus sign or is the flat, smooth side of the battery.
5. **Close Compartment:** Securely close the battery compartment.

Note: Ensure hands are clean and dry during installation to prevent contamination of battery terminals.

Operating Principles

Duracell Silver Oxide batteries provide a stable 1.5 Volt output, ideal for devices requiring consistent power over extended periods. The silver oxide chemistry offers a flat discharge curve, meaning the voltage remains relatively constant throughout the battery's life, ensuring reliable performance until depletion.



Image: A Duracell cylindrical battery next to a button cell battery, with text indicating "LONG LASTING POWER".



Image: Graphic showing various devices like a security camera, smart home control, flashlight, and smartwatch, illustrating the versatility of Duracell batteries.

Maintenance and Storage

Proper maintenance and storage extend battery life and ensure readiness when needed.

- **Storage:** Store unused batteries in their original packaging in a cool, dry place at room temperature. Avoid extreme temperatures and direct sunlight.
- **Guaranteed Storage Life:** These batteries are guaranteed to last for 4 years in storage.
- **Cleaning:** If battery terminals appear dirty, gently wipe them with a clean, dry cloth before installation.
- **Disposal:** Dispose of used batteries according to local regulations. Do not dispose of batteries in household waste or by burning.



Image: Graphic stating "GUARANTEED 4 YEARS IN STORAGE" for Duracell batteries.

Troubleshooting

If your device is not functioning after battery installation, consider the following:

- **Incorrect Orientation:** Verify that the battery is inserted with the correct positive (+) and negative (-) polarity.
- **Poor Contact:** Ensure the battery is making firm contact with the device's terminals. Gently clean terminals if necessary.
- **Device Malfunction:** Test the battery in another compatible device if possible, or test the device with a known good battery, to determine if the issue is with the battery or the device.
- **Battery Depletion:** If the battery has been in use for an extended period, it may be depleted and require replacement.

Specifications

Duracell 303/357/76 Silver Oxide Button Battery Specifications

Attribute	Detail
Brand	Duracell
Model Numbers	303/357/76, 4332762387
Battery Chemistry	Silver Oxide
Voltage	1.5 Volts
Unit Count	3 Count (Pack of 1)
Product Dimensions	0.25 x 1.75 x 3.5 inches
Item Weight	0.176 ounces
Compatible Types	SR44, SR44W, EPX76, SR44SW, 303, 357, D303/357, V303, V357, SR1154
Recommended Uses	Watches, Calculators, Laser Pointers, Digital Thermometers, Stopwatches, and other small electronics.

Quality Assurance and Support

Duracell products are manufactured with a commitment to quality. Every Duracell product is guaranteed against defects in material and workmanship.



Image: Graphic displaying "#1 TRUSTED BATTERY BRAND" for Duracell.

For further assistance or inquiries regarding Duracell products, please refer to the official Duracell website or contact their customer support channels.

© 2025 Duracell. All rights reserved.